

SmartNode™ 10200 Series **TDM+VoIP Smart Media Gateway**

User Manual



Important

This is a Class A device and is not intended for use in a residential environment.

Sales Office: +1 (301) 975-1000
Technical Support: +1 (301) 975-1007
E-mail: support@patton.com
www.patton.com

Part Number: **07MSN10200, Rev. A**
Revised: **April 3, 2012**

Patton Electronics Company, Inc.

7622 Rickenbacker Drive
Gaithersburg, MD 20879 USA
Tel: +1 (301) 975-1000
Fax: +1 (301) 869-9293
Support: +1 (301) 975-1007
Web: www.patton.com
E-mail: support@patton.com

Trademark Statement

The term *SmartNode* is a trademark of Patton Electronics Company. All other trademarks presented in this document are the property of their respective owners.

Copyright © 2012, Patton Electronics Company. All rights reserved.

The information in this document is subject to change without notice. Patton Electronics assumes no liability for errors that may appear in this document.

Warranty Information

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

Patton Electronics warrants all SN10200 components to be free from defects, and will—at our option—repair or replace the product should it fail within one year from the first date of the shipment.

This warranty is limited to defects in workmanship or materials, and does not cover customer damage, abuse or unauthorized modification. If the product fails to perform as warranted, your sole recourse shall be repair or replacement as described above. Under no condition shall Patton Electronics be liable for any damages incurred by the use of this product. These damages include, but are not limited to, the following: lost profits, lost savings and incidental or consequential damages arising from the use of or inability to use this product. Patton Electronics specifically disclaims all other warranties, expressed or implied, and the installation or use of this product shall be deemed an acceptance of these terms by the user.

Summary Table of Contents

1	General Information.....	13
2	Hardware Installation.....	16
3	Initial Setup and Web Management.....	29
4	Contacting Patton	49
A	Compliance information	52
B	Specifications	54

Table of Contents

Summary Table of Contents	3
Table of Contents	4
List of Figures	7
List of Tables	8
About this guide	9
Audience.....	9
Structure.....	9
Precautions	10
Safety when working with electricity	11
General observations	12
Typographical conventions used in this document.....	12
General conventions	12
1 General Information.....	13
SN10200 overview	14
Features	14
SN10200 model codes	15
2 Hardware Installation.....	16
Planning the installation.....	17
Supplies	17
Procedures	17
Mounting the SN10200 to a rack.....	18
Connecting the management interface.....	19
Connecting to the console serial port.....	20
Connecting to a VoIP network.....	21
Connecting to the PSTN.....	22
SCSI Interface (T1/E1)	23
Dual BNC Interface (DS3)	24
Optical Interface (OC3/STM-1)	25
Connecting power	26
Connecting to AC Power	26
Connecting to DC Power	27
Powering Down	28
3 Initial Setup and Web Management.....	29
Overview	30
Accessing the SN10200	30
Accessing the SmartNode via the Console Management port	30
Logging into the SmartNode Console	30
Changing the IP address	31
Setting the IP address to DHCP	32

Accessing the SmartNode via the Ethernet Management port	33
Accessing and Navigating the Web Interface	34
Connecting to the web server and logging on to the Web Portal	34
Connecting to the web server	34
Logging on to the Web Portal	34
Navigating the Web Portal	34
Navigation and Information Panels	34
Knowing Your Location	35
Managing Users.....	36
Understanding User Access Levels	36
Viewing the User List	36
Creating a New User	37
Deleting a User	38
Logging Off	38
Managing the Database Backup.....	39
Carrying out a First Database Backup	39
Downloading a Database Backup	40
Uploading a Database Backup	40
Restoring a Database Backup	40
Working with Configurations.....	41
Managing Applications	41
Viewing the List of Installed Applications	41
Starting an Application	42
Verifying that an Application is Operating	43
Verifying the Application Path	43
Activating the Configuration	44
Verifying status	45
Configuring IP Interfaces	47
List of Parameters	48
4 Contacting Patton	49
Introduction	50
Contact information.....	50
Patton support headquarters in the USA	50
Alternate Patton support for Europe, Middle East, and Africa (EMEA)	50
Warranty Service and Returned Merchandise Authorizations (RMAs).....	50
Warranty coverage	50
Out-of-warranty service	51
Returns for credit	51
Return for credit policy	51
RMA numbers	51
Shipping instructions	51
A Compliance information	52
Compliance.....	53

EMC	53
Low Voltage Directive (Safety)	53
Radio and TV Interference (FCC Part 15)	53
CE Declaration of Conformity	53
Authorized European Representative	53
B Specifications	54
Capacity and voice processing.....	55
Simultaneous signaling support	55
SmartNode-CONTROL.....	55
OAM&P	56
Operating environment	56
Physical characteristics.....	56
Electrical characteristics	56

List of Figures

1	Mounting the SN10200 to a rack	18
2	Connecting the management interface	19
3	Computer to SN10200 Serial Port Connection	20
4	Console pinout	20
5	Connecting to a VoIP network	21
6	SCSI interface to the PSTN	23
7	DS3 interface to the PSTN	24
8	Optical interface to the PSTN	25
9	AC Power Connection	26
10	DC Power Connection	27
11	SN10200 Ethernet Management Interface	33
12	SN10200 Web Portal Navigation	35
13	SN10200 Web Portal Menus	35
14	SN10200 User Access Levels	36
15	Global > Users	36
16	User List	37
17	User List > Create New User	37
18	User List > Delete User	38
19	Navigation Menu: Logout	38
20	Global > Backups	39
21	Backups > Create new database backup	39
22	Database Backup Message	39
23	Database Backup List	39
24	Download Database Backup	40
25	Upload Database Backup File	40
26	Restore Database Backup File	40
27	Applications > Instances	41
28	Application Instance List	41
29	Application Instance List > Edit	42
30	Application Status	42
31	Apply States	42
32	SN10200 Interfaces	43
33	Application Status List	43
34	Global > Systems	44
35	System List	44
36	Name and Activate Configuration	44
37	Successful Activation	45
38	Global > Status	45
39	Status: General View	46
40	Status: Detailed View	46
41	Menu > IP Interfaces	47
42	IP Interface List	47
43	Editing an IP Interface	48

List of Tables

1	General conventions	12
2	SmartNode 10200 PSTN Ports and Voice Channels	15
3	SmartNode 10200 Height Requirements	18
4	Optical Interfaces	25
5	DC Power Cables	27
6	Configuration Parameters for IP Interfaces	48

About this guide

This guide describes the SmartNode 10200 hardware, installation and basic configuration. For detailed software configuration information refer to the *Smart Media Software Configuration Guide* located online at <http://www.patton.com/manuals/Smart Media-scg.pdf>.

Audience

This guide is intended for the following users:

- Operators
- Installers
- Maintenance technicians

Structure

This guide contains the following chapters and appendices:

- [Chapter 1](#) on page 13 provides information about the SN10200's features and capabilities
- [Chapter 2](#) on page 16 provides hardware installation procedures
- [Chapter 3](#) on page 29 provides information on setting up the network and logging into the SN10200
- [Chapter 4](#) on page 49 contains information on contacting Patton technical support for assistance
- [Appendix A](#) on page 52 contains compliance information for the SN10200
- [Appendix B](#) on page 54 contains specifications for the SN10200

For best results, read the contents of this guide *before* you install the SN10200.

Precautions

Notes, cautions, and warnings, which have the following meanings, are used throughout this guide to help you become aware of potential problems. **Warnings** are intended to prevent safety hazards that could result in personal injury. **Cautions** are intended to prevent situations that could result in property damage or impaired functioning.

Note A note presents additional information or interesting sidelights.



The alert symbol and IMPORTANT heading calls attention to important information.



The alert symbol and CAUTION heading indicate a potential hazard. Strictly follow the instructions to avoid property damage.



The shock hazard symbol and CAUTION heading indicate a potential electric shock hazard. Strictly follow the instructions to avoid property damage caused by electric shock.



The alert symbol and WARNING heading indicate a potential safety hazard. Strictly follow the warning instructions to avoid personal injury.



The shock hazard symbol and WARNING heading indicate a potential electric shock hazard. Strictly follow the warning instructions to avoid injury caused by electric shock.

Safety when working with electricity



- Do not open the device when the power cord is connected. For systems without a power switch and without an external power adapter, line voltages are present within the device when the power cord is connected.
- For devices with an external power adapter, the power adapter shall be a listed *Limited Power Source*. The mains outlet that is utilized to power the device shall be within 10 feet (3 meters) of the device, shall be easily accessible, and protected by a circuit breaker in compliance with local regulatory requirements.
- For AC powered devices, ensure that the power cable used meets all applicable standards for the country in which it is to be installed.
- For AC powered devices which have 3 conductor power plugs (L1, L2 & GND or Hot, Neutral & Safety/Protective Ground), the wall outlet (or socket) must have an earth ground.
- For DC powered devices, ensure that the interconnecting cables are rated for proper voltage, current, anticipated temperature, flammability, and mechanical serviceability.
- WAN, LAN & PSTN ports (connections) may have hazardous voltages present regardless of whether the device is powered ON or OFF. PSTN relates to interfaces such as telephone lines, FXS, FXO, DSL, xDSL, T1, E1, ISDN, Voice, etc. These are known as "hazardous network voltages" and to avoid electric shock use caution when working near these ports. When disconnecting cables for these ports, detach the far end connection first.
- Do not work on the device or connect or disconnect cables during periods of lightning activity
- This device contains no user serviceable parts. This device can only be repaired by qualified service personnel.
- If one has reason to open the chassis or case, then the precautions mentioned above shall be followed. This includes both the warnings relating to disconnection of the input power, and the warnings relating to the disconnection of WAN, LAN & PSTN ports.



In accordance with the requirements of council directive 2002/96/EC on Waste of Electrical and Electronic Equipment (WEEE), ensure that at end-of-life you separate this product from other waste and scrap and deliver to the WEEE collection system in your country for recycling.



This device is NOT intended nor approved for connection to the PSTN. It is intended only for connection to customer premise equipment.



Always follow ESD prevention procedures when removing and replacing cards.

Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. Connect the clip to an unpainted surface of the chassis frame to safely channel unwanted ESD voltages to ground.

To properly guard against ESD damage and shocks, the wrist strap and cord must operate effectively. If no wrist strap is available, ground yourself by touching the metal part of the chassis.

General observations

- Clean the case with a soft slightly moist anti-static cloth
- Place the unit on a flat surface and ensure free air circulation
- Avoid exposing the unit to direct sunlight and other heat sources
- Protect the unit from moisture, vapors, and corrosive liquids

Typographical conventions used in this document

This section describes the typographical conventions and terms used in this guide.

General conventions

The procedures described in this manual use the following text conventions:

Table 1. General conventions

Convention	Meaning
Garamond blue type	Indicates a cross-reference hyperlink that points to a figure, graphic, table, or section heading. Clicking on the hyperlink jumps you to the reference.
Futura bold type	Commands and keywords are in boldface font.
<i>Futura bold-italic type</i>	Parts of commands, which are related to elements already named by the user, are in boldface italic font.
<i>Italicized Futura type</i>	Variables for which you supply values are in <i>italic</i> font
Futura type	Indicates the names of fields or windows.
Garamond bold type	Indicates the names of command buttons that execute an action.
< >	Angle brackets indicate function and keyboard keys, such as <SHIFT>, <CTRL>, <C>, and so on.
[]	Elements in square brackets are optional.
{ a b c }	Alternative but required keywords are grouped in braces ({ }) and are separated by vertical bars ()
node	The leading IP address or nodename of a SN10200 is substituted with node in boldface italic font.
SN	The leading SN on a command line represents the nodename of the SN10200
#	An hash sign at the beginning of a line indicates a comment line.

Chapter 1

General Information

Chapter contents

SN10200 overview	14
Features	14
SN10200 model codes	15

SN10200 overview

Service providers are adding VoIP capabilities to their networks, whether to reduce costs when interconnecting with other carriers, to cost-effectively build out their network footprints, or simply to transport voice traffic across their IP backbones. This can be best accomplished using a 16 to 64 E1/T1



SmartNode 10200 Series media gateway, which enables the delivery of VoIP services by bridging voice traffic between the public switched telephone network (PSTN)—based on time-division multiplexing (TDM)—and IP networks such as the Internet. Whether sitting at the network core or at the edge, SmartNode media gateways enable service providers to introduce VoIP into their networks while maintaining the quality and the reliability of traditional TDM networks.

Features

- **TDM Interfaces**

Service providers, whether providing local, long-distance or international voice services, are interconnected with a multitude of other providers using T1/E1, DS3 or STM-1 links. It is critical for service providers to be able to rapidly establish new interconnections without having to always deploy new devices. SmartNode 10200 Series media gateways therefore offer flexibility and can be configured to support T1/E1, DS-3 or STM-1 interfaces.

- **Signaling and Control Protocols:**

Just as flexibility in the selection and deployment of TDM links is a key requirement for service providers, the need to support multiple signaling protocols across various carrier partners is just as important. Each SN10200 media gateway provides support for the concurrent use of ISDN, SS7/C7, CAS (R2), SIP, and SIGTRAN signaling in the same device. The ability to provide both switching and conversion across multiple TDM and IP signaling protocols at once is paramount to enabling the operational flexibility and cost savings that drive service providers to expand their carrier relationships and converge their networks.

In parallel with the TDM and IP signaling protocols mentioned above, SN10200 devices also support the H.248 media gateway control protocol, which enables any H.248-compliant 3-party softswitch to control a media gateway. While the softswitch manages call control interactions, the SN10200 handles transmission of call media as well as any required transcoding.

- **Media Handling**

Service providers will use one or more codecs on their VoIP networks according to their desire to save bandwidth, to provide a certain level of voice quality, or simply to interoperate with other VoIP devices or providers. The ability to support multiple different concurrent codecs and to allocate them in real time based on traffic is the key to delivering true network convergence.

SmartNode 10200 gateways feature extensive support for various wireline, mobile and IP telephony audio formats, delivering seamless transcoding in real-time. The media gateways ship with support for G.711, G.723.1, G.726, and G.729ab right out of the box, with no additional license fee required. They also offer optional support for mobile and IP vocoders such as AMR, AMR-WB (G.722.2), GSM-FR/GSM-EFR,

EVRC/QCELP, G.728, G.729eg, and iLBC. SN10200 gateways offer independent dynamic codec selection per channel. This means that it is possible to assign different vocoders to different channels, on a channel-by-channel basis. The devices can then run all of these codecs concurrently and do so with no impact on system performance.

SN10200 gateways also provide unparalleled support for Internet-based fax, also known as Fax over IP or Fax relay, using the T.38 protocol, which is used to carry fax communications over an IP network. (They also support the T.30 protocol for fax over the PSTN.)

- **System Density**

SN10200 gateways feature the industry's highest system density in a 2U form factor. Beside the capital savings achieved by purchasing less units of equipment, system density also provides operational cost savings in the form of reduced co-location fees as well as lower power and cooling costs.

- **Energy Efficiency**

For many, if not most, service providers, the payoff from reducing energy use can be particularly impressive; typically, for every watt of power required to operate a device, another watt is required to cool it. The SN10200 media gateways can play a major role in reducing energy costs, with an average two-thirds less power consumption than competing products of similar capacity.

- **Provisioning and Maintenance**

For network convergence efforts to contribute positively to revenue and profitability, service providers must maintain their reputation for uptime and availability during the introduction, operation, and maintenance of new services. The SN10200 offers OAM&P, an operations, administration, maintenance, provisioning (OAM&P) solution. OAM&P enables the service provider to perform the initial set-up of the SN10200 media gateway and any subsequent maintenance operations. These range from the simple, such as the collection of statistics and alarms, to the more complex, such as system configuration changes, the addition of new hardware or software components, and the application of software patches or software upgrades.

SN10200 model codes

The SmartNode 10200 series consists of several models. They differ in the type and number of PSTN interfaces and voice channels supported. All models come equipped with one serial console management port, one Ethernet management port, two 100/1000/Base-T VoIP ports and two 100/1000/Base-T Ethernet ports.

The SN10200 models are listed in [table 2](#).

Table 2. SmartNode 10200 PSTN Ports and Voice Channels

Model	E1/T1 Interfaces	DS3 Interfaces	OC3/STM-1 Interfaces	Voice Channels
SN10200/16E/UI	16	-	-	512
SN10200/32E/UI	32	-	-	1024
SN10200/48E/UI	48	-	-	1536
SN10200/64E/UI	64	-	-	2048
SN10200/1DS3/UI	-	1	-	672
SN10200/2DS3/UI	-	2	-	1344
SN10200/3DS3/UI	-	3	-	2016
SN10200/STM1/UI	-	-	1	2016

Chapter 2 **Hardware Installation**

Chapter contents

Planning the installation.....	17
Supplies	17
Procedures	17
Mounting the SN10200 to a rack.....	18
Connecting the management interface.....	19
Connecting to the console serial port.....	20
Connecting to a VoIP network.....	21
Connecting to the PSTN.....	22
SCSI Interface (T1/E1)	23
Dual BNC Interface (DS3)	24
Optical Interface (OC3/STM-1)	25
Connecting power	26
Connecting to AC Power	26
Connecting to DC Power	27
Powering Down	28

Planning the installation

Supplies

In the SN10200 box, you will find:

- One SN10200
- One set of mounting brackets with screws. These are used for mounting a SN10200 on a 19" rack.
- One DB-9 to RJ-45 adapter. Allows you to interface the serial port of your computer with the RJ-45 console port of the SN10200.
- SCSI cables and patch panels. This is optional and only provided for the SN10200-xxE models, which feature SCSI connectors.
- Three CAT5 Ethernet straight cables (male-male), three meters in length.
- One warranty sheet
- One packing slip
- One SN10200 Quick Start guide

Not included with the SN10200:

- No power cords are supplied for AC units. Two DC power cables are included with DC units.
- A 19" equipment rack. You must use a standard 19" wide equipment rack to install the SN10200.

Procedures

To install the SmartNode 10200, follow these steps:

1. Mount the SmartNode 10200 on an equipment rack (See [“Mounting the SN10200 to a rack”](#) on page 18)
2. Connect the management interface (See [“Connecting the management interface”](#) on page 19)
3. Connect the VoIP ports to the network (See [“Connecting to a VoIP network”](#) on page 21)
4. Connect the correct interfaces to the PSTN (See [“Connecting to the PSTN”](#) on page 22)
5. Connect to the power source (See [“Connecting power”](#) on page 26)

Mounting the SN10200 to a rack

The SN10200 is mounted on a customer provided equipment rack using the mounting hardware packaged in the box. To rack mount the SN10200, you will need:

- One 19" customer provided equipment racks. The rack must be solidly anchored to the floor with appropriate support at the top of the racks.
- Climate controlled room: 0 to +50 Celsius, 0 to 95% non-condensing humidity.

The SN10200 is housed in a 2U chassis, as described in [table 3](#). It is important that you provide for enough room on the equipment rack to allow for the installation of the SN10200. Consider the available space on your equipment rack and the height of the SN10200. Due to the rear-exhaust, heat vents and the efficient heat dissipation design, there is no need to leave any physical vertical space above or below the placement of the SN10200 on the equipment rack.

Table 3. SmartNode 10200 Height Requirements

Model	Vertical Height
SmartNode 10200	2U (3.5 inches or 89.10 mm)
Patch Panels ^a	1U (1.75 inches or 44.45 mm)

a. SN10200 models configured with a 32 to 64 T1/E1 TDM module require one patch panel for each 32 E1/T1 line grouping.

The SN10200 is mounted on the 19" equipment rack using the angle brackets and screws provided in the box. To mount the SN10200, follow these steps:

1. Using two metal screws, attach one angle bracket to the front, left-hand side of the SN10200 when viewed from the front, as shown in figure 2.1 on page 8. Do the same for the angle bracket on the right-hand side.
2. Start mounting equipment at the top-most position of the rack, keeping in mind the space required on the equipment rack ([table 3](#)).




Figure 1. Mounting the SN10200 to a rack

Connecting the management interface

The SmartNode 10200 Management Interface enables administrators to perform management tasks on the SN10200. To communicate with the Smart Media Management Interface for a SN10200, you will need a CAT5 Ethernet cable with RJ45 male-male terminations.

The SN10200 provides a Management Interface, using one Gigabit Ethernet network link, as shown in [Figure 2](#). To communicate with the Management Interface:

1. Connect the supplied CAT5 Ethernet cable to the management port labeled **Ethernet** on the front of the SmartNode 10200.
2. Log into the SmartNode using the specific credentials included on the sheet that shipped with your unit.




Figure 2. Connecting the management interface

Note The management port is configured using DHCP by default. Refer to [“Connecting to the console serial port”](#) on page 20 to change the IP address.

Connecting to the console serial port

The serial port interface enables administrators to perform management tasks on the SN10200. To connect to the serial port of a SN10200:

1. Connect a CAT5 RJ-45 (male-male) cable (supplied with unit) between the COM port of your computer and the serial port (labelled 1010) of the SN10200 as shown in [Figure 3](#).
2. If your computer's serial port features a DB9 connector, use the DB9 to RJ-45 adapter supplied with your SN10200. If your computer's serial port features a USB connector, you will need to provide a USB to DB9 adapter.




Figure 3. Computer to SN10200 Serial Port Connection




Figure 4. Console pinout

3. You must configure a terminal emulator or console application (such as HyperTerminal or Putty) to communicate with the SN10200 in order to configure initial settings. Configure the terminal emulator with the following settings:

Baud rate	Data rate	Parity	Stop bits	Flow control
9600	8 bits	None	1	None

4. To log into the console, use the specific credentials included on the sheet that shipped with your unit. For details about how to change the IP address via the console, see [“Accessing the SmartNode via the Console Management port”](#) on page 30.

Connecting to a VoIP network

The SN10200 features dual GigE ports for connection to different VoIP networks. This provides an access point to manage VoIP traffic. Should one of the IP networks fail, the SN10200 will continue to manage VoIP traffic using the alternate network.

Note Certain configurations of the SN10200 will exceed 100 Mbps, therefore 1000 Mbps is recommended.

To connect the SN10200 to the VoIP network, you will need:

- Gigabit Ethernet switch. A second one is required to support redundancy of the VoIP interface
- One or two CAT5 Ethernet cables with RJ45 male-male terminations.

The SN10200 is connected to the VoIP network by one or optionally two Ethernet GigE network links, as shown in [Figure 5](#). To connect the SN10200 to the VoIP network:

1. Connect a CAT5 Ethernet cable to VoIP0 at the rear of the SN10200. Connect the other end of the same CAT5 cable to the Gigabit Ethernet switch.
2. If your system employs a second Gigabit Ethernet switch for redundancy, connect a second CAT5 Ethernet cable to VoIP1 at the rear of the SN10200. Connect the other end of the same CAT5 cable to the second Gigabit Ethernet switch.




Figure 5. Connecting to a VoIP network

Connecting to the PSTN

The SN10200 features a variety of interfaces to the PSTN network. To connect the SN10200 to the PSTN network, you must comply with one of the following:

- The SN10200-xxE features SCSI connectors for connection to T1/E1 lines. You will require one patch panel for each 32 line grouping of T1/E1 line interfaces on the SN10200.
- The SN10200-DS3 features BNC connectors for connection to DS3 lines. You will require two coaxial cables for each DS3 interface.
- The SN10200-STM1 features electrical or optical STM-1 connectors. You will require two fibre optic cables for the STM-1 interface of the SN10200.

SCSI Interface (T1/E1)

A SN10200-xxE with 4 SCSI connectors enables the connection to T1/E1 lines. The termination impedance is set at 120 ohms. It is possible to connect an external balun in order to convert to 75 ohms (Figure 6).

Note All ports may not be active. T1/E1 ports are activated by software license; the number of active ports depends on the licenses purchased.

To connect the SN10200 (SCSI) to the PSTN:

1. Start with the SCSI ports 0-15 located at the bottom right as shown in Figure 6. Connect one SCSI cable between this port and SCSI patch panel number 1, ports 0-15. Connect SCSI ports 16-31 to patch panel number 1, ports 16-31.
2. Repeat step 1, using lines 32-63 and a second patch panel. Connect lines 32-47 to patch panel 2, ports 0-15. Connect lines 48-63 to patch panel 2, ports 16-31.




Figure 6. SCSI interface to the PSTN

Dual BNC Interface (DS3)

A SN10200-DS3 with 3 sets of BNC connectors enables the connection to DS3 lines (Figure 7).

Note All ports may not be active. DS3 ports are activated by software license; the number of active ports depends on the licenses purchased.

To connect the SN10200-DS3 to the PSTN:

1. Start with the Dual BNC port pair #0 (right-most) as shown in Figure 7. Connect one pair of BNC cables between this port and the DS3 line.
2. Repeat step 1, using the next available pair of BNC PSTN interface ports.




Figure 7. DS3 interface to the PSTN

Optical Interface (OC3/STM-1)

A SN10200-STM-1, with one main and one backup OC3 or STM1 port enables connection to OC3/STM1 lines (Figure 8). Refer to table 4 for a listing of optical interfaces. The default SFP module for OC3/STM1 connection is SMF, intermediate reach, (SFP-OC3-IR1) 1310 nm with LC type connectors.

Note Please make certain that the correct SFP model is selected at the time of ordering. If your installation requires a different model from the one that has been provided, you must replace it.

Automatic Protection Switching: The APS port is used for OC3/STM1 redundancy. Switchover occurs automatically based on configurable parameters. It is recommended that APS be used if the installation provides this feature.

To connect the SN10200-STM1 (Optical Interface) to the PSTN:

1. Connect a fiber optic cable between the Port 0 (Main) port and OC3/STM1 line.
2. Connect a fiber optic cable between the Port 1 (APS) port and OC3/STM1 line.




Figure 8. Optical interface to the PSTN

Table 4. Optical Interfaces

Tranceiver Model	Description	Spec	Mode	Type	Range (km)	Wavelength	Connection
SFP-OC3-IR1	OC3/STM1	Hot Pluggable	Single-mode	Intermediate reach	15	1310	LC
SFP-STM1E	STM1 (Electrical)	Hot Pluggable	75 ohms Copper	Max 180m	Variable range	N/A	DIN (mini-coax)

Connecting power

The SN10200 is furnished with two AC or DC power connections. Only once all other equipment installation work has been completed should the SN10200 be powered up.

To power the SN10200, you will need:

- A power source
- Two power cables for the SN10200

Refer to the following sections for information about power:

- “Connecting to AC Power” on page 26
- “Connecting to DC Power” on page 27
- “Powering Down” on page 28

Connecting to AC Power

The SN10200 AC model is furnished with two AC power connectors.

To connect the SN10200 to AC Power:

1. Connect an AC power cable between the AC connector of the SN10200 and an AC supply (Figure 9).

Note If the SN10200 features a second power supply and it is not connected to an AC power source, press the green button located at the rear of the unit to disable the audible alarm.

2. Power up the SN10200 by turning on its power switch(es).




Figure 9. AC Power Connection

Connecting to DC Power

The SN10200 DC models are furnished with two DC power connection ports. In addition, each DC powered SN10200 is supplied with two DC power cables.

To connect the SN10200 to DC power:

1. Connect one DC cable, supplied with the SN10200, as shown in Figure 10, to the DC outlet at the rear of the SN10200.
2. Connect one lead of the DC power cable to the positive terminal of the DC power source, as shown in Figure 10.
3. Connect the other lead of the DC power cable to the negative side of the DC power source.
4. Repeat steps 1-3 for the second power DC power source.




Figure 10. DC Power Connection

Table 5. DC Power Cables

Cable Type	Voltage	
	OV/Ground	-48V
Yellow/Black	Black	Yellow
Red/Black	Red	Black

Powering Down

Powering down the SN10200 requires that the Linux embedded host be shut down. In order to do this, you must connect to the management interface using SSH, and enter:

```
shutdown -hp now
```



DO NOT TURN OFF the power to the SN10200 using the power switch located at the rear, unless the Linux host has been properly shut down beforehand, using the reset button display, or manually using the shutdown command.

Allow enough time for the Linux host to shut down before turning the power to the SN10200 off (e.g. 1 min). Be aware that the shutdown procedure of the unit is logged and traceable for support and warranty purposes.

Chapter 3 **Initial Setup and Web Management**

Chapter contents

Overview	30
Accessing the SN10200	30
Accessing the SmartNode via the Console Management port	30
Logging into the SmartNode Console	30
Changing the IP address	31
Setting the IP address to DHCP	32
Accessing the SmartNode via the Ethernet Management port	33
Accessing and Navigating the Web Interface	34
Connecting to the web server and logging on to the Web Portal	34
Connecting to the web server	34
Logging on to the Web Portal	34
Navigating the Web Portal	34
Navigation and Information Panels	34
Knowing Your Location	35
Managing Users.....	36
Understanding User Access Levels	36
Viewing the User List	36
Creating a New User	37
Deleting a User	38
Logging Off	38
Managing the Database Backup.....	39
Carrying out a First Database Backup	39
Downloading a Database Backup	40
Uploading a Database Backup	40
Restoring a Database Backup	40
Working with Configurations.....	41
Managing Applications	41
Viewing the List of Installed Applications	41
Starting an Application	42
Verifying that an Application is Operating	43
Verifying the Application Path	43
Activating the Configuration	44
Verifying status	45
Configuring IP Interfaces	47
List of Parameters	48

Overview

This chapter explains how to connect the SmartNode 10200 to the network, and how to access and manage the SmartNode Web Interface. Refer to the following sections for more details on:

- “Accessing the SN10200” on page 30
- “Accessing and Navigating the Web Interface” on page 34
- “Managing Users” on page 36
- “Managing the Database Backup” on page 39
- “Working with Configurations” on page 41

Note For more detailed information about working with specific applications and configurations, refer to the *Smart Media Software Configuration Guide* located online at www.patton.com/manuals/SmartMedia_SCG.pdf.

Accessing the SN10200

You may access the SmartNode through the console management port, or through the Ethernet management port. Refer to the following sections for more information:

- “Accessing the SmartNode via the Console Management port” on page 30
- “Accessing the SmartNode via the Ethernet Management port” on page 33

Accessing the SmartNode via the Console Management port

Logging into the SmartNode Console

1. To physically connect the console serial port, follow the instructions in “Connecting to the console serial port” on page 20.
2. To communicate with the SN10200 through the console port, you must first configure a terminal emulator or console application (such as HyperTerminal or Putty) in order to configure initial settings. Configure the terminal emulator with the following settings:

Baud rate	Data rate	Parity	Stop bits	Flow control
9600	8 bits	None	1	None

3. Log into the console using the specific credentials included on the sheet that shipped with your unit. The factory default configuration for the Ethernet interface IP addresses and network masks are listed below.

	IP Address	Network Mask
Ethernet Management (ETH 0/0)	DHCP	255.255.255.0
DHCP address range	192.168.1.10–192.168.1.19	255.255.255.0

Changing the IP address

1. After logging into the console port, enter the following command to view the **eth0** configuration:

```
vi /etc/sysconfig/network-scripts/ifcfg-eth0
```

Note You must remove the line **DHCP_HOSTNAME**. The **eth1** interface must remain as *172.31.1.2*.

Example:

```
DEVICE=eth0
BOOTPROTO=static
IPADDR=192.168.1.10
NETMASK=255.255.255.0
IPV6ADDR=
IPV6PREFIX=
IPV6_AUTOCONF=yes
ONBOOT=yes
```

2. Add the default gateway address to the network configuration file:

```
vi /etc/sysconfig/network
```

Example:

```
HOSTNAME=TB005376
NETWORKING=yes
GATEWAY=192.168.1.1
```

3. Modify the DHCP client configuration:

Note If you don't have a nameserver, remove it from the file. If you have a nameserver, set it to a valid DNS.

```
vi /etc/resolv.conf
```

Example (*DNS configuration file without DNS server*):

```
; generated by /sbin/dhclient-script
```

Example (*DNS configuration file containing a DNS server*):

```
; generated by /sbin/dhclient-script
nameserver 4.2.2.2
```

4. Restart the network interfaces:

```
/etc/init.d/network restart
```

Setting the IP address to DHCP

1. To change the IP address from static to DHCP, enter the following command to modify the **eth0** configuration:

```
vi /etc/sysconfig/network-scripts/ifcfg-eth0
```

Note You must remove the **IPADDR** and **NETMASK** lines. The **eth1** interface must remain as *172.31.1.2*.

Example:

```
DEVICE=eth0
BOOTPROTO=dhcp
IPV6ADDR=
IPV6PREFIX=
IPV6_AUTOCONF=yes
ONBOOT=yes
DHCP_HOSTNAME=TB005376
```

2. Remove the default gateway address in the network configuration file:

```
vi /etc/sysconfig/network
```

Example:

```
HOSTNAME=TB005376
NETWORKING=yes
```

3. Modify the DHCP client configuration:

Note If you don't have a nameserver, remove it from the file. If you have a nameserver, set it to a valid DNS.

```
vi /etc/resolv.conf
```

Example (DNS configuration file without DNS server):

```
; generated by /sbin/dhclient-script
```

Example (DNS configuration file containing a DNS server):

```
; generated by /sbin/dhclient-script
nameserver 4.2.2.2
```


Accessing the SmartNode via the Ethernet Management port

The SN10200 is shipped with the SN-CTRL pre-installed. In order to make changes to the system configuration, you must connect to the **Management** port labeled **Ethernet** on the front of the SN10200 to a terminal.

To access the SN10200, you must use an SSH connection. The password is set at the factory and is indicated on the shipment sheet.




Figure 11. SN10200 Ethernet Management Interface

Accessing and Navigating the Web Interface

This section describes how to login and navigate the SmartNode 10200 Web Portal.

Connecting to the web server and logging on to the Web Portal

The first step involved in initially configuring any Smart Media system involves logging on to the Web Portal. This can be divided into two distinct tasks: Connecting to the web server, and logging on to the Web Portal.

Connecting to the web server

Using a web browser, connect to the Web Portal by typing the following in your address bar:

- **http://[DEVICE HOST NAME]:12358**

or, alternately,

- **http://[DEVICE IP ADDRESS]:12358**

Logging on to the Web Portal

In order to log on to the Web Portal configuration tool, enter the root user ID and password. The default values for these parameters are:

- **User ID:** root

- **Default password:** root

Navigating the Web Portal

Effective use of the Web Portal requires a basic understanding of the physical elements of the tool, how to access its various components and knowing your current location in the Web Portal display. The following topics are covered: *Navigation and Information Panels* and *Knowing Your Location*.

Navigation and Information Panels

The Web Portal has been designed with a consistent streamlined approach for the presentation of Smart Media configuration data. Information related to the hierarchy of data is displayed in the left-hand navigation panel, while information related to a selected category is displayed in the information panel found on the right side of the window.

Selecting a category in the navigation panel causes related configuration and status information to be dynamically displayed. The navigation panel displays information in a tree-like structure enabling you to understand how configuration parameters are contained by others.

Note Figure 12 on page 35 shows the SmartNode 10200 Web Portal. The navigation panel is located to the left of the screen. The information panel is located to the right.




Figure 12. SN10200 Web Portal Navigation

Knowing Your Location

As you navigate the Web Portal, it is important that you understand how to determine your current location. The Web Portal has been designed to make this easy for you. When you browse through the navigation panel, your current selection is always indicated by a graphical highlight. In addition, the system configuration that you are using and the specific Smart Media unit that is being configured is always displayed, as shown in the figure below.




Figure 13. SN10200 Web Portal Menus

- **1:** Indicates status Global sub-menu.
- **2:** Indicates a configuration named Student is selected.
- **3:** Indicates the Smart Media hardware device that is selected.
- **4:** Displays information concerning the system.

Managing Users

This section describes how to manage user access levels in the SN10200 Web Portal. (Refer to “[Connecting to the web server and logging on to the Web Portal](#)” on page 34 for information about how to login to the Web Portal).

Understanding User Access Levels

The Web Portal is designed to provide varying degrees of write and read privileges to users. By default, the root user is given full read and write access. This is required so that the root user can function as the system administrator without any restrictions imposed. Subsequent users can be created with the ability to read and write, or just to read. An integer value from 0 - 9 is assigned to each user.




Figure 14. SN10200 User Access Levels

- A user with an access level of 0 has access to configurations created with levels 0 - 9.
- A user with an access level of 4, will have access to configurations created with user levels 4 - 9.
- Configurations created with user levels 0 - 3 will be invisible to user levels 4-9.

Viewing the User List

It is possible to create an unlimited list of users, each with an assignment from 0-9. Any user can view the entire list of users, however only a root user with an access level of 0 can modify the access rights of other users.

To view the user list:

1. Select **Users** from the navigation panel.





Figure 15. Global > Users

2. The **User List** is displayed.




Username	Read Privilege Level	Write Privilege Level	Actions
root	0	0	Edit Delete
Test	1	3	Edit Delete

Figure 16. User List

Creating a New User

1. Select **Users** from the navigation panel.
2. Click **Create New User**.



Configuration

[List](#)

Creating New User:

Name

Password

Read privilege Level

Write privilege Level

Figure 17. User List > Create New User

3. Enter a **User Name** and **Password**.
4. Select a **Read Privilege Level** (from 0-9).
5. Select a **Write Privilege Level** (from 0-9).
6. Press **Create** to save your changes. The **User List** window is displayed with the newly added user.

Deleting a User

1. Select **Users** from the navigation panel.
2. Click **Delete** in the information panel, next to the user account that you wish to delete.

User List

Username ^	Read Privilege Level	Write Privilege Level	Actions	
root	0	0	Edit	Delete
Test	1	3	Edit	Delete

Figure 18. User List > Delete User

3. Click **OK** to confirm the deletion.
4. The modified **User List** is displayed.

Logging Off

When you are finished working in the Web Portal, it is recommended that you log out from your session. If you do not log out, the session between the Web Browser on your PC and the Web Portal remains active.

To log out from the Web Portal, select Logout from the navigation panel.



Figure 19. Navigation Menu: Logout

Managing the Database Backup

After carrying out system modifications, it is recommended that you back up the SQL database. This section describes how to back up the database for the first time, retrieve a saved backup file, upload a new backup file, and restore the database from a backup file.

Carrying out a First Database Backup

To create a backup file of the database:

1. Click **Backups** in the navigation panel.



Figure 20. Global > Backups

2. Click **Create**, under Create New Database Backup.




Figure 21. Backups > Create new database backup

3. Verify that the “**Database backup dump was successfully started. Refresh this page when it is done**” message appears. Then, refresh your Internet browser page.

Database backup dump was successfully started. Refresh this page to see when it is done.

Figure 22. Database Backup Message

4. Verify that your new backup appears in the **Database Backup List**.

Database Backup List

Name	Actions
toolpack_2_6_10_2011_12_07_08_32_41.sql.gz	Rename Download Validate Recover Delete

Figure 23. Database Backup List

Downloading a Database Backup

Once you have created a backup of your database, it is recommended that you download it to store it to an external storage device.

1. Click the **Download** link to store your backup externally.

Database Backup List

Name	Actions
toolpack_2_6_10_2011_12_07_08_32_41.sql.gz	Rename Download Validate Recover Delete

Figure 24. Download Database Backup

2. Click **Save** in the pop-up window to store the backup.

Uploading a Database Backup

An external backup of your database can be uploaded to your SmartNode 10200.

1. Click the **Choose File** tab, under Upload Database Backup, and select your external database backup.

Upload database backup

Backup file Choose File No file chosen

Figure 25. Upload Database Backup File

2. Click the **Upload** tab, under Backup File.

Restoring a Database Backup

The configuration settings of your system can be restored from a local or remote copy of your database.

1. Click the Recover link, under Database Backup List, to overwrite the current database and restore your file backups.

Database Backup List

Name	Actions
toolpack_2_6_10_2011_12_07_08_32_41.sql.gz	Rename Download Validate Recover Delete

Figure 26. Restore Database Backup File

2. After a few minutes, the Web Portal will come back online and the new configuration will be available. You need to activate the configuration to apply the changes.

Working with Configurations

This section explains how to manage applications and instances on the SN10200 Web Portal, how to activate a configuration, and how to configure IP interfaces. Refer to the following sections for information on:

- “Managing Applications” on page 41
- “Activating the Configuration” on page 44
- “Configuring IP Interfaces” on page 47

Note For more detailed information about working with specific applications and configurations, refer to the *Smart Media Software Configuration Guide* located online at www.patton.com/manuals/SmartMedia_SCG.pdf.

Managing Applications

This section explains how to start up and verify applications and instances on the Smart Media application server.

Viewing the List of Installed Applications

The Smart Media application server is designed to run a large variety of applications. Before you can run an application, you must first be able to view it from a list of applications. To view the selection of applications:

1. Select **Instances** from the navigation panel.



Figure 27. Applications > Instances

2. The **Application Instance List** is displayed in the information panel.

Application Instance List

Name	Host Name	Target State	Application Config	Actions
gateway	SKULLHEAD	Run	gateway	Edit
logtrace	SKULLHEAD	Run	logtrace	Edit
stream_server	SKULLHEAD	Dont run	stream_server_1	Edit
tboam_app	SKULLHEAD	Run	tboamapp	Edit
tbsnmpagent	SKULLHEAD	Dont run	tbsnmpagent	Edit
tbuctwriter	SKULLHEAD	Run	tbuctwriter	Edit
toolpack_engine	SKULLHEAD	Run	toolpack_engine	Edit
toolpack_sys_mgr	SKULLHEAD	Run	toolpack_sys_mgr	Edit

Figure 28. Application Instance List

Applications are displayed in one of three states:

- Run (application is operating)
- Management (application is installed but not in operation)
- Fault (application has an operation fault)

Starting an Application

In order to be able to load and start an application, it will need to have been installed on the Smart Media application server. In addition, at least one Smart Media unit must have been configured on the Smart Media application server so that you are able to connect to it.

When you first log on to the Web Portal, your system application will have been installed on the Smart Media application server, and it will be in a management state. This means that the application is not yet operating and controlling your system. In order to start an application, its state must be changed from Management to Run. To start an application:

1. Select **Instances** from the navigation panel.
2. Select the application that you wish to run and click **Edit**.

Name	Host Name	Target State	Application Config	Actions
gateway	SKULLHEAD	Run	gateway	Edit
logtrace	SKULLHEAD	Run	logtrace	Edit
stream_server	SKULLHEAD	Dont run	stream_server_1	Edit
tboam_app	SKULLHEAD	Run	tboamapp	Edit
tbsnmpagent	SKULLHEAD	Dont run	tbsnmpagent	Edit
tbuctwriter	SKULLHEAD	Run	tbuctwriter	Edit
toolpack_engine	SKULLHEAD	Run	toolpack_engine	Edit

Figure 29. Application Instance List > Edit

3. Click the **Status** tab to activate the application.

Figure 30. Application Status

4. Set the **Oam target state** to **Run**.
5. Click **Apply States**.

Figure 31. Apply States

Verifying that an Application is Operating

When an application's target state is set to run, there are a number of crucial verifications that you should conduct in order to know that an application is running properly. These verifications are as follows:

- **Verify the application's current path.** It is important that once the application has been set to run, a path is displayed.
- **Verify the TDM interface.** If you are running a TDM application on your Smart Media unit then you can verify the TDM interface. Although, you most likely have not yet configured the TDM interface of the Smart Media unit, certain status LEDs will indicate that your application is operational.
- **Verify the IP Interfaces.** Your Smart Media unit is furnished with two IP interfaces for access to a VoIP network. Although you have not as of yet configured the interfaces, certain LED indications will be displayed. See [Figure 32](#) below.




Figure 32. SN10200 Interfaces

Verifying the Application Path

One important indication of the normal operation of an application is when the application path is displayed in the hardware status window. To verify that the application path is displayed:

1. Select **Instances** from the navigation panel.
2. Click the **Status** tab, in the Application Instances window, to view the application path
3. Verify that the application path is displayed. Verify that the target state is set to **Run**, the current state displays **Ready**, and the current HA state displays **Active**.

Application Status List

Status Options

Refresh every:

Name	Host	Oam target state	Oam target update state	Oam current state	Current bin path	Oam ha current state
gateway	SKULLHEAD	Run	Run	Not running	w:\tb\pkg\2.6.10\bin\release\i586-msvc8\gateway.exe	Not present
logtrace	SKULLHEAD	Run	Run	Not running	w:\tb\pkg\2.6.10\bin\release\i586-msvc8\tblogtrace.exe	Not present
stream_server	SKULLHEAD	Dont_run	Run	Not running		Not present
tboam_app	SKULLHEAD	Run	Run	Not running		Not present
tbsnmpagent	SKULLHEAD	Dont_run	Run	Not running		Not present
tbuctwriter	SKULLHEAD	Run	Run	Not running	w:\tb\pkg\2.6.10\bin\release\i586-msvc8\tbuctwriter.exe	Not present
toolpack_engine	SKULLHEAD	Run	Run	Not running	w:\tb\pkg\2.6.10\bin\release\i586-msvc8\toolpack_engine.exe	Not present
toolpack_sys_mgr	SKULLHEAD	Run	Run	Not running	w:\tb\pkg\2.6.10\bin\release\i586-msvc8\toolpack_sys_manager.exe	Not present

Figure 33. Application Status List

Activating the Configuration

Changes made to the configuration of the Smart Media units are stored on the OAM&P Configuration and Logging database. In order for changes to be used by the system, they must first be activated. This is done at the system level and accessed from the Navigation panel.

Note To activate a configuration, you must be the Root user or have a user access level of 0.

1. Select **Systems** from the navigation panel.




Figure 34. Global > Systems

2. Click **Edit** next to the system you wish to activate, in order to access the System Configuration screen.

System List

Name	Gateway Port	Active Configuration	Target Configuration	Active Package	Target Package	Actions
system_1	12358	config_1		2.6.10_package		Edit Delete

Figure 35. System List

3. Activate the configuration. Enter a name for the system. Under **Activate Configuration**: Select a Configuration on which to run the system. Click **Activate**.

Note Make certain that **Lock Active Configuration** box (located at the top of the page) is 'unchecked.' Failure to do so will prevent the configuration from being saved.

 A screenshot of a web application's 'System Configuration' screen. The screen has two tabs: 'System' and 'Status'. The 'System' tab is active. Below the tabs, there is a 'List' link. The main content area is divided into two sections. The first section, 'Editing system:', contains a 'Name' field with the value 'system_1', a 'Gateway Port' field with the value '12358', and a 'Lock active configuration' checkbox which is unchecked. There is a 'Save' button below this section. The second section, 'Activate configuration', contains a 'Configuration' dropdown menu with the value 'config_1' and an 'Activate' button. The 'Activate' button is circled in red. Below the 'Activate' button, there is a message that says 'No validation requested.'

Figure 36. Name and Activate Configuration

4. Verify that an activation confirmation message is displayed. The system will remind you to back up your database when you are done configuring (at top of screen, in yellow).

The screenshot shows the 'System' tab of the SmartNode web management interface. It features two main sections: 'Editing system:' and 'Activate configuration'. In the 'Editing system:' section, there are three input fields: 'Name' (containing 'system_1'), 'Gateway Port' (containing '12358'), and 'Lock active configuration' (an unchecked checkbox). A 'Save' button is located below these fields. The 'Activate configuration' section contains a 'Configuration' dropdown menu set to 'config_1' and an 'Activate' button, which is circled in red. Below the 'Activate' button, the text 'No validation requested.' is displayed.

Figure 37. Successful Activation

Verifying status

General and detailed status information about the applications that are run by one or more host machine(s) is accessible from the **Applications** tab of the Global-->Status menu.




Figure 38. Global > Status

You may view the status in *General View* or *Detailed View*.

General View: The general view, shown below, lists the applications, and their current general status (ready, fault, not running). This window also provides a count of all applications with ready or fault status.

Status Options

Refresh every:

Extended status ☐

Applications

name	value
Ready cnt	6
Fault cnt	0

SKULLHEAD

states	list
Ready list	tboam_app.gateway , toolpack_sys_mgr.logtrace , toolpack_engine.tbuctwriter , stream_server.tbismpagent
Fault list	
Not running list	

Figure 39. Status: General View

Detailed View: A more detailed description of each application can be viewed by following the appropriate link in the general window (shown above). The detailed status screen, shown below, lists the states of the application, its name, the host machine and the location of the application on the host.

From this detailed view, the **Oam target state may be changed**.

To modify the Oam target state of an application: Select a state from the **Oam target state** combo box. Click **Apply States** to change the states.

Configuration **Status**

[List](#)

Application Instance Status - SKULLHEAD.gateway

Status Options

Refresh every:

Extended status ☐

Name	Value
Host	SKULLHEAD
Name	gateway
Oam target state	<input type="button" value="Run"/>
Oam target update state	Run
Oam current state	Ready
Current bin path	w:\tb\pkg\2.6.10\bin\release\l586-msvc8\gateway.exe
Working dir	
Oam ha current state	Active

Apply states

Figure 40. Status: Detailed View

Configuring IP Interfaces

The IP interface of the VoIP0 and VoIP1 ports can be configured by setting the following:

- IP Address
- Netmask
- Gateway

To configure a VoIP0 or VoIP1 port:

1. Select **IP Interfaces** from the navigation pane:




Figure 41. Menu > IP Interfaces

2. Click **Edit** from the IP Interfaces Information panel.

IP Interface List

Name ^	IP Address	Netmask	Gateway	DHCP	Actions
ETH0	10.3.2.19	255.255.252.0	10.3.0.1	false	
ETH1	10.3.6.19	255.255.252.0	10.3.4.1	false	
VOIP0	10.3.10.19	255.255.252.0	10.3.8.1	false	Edit

Figure 42. IP Interface List

3. Configure the IP port:
 - Indicate whether or not to use **DHCP** on this port
 - Enter an **IP address**
 - Enter a **Netmask**
 - Enter a **gateway address**
 - Click **Save**

Note The IP addresses of ETH0, ETH1, VOIP0 and VOIP1 must be on different subnets.

Editing IP Interface:

Interface name	VOIP0
Use DHCP	<input type="checkbox"/>
Ip address	67.101.23.83
Netmask	255.255.255.192
Gateway	67.101.23.65
<input type="button" value="Save"/>	

Figure 43. Editing an IP Interface

- The changes are displayed in the IP interfaces information panel.



The system will display the following notice, describing steps to apply your new configuration:

NOTE: To apply IP configuration change, activate current configuration, then reboot the adapter.

- Activate the configuration: Systems -> Edit -> Activate
- Reboot the adapter (will drop active calls): Status -> Adapters -> Click on the adapter Serial Number -> Reboot adapter. It will take about 1.5 minutes to restart the unit.

List of Parameters

Table 6. Configuration Parameters for IP Interfaces

Parameter	Description
Use DHCP	Indicates that the DHCP autoconfiguration protocol is to be used on an IP port.
IP Address	Sets an address for accessing a new media gateway controller (MGC).
Netmask	Sets a subnetwork mask number on an IP port.
Gateway	Associates the address of a TCP/IP network gateway with an IP port.

Chapter 4 **Contacting Patton**

Chapter contents

Introduction	50
Contact information.....	50
Patton support headquarters in the USA	50
Alternate Patton support for Europe, Middle East, and Africa (EMEA)	50
Warranty Service and Returned Merchandise Authorizations (RMAs).....	50
Warranty coverage	50
Out-of-warranty service	51
Returns for credit	51
Return for credit policy	51
RMA numbers	51
Shipping instructions	51

Introduction

This chapter contains the following information:

- “Contact information”—describes how to contact Patton technical support for assistance.
- “Warranty Service and Returned Merchandise Authorizations (RMAs)”—contains information about the RAS warranty and obtaining a return merchandise authorization (RMA).

Contact information

Patton Electronics offers a wide array of free technical services. If you have questions about any of our other products we recommend you begin your search for answers by using our technical knowledge base. Here, we have gathered together many of the more commonly asked questions and compiled them into a searchable database to help you quickly solve your problems.

Patton support headquarters in the USA

- Online support: available at **www.patton.com**
- E-mail support: e-mail sent to **support@patton.com** will be answered within 1 business day
- Telephone support: standard telephone support is available five days a week—from **8:00 am to 5:00 pm EST (1300 to 2200 UTC/GMT)**—by calling **+1 (301) 975-1007**
- Fax: **+1 (253) 663-5693**

Alternate Patton support for Europe, Middle East, and Africa (EMEA)

- Online support: available at **www.patton.com**
- E-mail support: e-mail sent to **support@patton.com** will be answered within 1 business day
- Telephone support: standard telephone support is available five days a week—from **9:00 am to 5:30 pm CET (0800 to 1630 UTC/GMT)**—by calling **+41 (0)31 985 25 55**
- Fax: **+41 (0)31 985 25 26**

Warranty Service and Returned Merchandise Authorizations (RMAs)

Patton Electronics is an ISO-9001 certified manufacturer and our products are carefully tested before shipment. All of our products are backed by a comprehensive warranty program.

Note If you purchased your equipment from a Patton Electronics reseller, ask your reseller how you should proceed with warranty service. It is often more convenient for you to work with your local reseller to obtain a replacement. Patton services our products no matter how you acquired them.

Warranty coverage

Our products are under warranty to be free from defects, and we will, at our option, repair or replace the product should it fail within one year from the first date of shipment. Our warranty is limited to defects in workmanship or materials, and does not cover customer damage, lightning or power surge damage, abuse, or unauthorized modification.

Out-of-warranty service

Patton services what we sell, no matter how you acquired it, including malfunctioning products that are no longer under warranty. Our products have a flat fee for repairs. Units damaged by lightning or other catastrophes may require replacement.

Returns for credit

Customer satisfaction is important to us, therefore any product may be returned with authorization within 30 days from the shipment date for a full credit of the purchase price. If you have ordered the wrong equipment or you are dissatisfied in any way, please contact us to request an RMA number to accept your return. Patton is not responsible for equipment returned without a Return Authorization.

Return for credit policy

- Less than 30 days: No Charge. Your credit will be issued upon receipt and inspection of the equipment.
- 30 to 60 days: We will add a 20% restocking charge (crediting your account with 80% of the purchase price).
- Over 60 days: Products will be accepted for repairs only.

RMA numbers

RMA numbers are required for all product returns. You can obtain an RMA by doing one of the following:

- Completing a request on the RMA Request page in the *Support* section at **www.patton.com**
- By calling **+1 (301) 975-1007** and speaking to a Technical Support Engineer
- By sending an e-mail to **returns@patton.com**

All returned units must have the RMA number clearly visible on the outside of the shipping container. Please use the original packing material that the device came in or pack the unit securely to avoid damage during shipping.

Shipping instructions

The RMA number should be clearly visible on the address label. Our shipping address is as follows:

Patton Electronics Company

RMA#: xxxx

7622 Rickenbacker Dr.

Gaithersburg, MD 20879-4773 USA

Patton will ship the equipment back to you in the same manner you ship it to us. Patton will pay the return shipping costs.

Appendix A **Compliance information**

Chapter contents

Compliance53

 EMC53

 Low Voltage Directive (Safety)53

Radio and TV Interference (FCC Part 15)53

CE Declaration of Conformity53

Authorized European Representative53

Compliance

EMC

- FCC Part 15, Class A
- EN55022, Class A
- EN ETSI 300 386 V1.3.3

Low Voltage Directive (Safety)

- UL 60950-1/CSA C22.2 No. 60950-1
- IEC/EN60950-1

Radio and TV Interference (FCC Part 15)

This device generates and uses radio frequency energy, and if not installed and used properly—that is, in strict accordance with the manufacturer’s instructions—may cause interference to radio and television reception. The device has been tested and found to comply with the limits for a Class A computing device in accordance with specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection from such interference in a commercial installation. However, there is no guarantee that interference will not occur in a particular installation. If the device does cause interference to radio or television reception, which can be determined by disconnecting the unit, the user is encouraged to try to correct the interference by one or more of the following measures: moving the computing equipment away from the receiver, re-orienting the receiving antenna and/or plugging the receiving equipment into a different AC outlet (such that the computing equipment and receiver are on different branches).

CE Declaration of Conformity

Patton Electronics, Inc declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The Declaration of Conformity may be obtained from Patton Electronics, Inc at www.patton.com/certifications.

The safety advice in the documentation accompanying this device shall be obeyed. The conformity to the above directive is indicated by CE mark on the device.

Authorized European Representative

D R M Green

European Compliance Services Limited.

Avalon House, Marcham Road

Abingdon,

Oxon OX14 1UD, UK

Appendix B Specifications

Chapter contents

Capacity and voice processing.....	55
Simultaneous signaling support	55
SmartNode-CONTROL.....	55
OAM&P	56
Operating environment	56
Physical characteristics	56
Electrical characteristics	56

Capacity and voice processing

VoIP channels—512 to 2,016

PSTN interfaces—1 OC3/STM1 with APS (automatic protection switching) • 1 or 2 DS3 • Dual RJ48C for BITS or T1/E1 for signaling

VoIP interfaces—Dual 100/1000Base-T • RJ45 connectors on rear of unit

Vocoding—Universal codecs: G.711, G.723.1, G.726, G.729ab, T.38 • Other codecs: G.722.2 (AMR-WB), G.728, G.729eg, iLBC, clear mode (RFC 4040)

Fax/Modem/Data—T.38 fax relay (V.17 and V.34) • Automatic G.711 fallback • Modem and data pass-through DTMF relay—RFC 2833, SIP INFO Method, In-band

Echo cancellation—G.168 echo cancellation • 128 ms echo tail on all channels simultaneously

Voice processing—Dynamic and programmable jitter buffer (20 to 200 ms) • Voice activity detection (VAD) • Comfort noise generation (CNG)

Management interfaces—Dual 100/1000Base-T for OAM&P

Simultaneous signaling support

SIP—Supported RFCs: 2327, 2976, 3261, 3262, 3263, 3264, 3311*, 3323*, 3325*, 3398, 3515*, 3578*, 3764, 3891, 4028 (*partial compliance)

SIGTRAN—M2PA, M2UA, M3UA, IUA • SS7 termination and/or relay supported

SS7—Up to 64 x MTP2 links (56, 64, n x 56/64 kbps, HSL) • Multiple redundant MTP2 links • Up to 64 MTP3 originating point codes and linksets • ISUP variants: ITU 92, ITU 97, ANSI 88, ANSI 92, ANSI 95, Telcordia 97, ETSIv2, ETSIv3, China, Singapore, UK Brazil

ISDN PRI—Q.931 ISDN PRI: NI-2, 4ESS, 5ESS, DMS-100, DMS-250, Euro ISDN ETSI NET5 (France, Germany, UK, China, Hong Kong, Korea), NTT (Japan), Australia

CAS—MFC R2 (standard ITU, Brazil) • Customizable protocol script files

SmartNode-CONTROL

Standalone call control—Any to any call routing (TDM-VoIP, TDM-TDM, VoIP-VoIP with transcoding) • Call routing based on: trunk group, calling/called numbers, nature of address, ASR, time of day, load-based, cost-based, TO:, FROM: Request URI, redirect numbers, and other parameters • NPA-NXX routing (100k+ table entries, Excel or CVS file upload) • Route retries • Call transfer (REFER, AT&T TR 50075)

H.248 (MEGACO) call control—ITU-T H.248 versions 1 and 2 • UDP, SCTP, IPsec transport • DTMF and fax detection • DTMF, announcements and call progress tone generation • Call quality and inactivity alerts

Session management and billing—SIP peer availability polling • RTP inactivity monitoring • CDR generation (RADIUS and text file)

OAM&P

Operation & Administration—Web-based system status and operations • SNMP v2/v3 GET, TRAPs and alarms • Dynamic configuration changes

Maintenance—Web-based interface for maintenance • Automated system upgrade • System backup, restore and copy

Provisioning—Web-based interface for configuration • Dynamic activation

Troubleshooting—Per-call tracing (history and/or live) • Signalling capture tools • SSH command-line interface

Operating environment

Operating temperature—32–131°F (0–55°C)

Operating humidity—95% (non condensing)

Physical characteristics

Dimensions—2U, 3.5H x 17.4W x 16D in. (88.9H x 442W x 406D mm)

Weight—20 lbs (9.1 kg)

Electrical characteristics

Power input—90 to 260 VAC, 47 to 63 Hz • -40 to -60 VDC • Redundant power supply with dual power inputs • Maximum 138 W power consumption