

**For Quick
Start Installation**

see page 27



Model 3086 **G.SHDSL Integrated Access Device**

User Guide



Important

This is a Class A device and is intended for use in a light industrial environment. It is not intended nor approved for use in an industrial or residential environment.

Sales Office: +1 (301) 975-1000
Technical Support: +1 (301) 975-1007
E-mail: support@patton.com
WWW: www.patton.com

Document Number: **033221U Rev. D**
Part Number: **07M3086**
Revised: **October 17, 2008**

Patton Electronics Company, Inc.

7622 Rickenbacker Drive
Gaithersburg, MD 20879 USA
tel: +1 (301) 975-1000
fax: +1 (301) 869-9293
support: +1 (301) 975-1007
web: www.patton.com
e-mail: support@patton.com

Copyright © 2008, Patton Electronics Company. All rights reserved.

The information in this document is subject to change without notice. Patton Electronics assumes no liability for errors that may appear in this document.

Warranty Information

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

Patton Electronics warrants all Model 3086 components to be free from defects, and will—at our option—repair or replace the product should it fail within one year from the first date of the shipment.

This warranty is limited to defects in workmanship or materials, and does not cover customer damage, abuse or unauthorized modification. If the product fails to perform as warranted, your sole recourse shall be repair or replacement as described above.

Under no condition shall **Patton Electronics** be liable for any damages incurred by the use of this product. These damages include, but are not limited to, the following: lost profits, lost savings and incidental or consequential damages arising from the use of or inability to use this product. **Patton Electronics** specifically disclaims all other warranties, expressed or implied, and the installation or use of this product shall be deemed an acceptance of these terms by the user.

Contents

Contents	3
About this guide	11
Audience.....	11
Structure.....	11
Precautions	12
Safety when working with electricity	13
Factory default parameters	13
Typographical conventions used in this document.....	14
General conventions	14
Mouse conventions	14
1 General Information.....	15
Model 3086 G.SHDSL IAD overview.....	16
General attributes	16
G.SHDSL Characteristics	17
Ethernet	17
TDM Interface	17
Protocol support	17
PPP Support	18
ATM Protocols	18
Protocol Support	18
Management	18
Security	19
Front Panel Status LEDs, Test Mode Switches, and Console Port	19
Console port (outlined in red)	21
Rear panel connectors and switches	21
Power connector	21
AC universal power supply	21
48 VDC power supply	21
Ethernet port (outlined in green)	22
MDI-X	22
Line port (outlined in yellow)	22
2 Product Overview.....	23
Product Overview.....	24
Applications Overview	24
Internet/Extranet Access	25
IP/FR and TDM Access	25
IP/FR and Voice over DSL	25
Metro Intranet Access	26
3 Quick Start Installation.....	27

Hardware installation	28
What you will need	28
Installing the AC power cord	28
Connecting network cables	29
IP address Quick Start modification	30
Web Operation and Configuration	30
PC Configuration	30
Web Browser	30
4 Basic Application Configurations.....	33
Introduction	36
TDM Port.....	37
V.35 and X.21 Ports.....	39
Connecting the 3086 serial port to a DTE	39
Connecting the 3086 serial port to a DCE	39
V.35 interfaces.	39
X.21 interfaces.	39
Configuring the V.35 or X.21 port via DIP switches	40
Switch Bank S2	42
Switches S2-1 through S2-7	42
Switch S2-8	43
Switch Bank S3	43
Switch S3-1: CO/CP selection	43
Switch S3-3: Transmit Clock Mode	44
T1 Interface.....	44
T1 Interface Connection	44
T1 Interface Configuration	45
DIP Switch Configuration	45
Switch Bank S2	45
Switches S2-1 through S2-7	46
Switch S2-8	46
Switch Bank S3	47
Switch S3-1: CO/CP selection	47
Switch S3-3: Transmit Clock Mode	47
Switch S3-6: Annex	48
Switch S3-7	48
Switch S3-8	48
Switch S3 applies to E1 applications, for T1 applications this switch is ignored.	48
Web Interface Configuration	48
E1 Interface.....	49
E1 Interface Connection	49
DIP Switch Configuration	50
Switch Bank S2	50
Switch S2-8	51

Switch Bank S3	51
Switch S3-1: CO/CP selection	51
Switch S3-3: Transmit Clock Mode	52
Switch S3-6: Annex	52
Switch S3-7	52
Switch S3-8	52
Web Interface Configuration	53
Using the 3086 as a simple modem (TDM data over DSL)	54
DIP Switch Configuration	54
CLI configuration	54
3086 A CLI configuration	54
3086 B CLI configuration	55
Web browser configuration	56
Circuit ID	56
Clear Error Counters	56
Intended DSL Data Rate	56
Actual DSL Rate	56
Intended Serial Interface Data Rate	57
DSL Rate: Number of i Bit	57
Terminal Type	57
Interface Type	58
PCM Mode	58
PCM Transmit Polarity	58
PCM Receive Polarity	58
Loopback	58
Annex Type	58
Line Probe	58
TDM Plus Ethernet Traffic.....	58
CLI configuration	59
Selecting the DSL link speed	59
Selecting PCM mode	59
Assigning bandwidth to serial and Ethernet ports	59
Central or Remote terminal (Master/Slave)	59
Interface Type	60
Annex Type	60
Web Browser Configuration	60
Circuit ID	61
Clear Error Counters	61
Intended DSL Data Rate	61
Actual DSL Rate	61
Intended Serial Interface Data Rate	62
DSL Rate: Number of i Bit	62
Terminal Type	62
Interface Type	63

PCM Mode	63
PCM Transmit Polarity	63
PCM Receive Polarity	63
Loopback	63
Annex Type	63
Line Probe	63
Using the 3086 in Routed or Bridged applications	64
Two stand-alone units directly connected	64
Ethernet extension (HDLC – PPPOH) Bridged	64
Network Extension (HDLC—PPPoH Routed)	67
DSLAM Connections with remote CPE units	73
Bridged application configurations to a DSLAM	73
RFC 1483 Bridged Configuration.	73
PPPoH Bridged Configuration	76
PPPoA Bridged (RFC 2364) Configuration	79
Routed application configurations to a DSLAM	81
RFC 1483 Routed	81
PPPoH Routed	88
PPPoA Routed (RFC 2364)	95
IPoA Routed (RFC 1577)	107
5 Specialized Configurations	113
IP Configurations	114
Router	114
DHCP Server and Relay	114
6 Security	119
Introduction	120
Configuring the IAD	120
Configuring the security interfaces	121
Deleting a Firewall Policy	122
Enabling the Firewall	123
Firewall Portfilters	123
Security Triggers	124
Intrusion Detection System (IDS)	126
7 NAT (Network Address Translation)	129
Introduction	130
Enabling NAT	130
Global address pool and reserved map	131
8 Monitoring Status	133
Status LEDs	134
9 Diagnostics	135
Introduction	136
Ping	136

Software Upgrades	136
Configuration	136
Procedure	136
Operating Local Analog Loopback (LAL)—Serial Port Loop.....	137
Operating Remote Digital Loopback (RDL)—DSL Loop	137
T1/E1 Diagnostics.....	138
Network Loop	138
T1/E1 Local Loop	139
QRSS—BIT Error Rate Diagnostics	140
T1/E1 connection Status	141
Alarms	141
Transceiver Status.	141
FDL statistics (T1 only)	141
E1/T1 DS0 Monitor	141
BIT Error Rate (V.52) Diagnostics	142
10 Contacting Patton for assistance	143
Introduction	144
Contact information.....	144
Warranty Service and Returned Merchandise Authorizations (RMAs)	144
Warranty coverage	144
Out-of-warranty service	144
Returns for credit	144
Return for credit policy	145
RMA numbers	145
Shipping instructions	145
A Compliance information	147
Compliance	148
EMC	148
Safety	148
PSTN Regulatory	148
Radio and TV Interference (FCC Part 15)	148
CE Declaration of Conformity	148
Authorized European Representative	149
FCC Part 68 (ACTA) Statement	149
Industry Canada Notice	149
B Specifications	151
General Characteristics	152
G.SHDSL Characteristics.....	152
Ethernet	152
Sync Serial Interface	153
T1/E1 Interface (3086/RIK and RIT models only)	153
64K/G.703 Port (3086/RIF Model)	153
Protocol Support	153

PPP Support.....	154
ATM Protocols.....	154
Management	154
Security	155
Compliance Standard Requirements.....	155
Australia Specific	155
Dimensions	155
Power and Power Supply Specifications.....	155
AC universal power supply	155
48 VDC power supply	155
C Cable Recommendations	157
DSL Cable.....	158
Ethernet Cable	158
Adapter.....	158
D Physical Connectors	159
RJ-45 shielded 10/100 Ethernet port.....	160
RJ-11 non-shielded port	160
RJ-45 non-shielded RS-232 console port (EIA-561)	160
Serial port.....	161
V.35 (M/34 Connector)	161
V.35 (DB-25 Female Connector)	161
X.21 (DB-15 Connector)	162
E1/T1 (RJ-48C Connector)	162
Power input.....	162
E Command Line Interface (CLI) Operation	163
Introduction	164
CLI Terminology	164
Local (VT-100 emulation)	164
Remote (Telnet)	164
Using the Console	165
Administering user accounts	166
Adding new users	166
Setting user passwords	166
Changing user settings	167
Controlling login access	167
Controlling user access	167
G.SHDSL Commands:	167
To establish the DSL link	168
F Interworking Functions Information	171
Introduction	173
Frame Relay Local Management Interface	173
LMI Configuration Options:	173

managementType: (Default Value: no_maintenance)	173
MgtState	174
mgtAutoStart: (Default Value: FALSE)	174
T391_Value: (Default Value: 10)	174
T392_Value: (Default Value: 16)	174
fullReportCycle: (Default Value: 6)	174
netErrorWindowSize: (Default Value: 4)	174
netMaxErrors: (Default Value: 3)	174
userErrorWindowSize: (Default Value: 4)	174
userMaxErrors: (Default Value: 3)	174
CLI Configuration Methods	175
Show current configuration	175
Set configuration variable	175
Web Configuration Methods	176
Frame Relay Service Interworking (FRF.8)	176
FRS Configuration Options	176
DE Mapping	176
FECN Mapping	177
Translation Mode:	177
FRS Name	178
CLI Configuration Method	179
Show one of the eight groups	179
Set variable attributes on a specified group	179
Set variable attributes on a specified channel	180
Web Configuration Methods	180
FRS Overview Screen	180
Group/Channel Level Configuration Screen	181
Frame Relay Network Interworking (FRF.5)	182
FRN Configuration Options	182
Port Level Configuration Options:	183
Channel Level Configuration Options	184
CLI Configuration Methods for Port Level Management	185
List all ports available to the system	185
Show detailed information about a specific port	185
Set configuration variables associated with the specified port	186
Configuration Management of the Channel Level Variables	186
Understanding the Channel Level View	186
Set Configuration Variables associated with the Channels	187
Web Configuration Methods for FRF.5 Port and Channel Level Configuration	187
Port Level Information Screen	188
Channel Level Information Screen	189
Packet Information Screen	189
Frame Relay (Ethernet Based) Operations	190
Frame Relay Configuration Options	190

Channel Segment Size	190
DLCI: Data Link Connection Identifier	190
Encapsulation Type	190
Port	190
Rxmaxpdu	190
Txmaxpdu	190
Frame Relay CLI Configuration Options	190
Build a new Frame Relay Transport	190
Clear all Frame Relay Transports	191
Delete the specified transport	191
List all active Frame Relay Channels	191
Set configuration variables for the specified frame relay transport	191
Show detailed configuration information on the specified channel:	191
Web Based Configuration of the Frame Relay Channel	192
Serial Interface Configuration	192
Configuration Variables Available	192
Clock Mode	192
Clock Invert Functions: (rxClkInv – receive clock, txClkInv – transmit clock)	192
Speed	192
CLI Configuration Methods	193
Set configuration variable	193
Show current configuration settings	193
Gain help about the Serial Interface	193
Web Interface Configurations	194
Ping and Trace Route	194
Ping commands from the CLI Interface	194
Trace Route from the CLI Interface	195
Define Usage: “ip traceroute”	195
Start Trace Route: “ip traceroute start 192.168.50.2”	195
Ping and traceroute from the web interface:	196
Backup and Restore Features	196
Backup Configuration	196
Restore Configuration	196

About this guide

This guide describes installing and configuring a Patton Electronics Model 3086 G.SHDSL Integrated Access Device (IAD). The instructions in this guide are based on the following assumptions:

- The IAD may connect to a serial DTE device
- There is a LAN connected to the Ethernet port of the IAD
- Users will be connected to remote IADs

Audience

This guide is intended for the following users:

- Operators
- Installers
- Maintenance technicians

Structure

This guide contains the following chapters and appendices:

- Chapter 1 provides information about IAD features and capabilities
- Chapter 2 contains an overview describing IAD operation
- Chapter 3 provides quick start installation procedures
- Chapter 4 describes configuring the IAD for typical applications
- Chapter 5 describes configuring the IAD for specialized applications
- Chapter 6 describes configuring security for the IAD
- Chapter 7 describes configuring for network address translation (NAT)
- Chapter 8 contains definitions for the LED status indicators
- Chapter 9 describes IAD diagnostics
- Appendix B contains specifications for the IADs
- Appendix C provides cable recommendations
- Appendix D describes the IAD's ports
- Appendix E describes how to use the command line interface (CLI)

For best results, read the contents of this guide *before* you install the IAD.

Precautions

Notes and cautions, which have the following meanings, are used throughout this guide to help you become aware of potential IAD problems. *Warnings* relate to personal injury issues, and *Cautions* refer to potential property damage.

Note Calls attention to important information.



The shock hazard symbol and **WARNING** heading indicate a potential electric shock hazard. Strictly follow the warning instructions to avoid injury caused by electric shock.



The alert symbol and **WARNING** heading indicate a potential safety hazard. Strictly follow the warning instructions to avoid personal injury.



The shock hazard symbol and **CAUTION** heading indicate a potential electric shock hazard. Strictly follow the instructions to avoid property damage caused by electric shock.



The alert symbol and **CAUTION** heading indicate a potential hazard. Strictly follow the instructions to avoid property damage.

Safety when working with electricity



- This device contains no user serviceable parts. The equipment shall be returned to Patton Electronics for repairs, or repaired by qualified service personnel.
- **Mains Voltage:** Do not open the case when the power cord is attached. Line voltages are present within the power supply when the power cords are connected. The mains outlet that is utilized to power the device shall be within 10 feet (3 meters) of the device, shall be easily accessible, and protected by a circuit breaker.
- For AC powered units, ensure that the power cable used meets all applicable standards for the country in which it is to be installed, and that it is connected to a wall outlet which has earth ground.
- For units with an external power adapter, the adapter shall be a listed Limited Power Source.
- Hazardous network voltages are present in WAN ports regardless of whether power to the unit is ON or OFF. To avoid electric shock, use caution when near WAN ports. When detaching the cables, detach the end away from the device first.
- Do not work on the system or connect or disconnect cables during periods of lightning activity.



In accordance with the requirements of council directive 2002/96/EC on Waste of Electrical and Electronic Equipment (WEEE), ensure that at end-of-life you separate this product from other waste and scrap and deliver to the WEEE collection system in your country for recycling.

Factory default parameters

The **Model 3086** G.SHDSL IAD has the following factory default parameters.

- Ethernet IP address: 192.168.200.10/24
- WAN Connection: PPPoH Bridged
- Autonegotiate the G.SHDSL speed
- Ethernet and serial connections
- Annex B
- Remote (CPE)
- MDI (LAN connector)
- Switch configuration disabled

Typographical conventions used in this document

This section describes the typographical conventions and terms used in this guide.

General conventions

The procedures described in this manual use the following text conventions:

Table 1. General conventions

Convention	Meaning
Futura bold type	Indicates the names of menu bar options.
<i>Italicized Futura type</i>	Indicates the names of options on pull-down menus.
Futura type	Indicates the names of fields or windows.
Garamond bold type	Indicates the names of command buttons that execute an action.
< >	Angle brackets indicate function and keyboard keys, such as <SHIFT>, <CTRL>, <C>, and so on.
Are you ready?	All system messages and prompts appear in the Courier font as the system would display them.
% dir *.*	Bold Courier font indicates where the operator must type a response or command

Mouse conventions

The following conventions are used when describing mouse actions:

Table 2. Mouse conventions

Convention	Meaning
Left mouse button	This button refers to the primary or leftmost mouse button (unless you have changed the default configuration).
Right mouse button	This button refers the secondary or rightmost mouse button (unless you have changed the default configuration).
Point	This word means to move the mouse in such a way that the tip of the pointing arrow on the screen ends up resting at the desired location.
Click	Means to quickly press and release the left or right mouse button (as instructed in the procedure). Make sure you do not move the mouse pointer while clicking a mouse button.
Double-click	Means to press and release the same mouse button two times quickly
Drag	This word means to point the arrow and then hold down the left or right mouse button (as instructed in the procedure) as you move the mouse to a new location. When you have moved the mouse pointer to the desired location, you can release the mouse button.

Chapter 1 **General Information**

Chapter contents

Model 3086 G.SHDSL IAD overview	16
General attributes	16
G.SHDSL Characteristics	17
Ethernet	17
TDM Interface	17
Protocol support	17
PPP Support	18
ATM Protocols	18
Protocol Support	18
Management	18
Security	19
Front Panel Status LEDs, Test Mode Switches, and Console Port	19
Console port (outlined in red)	21
Rear panel connectors and switches	21
Power connector	21
AC universal power supply	21
48 VDC power supply	21
Ethernet port (outlined in green)	22
MDI-X	22
Line port (outlined in yellow)	22

Model 3086 G.SHDSL IAD overview

The Model 3086 is a G.SHDSL Integrated Access Device that combines high-speed IP routing and access via ATM/FR/PPP along with TDM data access. The model 3086 offers direct connection to a 10/100Base-T Ethernet environment, a V.35/X.21 Serial direct connection to a router or multiplexer, or a T1, E1, or 64K/G.703 port for connection to local device (e.g., PBX).

The Model 3086 complies with ETSI/ITU standard G.991.2 and allows full duplex, up to 2.3 Mbps speed over a single twisted pair. In addition, the Model 3086 works at up to 4.6 Mbps over 2-wire. Whereas G.991.2 specifies 4-wire for data rates from 2.3 to 4.6 Mbps, the 3086 is able to operate up to 4.6 Mbps *over jsut 2 wires!* Speed setting ranges are user selectable in nx64 kbps increments from 64 kbps.

The following sections describe Model 3086 features and capabilities:

- General attributes, see page 16
- G.SHDSL Characteristics (Model 3086), see page 17
- Ethernet, see page 17
- Protocol support, see page 17
- PPP support, see page 18
- ATM protocols, see page 18
- Management, see page 18
- TDM Interface, see page 17
- Security, see page 19
- Front panel status LEDs, switches, etc., see page 19

General attributes

- Compact, low cost IAD
- 10/100 Ethernet
- Unlimited host support.
- Comprehensive hardware diagnostics, works with any operating system, easy maintenance and effortless installation.
- Plug-and-Play operation for fast and seamless turn-up with pre-configured WAN and LAN options.
- Built-in web configuration.
- Setup allows for standard IP address and unique method for entering an IP address and mask WITHOUT use of a console connection. Default IP address of 192.168.1.1/24.
- Simple software upgrade using FTP into FLASH memory.
- Twelve front panel LEDs indicate , DSL WAN, Sync Serial, Ethernet LAN speed and status, and Test mode status.
- Convenient and standard RJ connectors for Ethernet, Line, and Console.
- Field Factory Default Option.

- Standard 1 year warranty.
- Convenient and standard RJ connectors for Ethernet, Line, and Console.

G.SHDSL Characteristics

- Full duplex 2.3 Mbps speed over 2-wire (in accordance with ETSI/ITU standard G.991.2). 2.3 Mbps to 4.6 Mbps, full duplex, over 2-wire.
- DTE rates 64 kbps to 2.3 Mbps operation (Sync serial can work in increments of 64 kbps up to a bandwidth of 2.3 Mbps, n=32).
- Distance from 24,900 feet (7,590 m) at 192 kbps to 10,200 ft (3,109 m) at 2.3 Mbps on 26 AWG (0.4 mm) wire
- Annex A (ANSI), Annex B (ETSI) PSD selection.
- CO and CP modes supported
- TC-PAM based DSL modulations.
- EOC Management channel for remote end-to-end management.

Ethernet

- Auto-sensing Full-Duplex 10Base-T/100Base-TX Ethernet.
- Standard RJ-45 connector
- Built-in MDI-X cross-over switch.
- IEEE 8021.d transparent learning bridge up to 1,024 addresses and Spanning Tree.
- 8 IP address/subnets on Ethernet interface.

TDM Interface

- V.35, X.21, or T1/E1 interface
- Available with female M/34, DB-25, DB-15, and RJ-48C connectors
- User configurable DTE/DCE for X.21

Protocol support

- Complete internetworking with IP (RFC 741), TCP (RFC 793), UDP (RFC 768), ICMP (RFC 950), ARP (RFC 826).
- IP Router with RIP (RFC 1058), RIPv2 (RFC 2453) for up to 64 static routes.
- Built-in Ping and Traceroute facilities.
- Integrated DHCP Server (RFC 2131).
- DHCP relay agent (RFC 2132/RFC 1542) with 8 individual address pools.
- DNS Relay with primary and secondary Name Server selection.
- NAT (RFC 3022) with Network Address Port Translation (NAPT), MultiNat with 1:1, Many:1, Many:Many mapping, Port/IP redirection and mapping.

PPP Support

- Point-to-Point Protocol over HDLC
- PPPoA (RFC 2364) Point-to-Point Protocol over ATM.
- PPPoE (RFC 2516) Client for autonomous network connection. Eliminates the requirement of installing client software on a local PC and allows sharing of the connection across a LAN.
- User configurable PPP PAP (RFC 1661) or CHAP (RFC 1994) authentication..

ATM Protocols

- Multiprotocol over ATM AAL5 and Multiprotocol Bridged encapsulation RFC 2684 (Formerly RFC 1483) and RFC 1577 Classical IP over ATM. Default RFC-1483 route mode. Logical Link Control (LLC)/ Subnetwork Access Protocol (SNAP) encapsulation. Default VC mux mode.
- ATM UNI 3.0, 3.1, and 4.0 signaling ATM QoS with UBR, CBR, nrt-VBR, and rt-VBR.
- Peak cell rate shaping on a per-VCC basis up to 32 active VCCs across VPI 0-255, VCI 0-65525. Single default PVC: 8/35 with PCR=5,500 cells.

Protocol Support

- Complete internetworking with IP (RFC 741), TCP (RFC 793), UDP (RFC 768), ICMP (RFC 950), ARP (RFC 826).
- IP Router with RIP (RFC 1058), RIPv2 (RFC 2453),
- Up to 64 static routes with user selectable priority over RIP/OSPF routes.
- Built-in ping facilities.
- Integrated DHCP Server (RFC 2131). Selectable general IP leases and user specific MAC/IP parings. Selectable lease period.
- DHCP relay agent (RFC 2132/RFC 1542) with 8 individual address pools.
- DNS Relay with primary and secondary Name Server selection.
- NAT (RFC 3022) with Network Address Port Translation (NAPT) for cost-effective sharing of a single DSL connection. Integrated Application Level Gateway with support for over 80 applications.
- NAT MultiNat with 1:1 mapping.
- NAT Many:1.
- NAT Many:Many mapping.
- NAT Port/IP redirection and mapping.
- uPNP controlled device for seamless networked device interconnectivity and Windows XP integration.
- IGMPv2 Proxy support (RFC 2236).
- Frame Relay with Annex A/D/LMI, RFC 1490 MpoFR and FRF.12 Fragmentation.

Management

- User selectable ATM, PPP, or Frame Relay WAN datalink connection.
- Web-Based configuration via embedded web server
- CLI menu for configuration, management, and diagnostics.
- Local/Remote CLI (VT-100 or Telnet).

- SNMPv1 (RFC 1157) MIB II (RFC 1213)
- Quick Start Setup runs through common options to simplify circuit turn-up.
- Logging via SYSLOG, and VT-100 console. Console port set at 9600 bps 8/N/1 settings no flow control.
- EOC access for End-To-End management, configuration, and control.

Security

- Packet filtering firewall for controlled access to and from LAN/WAN. Support for 255 rules in 32 filter sets. 16 individual connection profiles.
- DoS Detection/protection. Intrusion detection, Logging of session, blocking and intrusion events and Real-Time alerts. Logging or SMTP on event.
- Password protected system management with a username/password for console and virtual terminal. Separate user selectable passwords for SNMP RO/RW strings.
- Access list determining up to 5 hosts/networks which are allowed to access management system SNMP/HTTP/TELNET.
- Logging or SMTP on events: POST, POST errors, line/DSL, PPP/DHCP, IP.

Front Panel Status LEDs, Test Mode Switches, and Console Port

The IpRocketLink routers have all status LEDs and console port on the front panel of the unit, and all other electrical connections are located on the rear panel.



Figure 1. Model 3086

The status LEDs from left to right are (see table 3 for LED descriptions):

- Power
- WAN Link (DSL)
- Sync Serial (TD, RD, CTS, and DTR) or T1/E1 (Link, LOSS, TD, and RD)
- Ethernet Link, 100M, Tx, and Rx
- Status NS, ER, and TM

Table 3. Status LED descriptions

Power		Green	ON indicates that power is applied. Off indicates that no power is applied.
WAN (DSL)	Link	Green	Solid green: connected Off: disconnected
Sync Serial	TD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
	RD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
	CTS	Green	ON: indicates the CTS signal from the IAD is active, binary '1' off: indicates CTS is binary '0'
	DTR	Green	ON: indicates the DTR signal from the DTE device attached to the serial port is active, binary '1'
T1/E1	Link	Green	On: indicates the T1/E1 interface is connected to a live T1/E1 line
	LOS	Red	On: indicates a T1/E1 loss-of-frame condition. It also indicates that no T1/E1 signal is detected.
	TD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
	RD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
Ethernet	Link	Green	ON: indicates an active 10/100 BaseT connection
	100M	Green	ON: connected to a 100BaseT LAN Off: connected to a 10BaseT LAN
	Tx	Green	Flashing: when transmitting data from the IAD to the Ethernet
	Rx	Green	Flashing: when transmitting data from the Ethernet to the IAD.
Status	NS	Red	ON: indicates absence of a valid DSL connection
	ER	Red	flashes once: indicates bit errors occurring during 511/511E tests
	TM	Yellow	ON: is under one of the test modes (local loop, remote loop, or V.54 BER pattern)

The test mode switches are:

- Normal, Local, and Remote Loopbacks
- Normal, 511, and 511E pseudo-random bit patterns

Console port (outlined in red)

The unshielded RJ-45 RS-232 console DCE port (EIA-561) with the pin-out listed in the following table:

Pin No.	Signal Direction	Signal Name
1	Out	DSR
2	Out	CD
3	In	DTR
4	—	Signal Ground
5	Out	RD
6	In	TD
7	Out	CTS
8	In	RTS

Rear panel connectors and switches

On the rear panel from left to right are the following:

- Power input connector
- Ethernet connector
- MDI-X switch
- TDM port. V.35 (3086/C), X.21 (3086/D), T1/E1 (3086/K)
- Line connector

*Power connector***AC universal power supply.**

The Model 3086 offers internal or external AC power supply options.

- The internal power supply connects to an AC source via an IEC-320 connector (100–240 VAC, 200 mA, 50/60 Hz)
- The external power supply connects to an external source providing +5 VDC via a barrel-type connector

48 VDC power supply.

- Rated voltage and current: 36–60 VDC, 400 mA
- Fuse rating: 250 Volts, 400 mA, time delay



Connect the equipment to a 36–60 VDC source that is electrically isolated from the AC source. The 36–60 VDC source is to be reliably connected to earth.

Ethernet port (outlined in green)

Shielded RJ-45 10Base-T/100Base-TX Ethernet port using pins 1,2,3, & 6. See MDI-X switch for hub or transceiver configuration. The following table defines conditions that occur when the MDI-X switch is in the out position.

Pin No.	Signal Direction	Signal Name
1	Output	TX+
2	Output	TX-
3	Input	RX+
4	—	—
5	—	—
6	Input	RX-
7	—	—
8	—	—

MDI-X

The MDI-X push switch operates as follows:

- When in the default “out” position, the Ethernet circuitry takes on a straight-through MDI configuration and functions as a transceiver. It will connect directly to a hub.
- When in the “in” position, the Ethernet circuitry is configured in cross-over MDI-X mode so that a straight-through cable can connect the Model 3086 DSL modem’s Ethernet port directly to a PC’s NIC card.

Line port (outlined in yellow)

The RJ-11/4 DSL line port uses pins 2 and 3 of the RJ-11 port.

Pin No.	Signal Name
1	—
2	In/Out-A
3	In/Out-B
4	—

Chapter 2 **Product Overview**

Chapter contents

Product Overview.....24

Applications Overview24

 Internet/Extranet Access25

 IP/FR and TDM Access25

 IP/FR and Voice over DSL25

 Metro Intranet Access26

Product Overview

The Model 3086 IAD operates as a bridge or a router and has three ports for communication:

- The Ethernet port—Connects to the LAN side of the connection
- The Line port—Provides the G.SHDSL transmission connection between the CPE and CO DSL IAD
- The TDM port—Connects to local devices for data uplink over the main DSL link

The IAD provides all layer 2 and layer 3 protocols required for end-to-end-link communication.

When configuring the 3086, questions must be answered so the 3086 functions as desired. For example, when a router or bridge module needs to be activated, some questions would be:

- Is a default gateway required?
- Which encapsulation technique is best for this application: PPPoA, Frame Relay, PPPoE or another?

These decisions can be made and implemented more easily if the Model 3086's fundamental architecture is understood. Also, while configuring the Model 3086 via a browser using the built-in HTTP server is very intuitive, an understanding of the architecture is essential when using the command-line interface (CLI) commands.

The fundamental building blocks comprise a router or bridge, interfaces, and transports. The router and bridge each have interfaces. A transport provides the path between an interface and an external connection. For example, the Ethernet transport attaches to an Internet Protocol (IP) interface. A transport consists of layer 2 and everything below it. Creating a transport and attaching it to a bridge or router's interface enables data to be bridged or routed. The supported transports are *PPPoA*, *PPPoE*, *Frame Relay*, *RFC 1483* (Multiprotocol Encapsulation over ATM AAL5), *IPoA*, *PPPoH*, and *Ethernet*.

Configuring an interface and transport for the router or bridge requires naming the interface and transport before attaching them. When using the built-in HTTP server web browser, this is done automatically. But when configuring the Model 3086 via CLI commands through the RS-232 control port, it must be done manually.

Model 3086 IADs can connect over an ATM PVC or HDLC transport.

The PVC requires the configuration of the virtual path identifier (VPI) and virtual circuit identifier (VCI). The VPI can be any integer between 0–4095 inclusive. The general rule for the VCI is an integer between 1–65,535 inclusive. Examples in this manual use a VCI of 600 or above. The main restriction in choosing a VCI is that VCIs below 32 are reserved for such predefined functions as ILMI. The VCI values of 600 and above used in this manual are also above the range used by many signaling implementations for SVCs.

The HDLC is a packet-based transmission across the DSL Link.


Several ATM connections are offered to address a variety of user applications. Although they all use RFC1483 as the transport mechanism between the two 3086 IADs, WAN services may use different PPP applications, such as *PPPoE routed*, *PPPoA routed*, or *PPPoA bridged*. Each one has its advantages and disadvantages.

Applications Overview

The Model 3086 IAD is geared to the connection of small to medium size enterprises in Internet (connection to ISP), or connection of remote branches using DSL access and IP/FR/ATM/PPP. In most applications, the Model 3086 works with Patton's 3096RC ForeFront System, but it will also connect to third-party G.SHDSL devices.

Internet/Extranet Access

While Frame Relay (FR) remains the most economical service to connect multiple corporate locations over PVCs (Private Virtual Connections) at burst and fixed data rates, high speed DSL is becoming the technology of choice for last mile access to FR switches. The Model 3086 connects to a 10/100Base-T hub or switch at the customer's LAN, while at the network side it connects to Patton's 3096RC via a 2-wire DSL Link. Data from the 3086 links is concentrated by the 3096RC and sent over the WAN via DS1, DS3, or STS links.



At the Data Link Layer, The Model 3086 encapsulates IP data from the customer LAN into FR packets and transmits over the DSL link to a Service Provider location. Inside the provider's network, VCs transport data across the WAN to their final destination. Additionally, the Model 3086 supports PPP encapsulation, FR to ATM network interworking, or FR to ATM Service interworking.

IP/FR and TDM Access


The Model 3086 goes a step further, along with providing IP/FR/ATM/PPP connectivity for a 10/100 Ethernet LAN, it also comes with a local serial port for connection to a router or multiplexer. Using Patton's FlexIP™ technology, serial (TDM) data from a router, and IP data from the 3086's Ethernet port is transported in splits DSL bandwidth mode. The serial port provides logical and physical segmentation and access in a multiple office campus environment



IP/FR and Voice over DSL

The Model 3086 can also connect to a PBX. Along with providing IP/FR/ATM/PPP connectivity for a 10/100 Ethernet LAN, the 3086/RIK's drop-and-insert port connects to a local PBX to provide voice and data solution in one simple to use box. Using Patton's FlexIP™ technology, IP data from an Ethernet environment, and

PCM encoded voice from a PBX are carried in split-DSL- bandwidth mode to a Central Office. At a Service Provider location the Model 3096RC separates PCM voice and IP data traffic for transport over the WAN



Metro Intranet Access

Patton's Model 3086 symmetrical G.SHDSL modulation scheme, allows deployment in back-to-back configurations for Metro Intranet Access with the following benefits.

- Low cost creation of VPN and Intranet Access
- Can be connected locally or via TDM networks
- Secure networking and more efficient Traffic Engineering



Chapter 3 **Quick Start Installation**

Chapter contents

Hardware installation	28
What you will need	28
Installing the AC power cord	28
Connecting network cables	29
IP address Quick Start modification	30
Web Operation and Configuration	30
PC Configuration	30
Web Browser	30

Hardware installation

If you are already familiar with Model 3086 IAD installation and configuration, this chapter will enable you to finish the job quickly. Installation consists of the following:

- Preparing for the installation (see section “What you will need”)
- Hooking up cables, verifying that the unit will power up, and running a HyperTerminal session (see section “Connecting network cables” on page 29)
- Changing the IP address from the factory default setting (see section “IP address Quick Start modification” on page 30)
- Launching a web browser in preparation for configuring the modem (see “Web Operation and Configuration” on page 30)

What you will need

- Model 3086 G.SHDSL IAD
- Ethernet cable with RJ45 plugs on each end (included with IAD)
- DB9-RJ45 Adapter (included with IAD)
- RJ45/RJ45 straight-through cable for connecting to control port (included with IAD)
- PC computer with HyperTerminal or equivalent VT-100 emulation program, or an ASCII (“dumb”) terminal.

Installing the AC power cord

This section describes installing the power cord into the IEC-320 connector on the 3086. *Do not connect the male end of the power cord to the power outlet at this time.* Do the following:

1. Install the power cable into *Power* connector (see figure 2). The AC main socket outlet shall be within 10 feet (3 meters) of the equipment and shall be easily accessible.




Figure 2. Power connector location on rear panel



To avoid the risk of injury from electric shock, the power cord connected to the IEC-320 connectors must be a grounded power cord.



The 3086 power supply automatically adjusts to accept an input voltage from 100 to 240 VAC (50/60 Hz).

Verify that the proper voltage is present before plugging the power cord into the receptacle. Failure to do so could result in equipment damage.

2. Verify that the AC power cord included with your 3086 is compatible with local standards. If it is not, refer to Chapter 10, “Contacting Patton for assistance” on page 27 to find out how to replace it with a compatible power cord.
3. Connect the male end of the power cord to an appropriate power outlet.
4. Verify that the green *POWER* LED is lit.
5. Unplug the AC power cord from the Model 3086 to power down the unit.

Connecting network cables

Except for the Console port, all connectors are on the rear panel of the ipRocketLink with the exception of the power connection. The Ethernet port is Green and the Line is Yellow. The Console port is the only electrical connection on the front panel.

Do the following:

1. Connect the DB9-RJ45 adapter to the DB-9 serial port on the PC or dumb terminal. Use the RJ45-RJ45 straight-through cable between the adapter and the red marked RJ45 port on the 3086 IAD.
2. Do NOT connect the IAD to the Ethernet LAN now.
3. On the PC, start a HyperTerminal session at 9600 bps, 8 data bits, 1 stop bit, and no parity.
4. Plug the AC power cord into the Model 3086 to power up the IAD.
5. Type *superuser* for Login:, and press Enter.
6. Then type *superuser* for the password, press Enter.
7. A message will display, “Login Successful.” By typing the character “?”, all the commands will be displayed. Any commands parameters may be seen by entering the command followed by a space and a question mark.

```
→ ethernet ? [The following parameters appear]
    add
    delete
    set
    show
    list
    clear
```

IP address Quick Start modification

The first parameter to change is the IP address from the default IP address of 192.168.1.1/24 (for the CP units) or 192.168.200.11 (for CO units) to your selected IP address. Follow these steps. Comments are in brackets [...].

→ ip list interfaces <enter> [lists the characteristics of the different interfaces]

```
IP Interfaces:
  ID | Name | IP Address | DHCP | Transport
-----|-----|-----|-----|-----
  1  | ip1  | 192.168.200.10 | disabled | <bridge>
```

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0 <enter> [Sets the new IP address which you have selected.

The IP address in this example is for illustrative purposes only.]

→ ip list interfaces <enter> [To see if the change in IP address is correct]

→ system config save <enter> [To save the new IP address in flash memory.]

Wait for "configuration saved" message...

Saving configuration

→

Configuration saved.
<enter>

→

The IP address has now been successfully changed.

Web Operation and Configuration

Now that the IP address has been configured for your application, you can complete the configuration using any standard web browser.

PC Configuration

In order to connect the PC to the Ethernet LAN to communicate with the Model 3086, the PC's IP address should be on the same subnet as the modem.

Connect a straight-through Ethernet cable between the PC's NIC or PCMCIA Ethernet card and an Ethernet hub or switch.

Web Browser

Do the following:

1. Launch a standard web browser such as Netscape Communicator or Internet Explorer (IE).
2. Enter the 3086's IP address into the URL or Address field of the browser.

The Model 3086 home page displays (see Figure 3).




Figure 3. Model 3086 home page

The Model 3086 menu structure is shown in figure 4 on page 32.




Figure 4. Model 3086 Menu Structure

Chapter 4 **Basic Application Configurations**

Chapter contents

Introduction	36
TDM Port	37
V.35 and X.21 Ports	39
Connecting the 3086 serial port to a DTE	39
Connecting the 3086 serial port to a DCE	39
V.35 interfaces.	39
X.21 interfaces.	39
Configuring the V.35 or X.21 port via DIP switches	40
Switch Bank S2	42
Switches S2-1 through S2-7	42
Switch S2-8	43
Switch Bank S3	43
Switch S3-1: CO/CP selection	43
Switch S3-3: Transmit Clock Mode	44
T1 Interface.....	44
T1 Interface Connection	44
T1 Interface Configuration	45
DIP Switch Configuration	45
Switch Bank S2	45
Switches S2-1 through S2-7	46
Switch S2-8	46
Switch Bank S3	47
Switch S3-1: CO/CP selection	47
Switch S3-3: Transmit Clock Mode	47
Switch S3-6: Annex	48
Switch S3-7	48
Switch S3-8	48
Switch S3 applies to E1 applications, for T1 applications this switch is ignored.	48
Web Interface Configuration	48
E1 Interface.....	49
E1 Interface Connection	49
DIP Switch Configuration	50
Switch Bank S2	50
Switch S2-8	51
Switch Bank S3	51
Switch S3-1: CO/CP selection	51
Switch S3-3: Transmit Clock Mode	52
Switch S3-6: Annex	52
Switch S3-7	52

Switch S3-8	52
Web Interface Configuration	53
Using the 3086 as a simple modem (TDM data over DSL)	54
DIP Switch Configuration	54
CLI configuration	54
3086 A CLI configuration	54
3086 B CLI configuration	55
Web browser configuration	56
Circuit ID	56
Clear Error Counters	56
Intended DSL Data Rate	56
Actual DSL Rate	56
Intended Serial Interface Data Rate	57
DSL Rate: Number of i Bit	57
Terminal Type	57
Interface Type	58
PCM Mode	58
PCM Transmit Polarity	58
PCM Receive Polarity	58
Loopback	58
Annex Type	58
Line Probe	58
TDM Plus Ethernet Traffic	58
CLI configuration	59
Selecting the DSL link speed	59
Selecting PCM mode	59
Assigning bandwidth to serial and Ethernet ports	59
Central or Remote terminal (Master/Slave)	59
Interface Type	60
Annex Type	60
Web Browser Configuration	60
Circuit ID	61
Clear Error Counters	61
Intended DSL Data Rate	61
Actual DSL Rate	61
Intended Serial Interface Data Rate	62
DSL Rate: Number of i Bit	62
Terminal Type	62
Interface Type	63
PCM Mode	63
PCM Transmit Polarity	63
PCM Receive Polarity	63
Loopback	63
Annex Type	63

Line Probe	63
Using the 3086 in Routed or Bridged applications	64
Two stand-alone units directly connected	64
Ethernet extension (HDLC – PPPOH) Bridged	64
Network Extension (HDLC—PPPoH Routed)	67
DSLAM Connections with remote CPE units	73
Bridged application configurations to a DSLAM	73
RFC 1483 Bridged Configuration.	73
PPPoH Bridged Configuration	76
PPPoA Bridged (RFC 2364) Configuration	79
Routed application configurations to a DSLAM	81
RFC 1483 Routed	81
PPPoH Routed	88
PPPoA Routed (RFC 2364)	95
IPoA Routed (RFC 1577)	107

Introduction

The Model 3086 IAD comes with two data ports: a TDM (V.35, X.21, or T1/E1), and an Ethernet port. TDM port data is not processed by the router or bridge core in the 3086, data is transmitted unprocessed over the DSL link. Data from the Ethernet port is processed by the 3086 bridge or router core and sent in HDLC or ATM encapsulation over the DSL link.

The 3086 can be used as a simple modem – transporting TDM data from a router, multiplexer, or PBX connected to the V.35, X.21 or T1/E1 port. In this case the user configures DSL and TDM port features only.

The 3086 can concurrently transport TDM and Ethernet traffic, the TDM and Ethernet ports are activated, and the user must assign DSL bandwidth for both TDM and Ethernet traffic. Since Ethernet layer is activated, the user must configure the routing or bridging features and must choose from HDLC or ATM encapsulation.

The 3086 can be used to transport Ethernet traffic only, via its 10/100 Base-T LAN across a campus or across a WAN, in this case, the TDM port is not activated. In addition to configuring the DSL link, the user must configure the routing or bridging features and must choose from HDLC or ATM encapsulation.

Configuration for these applications is presented in the following sections. The 3086 is used to transport TDM data only, TDM plus Ethernet, or Ethernet only data. Since the configuration of the router or bridge and the ATM or HDLC Features are considerably more complex than the DSL and data port layers, we present physical layer configuration of TDM port and TDM port plus Ethernet first as the foundation from which the upper layers can be configured. An extensive section is devoted to the Bridge/Router, and HDLC/ATM application configuration.

What follows is a brief description and a table summarizing the parameters for bridged and routed WAN services achieved with the Model 3086.

The basic applications are divided according to whether the application is bridged or routed.

The bridged applications are *RFC 1483 Bridged*, *PPPoA Bridged*, and *HDLC Bridged*.

The routed applications are *RFC 1483*, *PPPoA*, *IPoA*, *PPPoE*, and *HDLC*.

Another way of organizing the applications is according to the type of encapsulation: *PPP*, *RFC 1483*, or *Frame Relay*. PPP encapsulation is available as *PPPoA bridged* or *routed* and *PPPoE*. RFC 1483 and Frame Relay can be configured for bridged and routed connections.

The following table shows the parameters that can be configured via the HTTP server using a web browser.

Web Page Parameter	Routed WAN Services					Bridged WAN Services			
	RFC 1483	PPPoA	IPoA	PPPoE	HDLC	RFC 1483	PPPoA	HDLC	
Description	X	X	X	X	X	X	X	X	
VPI	X	X	X	X		X	X		default = 0
VCI	X	X	X	X		X	X		default = 35
Encapsulation	X					X			Llc or VcMux
Use DHCP	X		X		X				
WAN IP address	X		X		X				default mask = 255.255.255.0
LLC header		X		X			X		
HDLC header		X		X	X		X	X	
No authentication		X		X			X		
PAP		X		X			X		
CHAP		X		X			X		
User Name		X		X			X		
Password		X		X			X		
WAN IP address (Local IP)		X (0.0.0.0)							Local IP Mask = 255.255.255.0
Access Concentrator				X					
Service Name				X					
DLCI					X			X	default = 1
FR HDLC Encapsulation					X			X	Routed: IP or raw
Bridged: BridgedEther, BridgedEtherCRC, or Raw.									

TDM Port

Model 3086 units enable V.35, X.21, or T1/E1 interface connection to local routers, multiplexers, or PBX devices. The V.35 interface is presented either on a M/34, or DB-25 female connectors. The X.21 interface is pre-

sented on a female DB-15 connector, while the T1/E1 interface is presented on an RJ-48C jack, additionally the E1 interface is presented on dual BNC. Figure 5 shows the different connectors offered for the serial port.




Figure 5. Rear panel power and interface connectors

V.35 and X.21 Ports

The serial port in the 3086 is simple to install. The V.35 interface is wired as a DCE, the X.21 interface can be configured as a DCE (factory default), or as a DTE via internal configuration jumper. The following sections describe the 3086 X.21 and V.35 port connection to DTE and DCE devices.

Connecting the 3086 serial port to a DTE

The serial port on the Model 3086 is configured as a DCE so it connects directly to a DTE using a standard straight through cable. The cable should present either a male M/34 or DB-25 connector on one end, for V.35 interfaces, or a male DB-15 for X.21 interface connection. The other end should be terminated with the appropriate connector (check your DTE equipment manual for pinout, gender, and DTE/DCE port configuration).

Connecting the 3086 serial port to a DCE

V.35 interfaces.

The V.35 interface in the 3086 is wired as a DCE, no DTE configuration is possible. If the equipment that the 3086 is connecting to locally does not have the option for DTE configuration, a tail-circuit cable will be required (this cable is available from most datacomm supply vendors). The tail-circuit cable will cross most interface signals, so that the DCE interface of the 3086 and the DCE interface of the third party equipment can function properly. Please be aware that some third party equipment will not be able to work properly in DCE to DCE configurations even when using a tail circuit cable (please refer to your third party equipment user manual for information on DCE-to DCE operation). The 3086 requires a cable with a male M/34 or male DB-25 connector.

X.21 interfaces.

The Model 3086's X.21 interface configuration can be modified, by the user, as DCE (factory default) or DTE, via an internal jumper board. When the local third party equipment is configured as DCE, the Model 3086 X.21 serial port can be configured as DTE, and a regular straight through cable can then be used. Do the following to configure the X.21 port as a DTE:

1. Open the 3086's case by inserting a screwdriver into the slots and twist the screwdriver head slightly. The top half of the case will separate from the lower half of the case (see Figure 6). Take caution not to damage any of the PC board mounted components.




Figure 6. Case being opened with screwdriver

2. Locate the small daughter board on the 3086 board between the DSL port (RJ-45) connector and the serial port connector (Figure 7 shows location of DTE/DCE daughter board).




Figure 7. Location of DCE/DTE board

3. The DTE/DCE daughter board is installed at the factory with the DCE label and arrows pointing towards the X.21 connector (DCE configuration). To change to DTE configuration, lift the daughter board from the connector, turn it around so that the DTE label and arrows point to the X.21 connector, and place it back on the connector. The X.21 port is now configured as a DTE.

Note When the X.21 port is configured as a DTE, the clocking mode for the port must be set for external clock.

Configuring the V.35 or X.21 port via DIP switches

The 3086 TDM port can be configured via terminal interface, web interface, or DIP switches. This section describes configuring the TDM port via DIP switches only. Please note that DIP switches modify serial port features only.

Switch configuration: Switch configuration in the 3086 is to be used in situations where the 3086 functions as a DSL modem carrying TDM (X.21, V.35) data only, without resorting to the use of a PC for configuration.

When configuring the Model 3086 via DIP switches, the following conditions apply:

- Speed selected applies to the Sync Serial port, not to the Ethernet port
- PCM Mode will be set to Serial only
- DSL interface will be set to HDLC
- To enable DIP switch operation, begin by setting up the DSL rate (units are shipped with switches in the On position —corresponding to CLI/Web management).
- Implementation of DIP switch settings can be done in two ways:
 - Set up DIP switches and then cycle power On/Off/On.
 - Set up DIP switches and then turn the implementation switch (S2-8) to the Off position, wait 3 to 4 seconds, turn S2-8 back to On (you do not need to cycle the power for the unit).
- To put the unit back to CLI/Web management, ALL DIP switches must be set to the On position.

The Model 3086 includes two eight-DIP switch banks labeled S2 and S3. They are externally accessible by removing the plate on the bottom side of the unit. Figure 8 shows the location of the DIP switches on the bottom of the printed circuit board.




Figure 8. DIP switches location

DIP switches S2 and S3 can be configured as either “On” or “Off”. Figure 9 shows the orientation of the DIP switches with respect to the ON/OFF positions.




Figure 9. Close-up of DIP switches showing ON/OFF positions

Switch Bank S2

Table 4 shows the default configuration for switch S2. A description of S2 options follows the table.

Table 4. S2 Summary Table

Switch Position	Function	Factory Default	Selected Option
S2-1	Serial Rate	On	Not a valid rate
S2-2		On	
S2-3		On	
S2-4		On	
S2-5		On	
S2-6		On	
S2-7		On	
S2-8	Switch configuration	On	Toggle On->Off>On To activate DIP configuration

Switches S2-1 through S2-7. Use Switches S2-1 through S2-7 to set the data rate. Each position represents nx64 settings.

S7	S6	S5	S4	S3	S2	S1	Data Rate (kbps)
On	On	On	On	On	On	Off	64
On	On	On	On	On	Off	On	128
On	On	On	On	On	Off	Off	192
On	On	On	On	Off	On	On	256
On	On	On	On	Off	On	Off	320
On	On	On	On	Off	Off	On	384
On	On	On	On	Off	Off	Off	448
On	On	On	Off	On	On	On	512
On	On	On	Off	On	On	Off	576
On	On	On	Off	On	Off	On	640
On	On	On	Off	On	Off	Off	704
On	On	On	Off	Off	On	On	768
On	On	On	Off	Off	On	Off	832
On	On	On	Off	Off	Off	On	896
On	On	On	Off	Off	Off	Off	960
On	On	Off	On	On	On	On	1024
On	On	Off	On	On	On	Off	1088
On	On	Off	On	On	Off	On	1152
On	On	Off	On	On	Off	Off	1216
On	On	Off	On	Off	On	On	1280
On	On	Off	On	Off	On	Off	1344
On	On	Off	On	Off	Off	On	1408

S7	S6	S5	S4	S3	S2	S1	Data Rate (kbps)
On	On	Off	On	Off	Off	Off	1472
On	On	Off	Off	On	On	On	1536
On	On	Off	Off	On	On	Off	1600
On	On	Off	Off	On	Off	On	1664
On	On	Off	Off	On	Off	Off	1728
On	On	Off	Off	Off	On	On	1792
On	On	Off	Off	Off	On	Off	1856
On	On	Off	Off	Off	Off	On	1920
On	On	Off	Off	Off	Off	Off	1984
On	Off	On	On	On	On	On	2048
On	Off	On	On	On	On	Off	2112
On	Off	On	On	On	Off	On	2176
On	Off	On	On	On	Off	Off	2240
On	Off	On	On	Off	On	On	2304

Switch S2-8. S2-8 activates configuration of Model 3086 via DIP switches. Any time the user desires to modify the 3086 configuration available through DIP switches, make the changes to the corresponding switches and then set S2-8, from On to Off position, wait 3-4 seconds and set back to the On position. Changes made to configuration via DIP switches will not take effect if S2-8 isn't toggled.

S2-8	Condition
ON->Off->ON	Implements switch configuration (toggled ON/OFF)

Switch Bank S3

The table below shows the default configuration for switch S3. A description of S3 options follows this table.

Table 5. S3 Summary Table

Switch Position	Function	Factory Default	Selected Option
S3-1	CO/CP Selection	On	CO
S3-2	Reserved	On	Reserved
S3-3	Clock	On	External
S3-4	Reserved	On	Reserved
S3-5	Reserved	On	Reserved
S3-6	Annex	Off = Annex A On = Annex B	Annex B
S3-7	Reserved	On	Reserved
S3-8	Reserved	On	Reserved

Switch S3-1: CO/CP selection. CO and CP stand for Central Office and Customer Premise respectively. When deploying the model 3086s, units installed at the Customer location should be set to CP and units

installed at a Central Office should be set to CO. For point-to-point operation, one unit must be *CO* while the other must be *CP*.

S3-3	Setting
Off	CP
ON	CO

Switch S3-3: Transmit Clock Mode. Use Switches S3-3 to configure the Model 3086 for internal or external clock mode (keep in mind that this setting only affects the operation of the serial port).

S3-3	Clock mode
Off	Internal. Transmit Clock to DTE is generated internally by the Model 3086
On	External. Transmist Clock to DTE is generated from external clock signal received from DTE. (This option is only available when the Model 3086 is set to CO mode.

T1 Interface

The 3086 enables T1 or E1 device located at customer locations to access a carrier's network over two wire, long reach DSL links. This capability allows providers to offer T1/E1 services at customer locations that were previously outside the reach of standard T1/E1 lines.

The 3086/K offers a user configurable T1 or E1 interface. Selection of the interface is done via DIP switches, HTTP/SNMP, or command line interface (CLI).

The T1 interface is an eight position keyed modular jack configured as a RJ-48C for connection to 100-ohm twisted pair lines.




Figure 10. 3086 T1 port pinout

T1 Interface Connection

The 3086 will usually connect either to a local T1 device, or to a Telco terminated T1 line jack.

- To connect the 3086's T1 port to a local T1 device (PBX, router, mux) use a T1 'crossover' twisted pair cable. A crossover cable connects the transmit pins of the Model 3086's T1 port to the receive pins of the device attached to this port and vice versa. Check the third party T1 equipment documentation for pinout information and cable requirements.
- To connect the 3086's T1 port to a Telco terminated T1 line jack, use a straight through twisted pair patch cable. Consult with your T1 service provider for exact pinout information and cable requirements.

T1 Interface Configuration

The 3086 T1 interface can be configured via DIP switches, HTTP/SNMP, or command line interface (CLI). This section discusses DIP switches and HTTP (web server) configuration. For CLI, see Appendix D, “Command Line Interface (CLI) Operation” on page 163.

DIP Switch Configuration

Switch configuration in the 3086 is to be used in situations where the 3086 functions as a DSL modem carrying TDM (T1) data only without resorting to the use of a PC for configuration.

Note The Model 3086 is shipped with all DIP switches set to the ON position. While in this setting, the Model 3086 can be configured only via software (console, Telnet, HTTP, SNMP). If you want to use the DIP switches to configure the Model 3086, see section “Switch S2-8” on page 43 to activate the DIP switch configuration option.

The Model 3086 includes two eight-DIP switch banks labeled S2 and S3. They are externally accessible by removing the plate on the bottom side of the unit.

Switch Bank S2

Table 6 shows the default configuration for switch S2. A description of S2 options follows the table.

Table 6. S2 Summary Table

Switch Position	Function	Factory Default	Selected Option
S2-1	Data Rate	On	Not a valid rate
S2-2		On	
S2-3		On	
S2-4		On	
S2-5		On	
S2-6		On	
S2-7		On	
S2-8	Switch configuration	On	Toggle On->Off>On To activate DIP configuration

Switches S2-1 through S2-7. Use Switches S2-1 through S2-7 to set the data rate (see Table 5 on page 43). Each position represents nx64 settings.

S7	S6	S5	S4	S3	S2	S1	Data Rate (kbps)
On	On	On	On	On	On	Off	64
On	On	On	On	On	Off	On	128
On	On	On	On	On	Off	Off	192
On	On	On	On	Off	On	On	256
On	On	On	On	Off	On	Off	320
On	On	On	On	Off	Off	On	384
On	On	On	On	Off	Off	Off	448
On	On	On	Off	On	On	On	512
On	On	On	Off	On	On	Off	576
On	On	On	Off	On	Off	On	640
On	On	On	Off	On	Off	Off	704
On	On	On	Off	Off	On	On	768
On	On	On	Off	Off	On	Off	832
On	On	On	Off	Off	Off	On	896
On	On	On	Off	Off	Off	Off	960
On	On	Off	On	On	On	On	1024
On	On	Off	On	On	On	Off	1088
On	On	Off	On	On	Off	On	1152
On	On	Off	On	On	Off	Off	1216
On	On	Off	On	Off	On	On	1280
On	On	Off	On	Off	On	Off	1344
On	On	Off	On	Off	Off	On	1408
On	On	Off	On	Off	Off	Off	1472
On	On	Off	Off	On	On	On	1536

Switch S2-8. S2-8 activates configuration of Model 3086 via DIP switches. Any time the user desires to modify the 3086 configuration available through DIP switches, make the changes to the corresponding switches and then set S2-8, from On to Off position, wait 3-4 seconds and set back to the On position. Changes made to configuration via DIP switches will not take effect if S2-8 isn't toggled.

S2-8	Condition
ON->Off->ON	Implements switch configuration (toggled ON/OFF)

Switch Bank S3

The table below shows the default configuration for switch S3. A description of S3 options follows this table.

Table 7. S3 Summary Table

Switch Position	Function	Factory Default	Selected Option
S3-1	CO/CP Selection	On	CO
S3-2	Reserved	On	Reserved
S3-3	Clock	On	Network
S3-4	Reserved	On	Reserved
S3-5	Reserved	On	Reserved
S3-6	Annex	Off = Annex A On = Annex B	Annex B
S3-7	Reserved	On	Reserved
S3-8	Reserved	On	Reserved

Switch S3-1: CO/CP selection. CO and CP stand for Central Office and Customer Premise respectively. When deploying the model 3086s, units installed at the Customer location should be set to CP and units installed at a Central Office should be set to CO. For point-to-point operation, one unit must be *CO* while the other must be *CP*.

S3-3	Setting
Off	CP
ON	CO

Switch S3-3: Transmit Clock Mode. Use Switches S3-3 to configure the 3086 for internal or external (network) clock mode.

S3-3	Clock mode
Off	Internal. DSL and T1 transmit clock generated by the 3086
On	External. DSL and T1 transmit clock derived from the received T1 signal (CO configuration only)

Switch S3-6: Annex. Annex A and B offer spectral compatibility with T1 and E1 signals respectively, this feature reduces the interference between DSL lines and adjacent E1 or T1 lines. For regions where T1 is used, select Annex A.

S3-6	Annex
Off	Annex A
On	Annex B

Switch S3-7. Use S3-7 to configure the TDM interface for T1 or E1 service. Note that selecting E1 automatically sets the E1 line rate to HDB3, line impedance to 120-Ohms. Selecting T1 automatically sets the framing to Extended Super Frame and B8ZS line code.

S3-7	Configuration
Off	E1 mode (HDB3)
On	T1 mode (ESF/B8ZS)

Switch S3-8. Switch S3 applies to E1 applications, for T1 applications this switch is ignored.

Web Interface Configuration

The T1 interface page is accessed from the Main Menu > E1/T1. This page allows configuration of T1 parameters as follows:

Time Slot Select. For a T1 using all 24 time slots, enter 1-24, for fractional T1 enter in any format for example: 1,2,3,5; or 1-5,10-24. Any entry for timeslots above 24 will return an invalid selection message.

Line Options: Fractional T1

Line Code: The 3086 T1 interface uses B8ZS

Patton Home Page

CONFIGURATION MENU

- [Home](#)
- [Status](#)
- [Quick Start](#)
- ▶ [System](#)
- ▶ [Configuration](#)
- ▼ [E1/T1](#)
 - [Status](#)
 - [Test Modes](#)
 - [DS0 Monitor](#)
 - [Configuration](#)
- ▶ [G.SHDSL](#)

E1/T1 Configuration:

Configuration Options

Payload Rate	1536K(24)	Time Slot Select:	1-24
Line Options	Fractional T1 ESF		
Code Sel	B8ZS		
Line Build Out	100 Ohm 0dB		
FDL Mode	Ansi-T1-403		
Idle Codes	Disabled		
Power Down	Normal		

Configure and Activate

Copyright (c) 2002 Patton Electronics Co. [Terms and conditions](#)

Line Build Out: Select from 100 ohm (0dB), 100 ohm (-7.5dB), 100 ohm (-15dB), and 100 ohm (-22.5dB). For CSU/DSU application use 100 0dB option, consult your T1 service provider for more information.

FDL Mode: Options are ANSI-T1-403, ATT-54016, and Fdl-none. Consult your T1 service provider or third party equipment for FDL mode required.

Idle code: Enabled, Disabled. When enabled, the 2603 inserts idle codes on unused timeslots. Set this option to 'Disabled' unless instructed otherwise.

Power Down: Normal, Powered Down. When powered down, T1/E1 transceiver input and output lines will be set to high impedance to protect the device—set unit to “Normal” for regular operation.

Once all options have been selected, click on the **Configure and Activate** at the bottom of the screen. Additionally, save the configuration by going to the *Configuration > Save Config* menu.

E1 Interface

The 3086 enables T1 or E1 device located at customer locations to access a carrier's network over two wire, long reach DSL links. This capability allows providers to offer T1/E1 services at customer locations that were previously outside the reach of standard T1/E1 lines.

The 3086 offers a user configurable T1 or E1 interface. Selection of the interface is done via DIP switches, HTTP/SNMP, or command line interface (CLI).

The E1 interface is presented on both a modular, 8-pin RJ-48C jack for connection to 120-ohm twisted pair lines, and dual BNC female connectors for connection to 75-ohm coaxial lines.




Figure 11. E1 interface with RJ-48C jack (120-ohm) and dual BNC (75-ohm) connectors

E1 Interface Connection

The 3086 will usually connect either to a local E1 device, or to a Telco terminated E1 line jack.

- To connect to the 3086 E1 port and a local E1 device (PBX, router, mux) use a E1 'crossover' twisted pair cable. A crossover cable connects the transmit pins of the Model 3086's E1 port to the receive pins of the device attached to this port and vice versa. Check the third party E1 equipment documentation for pinout

information and cable requirements. If the E1 connection is made via the BNC connectors, connect the TX BNC of the 3086 to Recive (RX) BNC of the local E1 device, and vice versa.

- To connect the 3086's E1 port to a Telco terminated E1 line jack, use a straight through twisted pair patch cable. Consult with your E1 service provider for exact pinout information and cable requirements.

The 3086 T1/E1 port can be configured via DIP switches, HTTP/SNMP, or command line interface (CLI). This section discusses DIP switches and HTTP (web server) configuration, for CLI and SNMP information see Appendix E on page 163.

DIP Switch Configuration

Switch configuration in the 3086 is to be used in situations where the 3086 functions as a DSL modem carrying TDM (E1) data only without resorting to the use of a PC for configuration.

Note The Model 3086 is shipped with all DIP switches set to the ON position. While in this setting, the Model 3086 can be configured only via software (console, Telnet, HTTP, SNMP). If you want to use the DIP switches to configure the Model 3086, see section “Switch S2-8” on page 43 to activate the DIP switch configuration option.

The Model 3086 includes two eight-DIP switch banks labeled S2 and S3. They are externally accessible by removing the plate on the bottom side of the unit.

Switch Bank S2

A description of S2 options follows the table.

S7	S6	S5	S4	S3	S2	S1	Data Rate (kbps)
On	On	On	On	On	On	Off	64
On	On	On	On	On	Off	On	128
On	On	On	On	On	Off	Off	192
On	On	On	On	Off	On	On	256
On	On	On	On	Off	On	Off	320
On	On	On	On	Off	Off	On	384
On	On	On	On	Off	Off	Off	448
On	On	On	Off	On	On	On	512
On	On	On	Off	On	On	Off	576
On	On	On	Off	On	Off	On	640
On	On	On	Off	On	Off	Off	704
On	On	On	Off	Off	On	On	768
On	On	On	Off	Off	On	Off	832
On	On	On	Off	Off	Off	On	896
On	On	On	Off	Off	Off	Off	960
On	On	Off	On	On	On	On	1024
On	On	Off	On	On	On	Off	1088
On	On	Off	On	On	Off	On	1152

S7	S6	S5	S4	S3	S2	S1	Data Rate (kbps)
On	On	Off	On	On	Off	Off	1216
On	On	Off	On	Off	On	On	1280
On	On	Off	On	Off	On	Off	1344
On	On	Off	On	Off	Off	On	1408
On	On	Off	On	Off	Off	Off	1472
On	On	Off	Off	On	On	On	1536
On	On	Off	Off	On	On	Off	1600
On	On	Off	Off	On	Off	On	1664
On	On	Off	Off	On	Off	Off	1728
On	On	Off	Off	Off	On	On	1792
On	On	Off	Off	Off	On	Off	1856
On	On	Off	Off	Off	Off	On	1920
On	On	Off	Off	Off	Off	Off	1984
On	Off	On	On	On	On	On	2048

Switch S2-8. S2-8 activates configuration of Model 3086 via DIP switches. Any time the user desires to modify the 3086 configuration available through DIP switches, make the changes to the corresponding switches and then set S2-8, from On to Off position, wait 3-4 seconds and set back to the On position. Changes made to configuration via DIP switches will not take effect if S2-8 isn't toggled.

S2-8	Condition
ON->Off->ON	Implements switch configuration (toggled ON/OFF)

Switch Bank S3

The table below shows the default configuration for switch S3. A description of S3 options follows this table.

Table 8. S3 Summary Table

Switch Position	Function	Factory Default	Selected Option
S3-1	CO/CP Selection	On	CO
S3-2	Reserved	On	Reserved
S3-3	Clock	On	External
S3-4	Reserved	On	Reserved
S3-5	Reserved	On	Reserved
S3-6	Annex	Off = Annex A On = Annex B	Annex B
S3-7	T1/E1	On	T1
S3-8	E1/CRC	On	No CRC

Switch S3-1: CO/CP selection. CO and CP stand for Central Office and Customer Premise respectively. When deploying the model 3086s, units installed at the Customer location should be set to CP and units

installed at a Central Office should be set to *CO*. For point-to-point operation, one unit must be *CO* while the other must be *CP*.

S3-3	Setting
Off	CP
ON	CO

Switch S3-3: Transmit Clock Mode. Use Switches S3-3 to configure the 3086 for internal or external clock mode.

S3-3	Clock mode
Off	Internal. Transmit clock generated by the 3086
On	External (network). DSL and E1 transmit clock derived from the received E1 signal (available in CO mode only)

Switch S3-6: Annex. Annex A and B offer spectral compatibility with T1 and E1 signals respectively, this feature reduces the interference between DSL lines and adjacent E1 or T1 lines. For regions where E1 is used, select Annex B.

S3-6	Annex
Off	Annex A
On	Annex B

Switch S3-7. Use S3-7 to configure the TDM interface for T1 or E1 service. Note that selecting E1 automatically sets the E1 line rate to HDB3, line impedance to 120-ohms. Selecting T1 automatically sets the framing to Extended Super Frame and B8ZS line code.

S3-7	Configuration
Off	E1 mode (HDB3)
On	T1 mode (ESF/B8ZS)

Switch S3-8. Switch S3-8 applies to E1 applications only. This switch selects whether the E1 link will use CRC or not while in framed mode. In Clear Channel mode (unframed) this switch is ignored.

S3-8	Setting
Off	E1 with CRC
ON	E1 without CRC

E1/T1 Configuration:

Configuration Options

Payload Rate	1984K(31)	Time Slot Select	1-31
Line Options	Fractional E1		
Code Sel	HDB3		
Line Build Out	120 Ohm		
FDL Mode	Fdl-none		
Idle Codes	Disabled		
Power Down	Normal		

Configure and Activate

Copyright (c) 2002 Patton Electronics Co. [Terms and conditions](#)

Web Interface Configuration

Launch Internet Explorer or similar web browser, type the IP address of the 2603, enter username 'superuser' and password 'superuser'. From the main page click on the E1/T1 option > Configuration. This page allows configuration of E1 parameters as follows:

Time Slot Select. For unframed E1 service (Clear Channel) enter time slots 0-31. For a full framed E1 enter 1-31, for partially filled E1 enter the range of timeslots using the format for example: 1,2,3,5; or 1-5,10-31. Any entry for timeslots above 31 will return an invalid selection message.

Line Options: Choose from Clear Channel E1, Fractional E1, Fractional E1, Multi-Frame(CAS) E1, Multi-Frame(CAS) E1 with CRC. Consult with your service provider which option is required.

Line Code: Choose from AMI or HDB3. Most E1 applications use HDB3

Line Build Out: Select 120 ohm if the E1 connection is made via the RJ-48C connector, select 75 Ohm if the E1 connection is made via the Dual BNC connectors.

FDL Mode: FDL is a T1 application, therefore select 'Fdl- none' for E1 applications.

Idle code: Options are Enabled or Disabled. When idle code is Enabled, the 3086/K inserts idle codes on E1 unused timeslots. Set this option to 'Disabled' unless instructed otherwise.

Power Down: Options are Normal and Powerdown. When the 3086 is set to powered down, it will set the E1 interface pins to high impedance to protect the device – set unit to "Normal" for regular operation.

Once all options have been selected, click on the **Configure and Activate** button at the bottom of the screen. Additionally, save the configuration by going to the *Configuration > Save Config* menu.

Using the 3086 as a simple modem (TDM data over DSL)

Serial port connection only, Ethernet port not used to send data over DSL but can be used for management.

There are three ways to configure the 3086 for serial port operation only:

- Via DIP switches
- Via the console port (using the command line interface or *CLI*)
- Via the Ethernet port using Telnet, Web browser, or SNMP tools.

For point-to-point operation (two 3086s connected directly) at 2.048 Mbps, follow the next example:



DIP Switch Configuration

3086 A			3086 B		
Switch	Setting	Condition	Switch	Setting	Condition
S2-1	On	2.048 Mbps	S2-1	On	2.048 Mbps
S2-2	Off		S2-2	Off	
S2-3	On		S2-3	On	
S2-4	On		S2-4	On	
S2-5	On		S2-5	On	
S2-6	On		S2-6	On	
S2-7	On		S2-7	On	
S2-8	On		S2-8	On	
S3-1	On	CO	S3-1	Off	CP
S3-3	Off	Int. clock	S3-3	Off	Int. Clock
S3-6	On	Annex B	S3-6	On	Annex B

Set switch S2-8 from On to Off, wait 3 to 4 seconds set it back to On.

CLI configuration

When using the console port, or Telnet session via Ethernet port, the user has access to the 3086 command line interface (CLI). The above configuration can be entered via the CLI as follows:

3086 A CLI configuration

Note Press the Enter key at the end of each command line.

```

→ gshdsl set terminal central
→ gshdsl set dsirateTS 32
→ gshdsl set interface hdlc

```

```
→ gshdsl set pcmmode Serial
→ gshdsl set ghsannex AnnexB
→ gshdsl set serialTS 32
→ system config save
```

Wait for 'configuration saved' message...

Saving configuration...

```
→
→ Configuration saved.
```

3086 B CLI configuration

Note Press the Enter key at the end of each command line.

```
→ gshdsl set terminal remote
→ gshdsl set dsrateTS 32
→ gshdsl set interface hdlc
→ gshdsl set pcmmode Serial
→ gshdsl set ghsannex AnnexB
→ gshdsl set serialTS 32
→ system config save
```

Wait for 'configuration saved' message...

Saving configuration...

```
→
→ Configuration saved.
```

Note When connecting to Patton Electronics Model 3096RC Central Office T-DACS, The model 3086 must be configured as CP (Remote). Check the 3096RC user manual for information on the configuration of the 3096RC.

Web browser configuration

From the main menu in the 3086, select *GSHDSL > Configuration*. Enter the selections as shown in the screen below. For Terminal Type, select *Central* for 3086 A, and *Remote* for 3086 B. Then go to the bottom of the screen and click on the **Configure** button.

Key Feature:	2
Circuit ID	Circuit ID **30Byte Maxi
Clear Error Counters	Do not Clear
Intended DSL Data Rate	2048K
Actual DSL Data Rate (kbps)	1992
Intended Serial Interface Data Rate	2048K
DSL Rate: Number of i Bit	0
Terminal Type	Remote
Interface Type	hdlc
PCM Mode	Serial Only
Clocking Options	Internal
PCM Transmit Clock Polarity	Normal
PCM Receive Clock Polarity	Normal
Loopback	off
Annex Type	Annex B
Line Probe	Disable

Circuit ID

User can enter up to 30 alphanumeric characters for circuit identification

Clear Error Counters

Selecting “Clear” will reset the error counters displayed in the “Status” screen.

Intended DSL Data Rate

This is the DSL line rate at which you wish to connect. In a point-to-point deployment, the unit designated as “Central” will impose the line rate on the unit designated as “Remote”. The model 3086 offers nx64 kbps speeds from 192 kbps to 4.6 Mbps.

Actual DSL Rate

This field displays the DSL rate connection; it displays the payload rate plus 8kbps automatically assigned to a DSL management channel. For instance, if a DSL rate of 1984 kbps is selected in the “Intended DSL Data Rate” window, the actual DSL data rate field will display 1992 kbps, this corresponds to 1984 kbps payload plus 8 kbps management channel.

Intended Serial Interface Data Rate

Selects the data rate assigned to the serial port in nx64 kbps increments from 64 kbps to a maximum of 2.3 Mbps. The following conditions apply when configuring the 3086 serial port:

- When the 3086 is operating as a simple modem – serial port operation only, the data rate assigned to the serial port must match the DSL rate (except when selecting 64 or 128kbps, DSL line rate at these speeds is 192kbps).
- When the 3086 transports serial and Ethernet traffic simultaneously, total data rate assigned to both Serial and Ethernet must match the DSL rate.
- When using the 3086 for simultaneous Serial and Ethernet data transport, assign partial bandwidth to the serial port only, the 3086 will automatically assign the remaining DSL bandwidth to the Ethernet port.
- When using the 3086 for simultaneous Serial and Ethernet data transport, timeslots (64kbps slots) carrying serial data are placed in the upper slots of the DSL frame, while Ethernet data is placed in the lower DSL frame timeslots.
- When the serial port is not used, set the “Intended Serial Interface” to “Not used”. The 3086 will automatically assign all DSL bandwidth to the Ethernet port.
- When using a 3086 with T1/E1 interface, the “Intended Serial Interface” field must match the speed selected for the T1/E1 port in the T1/E1 configuration menu.

DSL Rate: Number of i Bit

The *i* bit increments DSL speed by 8kbps in addition to the DSL rate selected in the “Intended DSL Data Rate” window. Most applications use nx64kbps DSL speeds, leave this setting at “0”, unless your application calls for a non-nx 64 speed. Selections for the I bit are 0 through 7 as follows:

- 0—No increment
- 1—Intended DSL data rate + 8 kbps
- 2—Intended DSL data rate + 16 kbps
- 3—Intended DSL data rate + 24 kbps
- 4—Intended DSL data rate + 32 kbps
- 5—Intended DSL data rate + 40 kbps
- 6—Intended DSL data rate + 48 kbps
- 7—Intended DSL data rate + 56 kbps

Terminal Type

Select between Remote and Central. Use the “Remote” setting for 3086s located at customer premises. Use “Central” setting for units located at a Central Office or ISP.

Note The unit set to “Central” will act as master and will impose DSL rate on the unit set as “Remote”

Interface Type

Selects between HDLC or ATM transports. This setting must match the transport selected in the “WAN connection” menu. When using the 3086 to transport serial data only, select HDLC transport.

PCM Mode

The PCM mode selection tells the Model 3086 whether the DSL link will carry Serial data (from serial port), Ethernet data (from Ethernet port), or both Serial and Ethernet. Make sure to assign bandwidth to the serial port in the “Intended Serial Interface Data Rate” when selecting “Serial” or “Serial and Ethernet” traffic.

Clocking Options

When using the serial port, the 3086 can transmit to the attached DTE using its internal clock, or using external clock from the DTE (this option is only available to units set for “Central”). Most applications use internal clock.

PCM Transmit Polarity

When using long cables on the serial port side, it is possible that the clock and data arriving at the DTE may be out of synchronization, causing data errors. Inverting the polarity of the transmit clock at the 3086 may solve this problem. Use the “Normal” setting when using short serial cables (less than 6 feet or 1.8 meters).

PCM Receive Polarity

When using long cables on the serial port side, it is possible that the clock and data arriving at the 3086 may be out of synchronization, causing data errors. Inverting the polarity of the receive clock at the 3086 may solve this problem. Use the “Normal” setting when using short serial cables (less than 6 feet or 1.8 meters).

Loopback

The 3086 uses a series of loopbacks to test the serial, Ethernet, and DSL links, Refer to Chapter 9, “Diagnostics” on page 135 for more information.

Annex Type

Annex type refers to spectral compatibility between DSL and T1 or E1 signals. For North America and other areas where T1 lines are used, select *Annex A*, for areas where E1 lines are used select *Annex B*.

Line Probe

Line probe is a tool used to determine maximum achievable rate when initially connecting 3086s to a copper line of unknown quality. Set this feature to “Enable” on both 3086s at each end of the link. Once line probe measurements have been completed set this feature to “Disabled”

Once you have completed your selections or changes, click on the **Configure** button at the bottom of the screen. Additionally, go to the G.SHDSL > Action link on the left side of the screen, and click action to start the DSL interface with the new settings.

TDM Plus Ethernet Traffic

The Model 3086 IAD can concurrently carry TDM data from the serial port (non-routed) and data from the Ethernet port, both data streams are carried simultaneously over the DSL link.

Note Data from the TDM port does not go through the routing core of the model 3086, this data is sent unprocessed over the DSL link.



CLI configuration

Configuring the 3086 to transport TDM and IP data concurrently requires use of a Laptop or PC terminal. When carrying IP data, the Model 3086 offers two WAN encapsulation methods: HDLC and ATM. In addition, when connecting two LAN segments over DSL, the 3086 offers options for Routed or Bridged services. The following example shows the configuration for connecting two LAN segments via DSL:

Selecting the DSL link speed

In this example a maximum DSL speed of 2.3Mbps (36 timeslots of 64 kbps each) will be selected, Using the CLI enter the following command:

```
→ gshdsl set dsllrateTS 36 <enter>
```

Selecting PCM mode

The PCM mode selection tells the Model 3086 Whether the DSL link will carry TDM data (from TDM port), Ethernet data (from Ethernet port), or both Serial and Ethernet.

In this example we will set the PCM mode for Serial and Ethernet data.

At the command prompt type:

```
→ gshdsl set pcmmode EthernetandSerial <enter>
```

Assigning bandwidth to serial and Ethernet ports

In this example, half of the bandwidth 1.152 Mbps (18 TS) assigned to the serial port and the other half 1.152 Mbps (18 TS) assigned to the Ethernet port.

From the CLI command prompt type:

```
→ gshdsl set serialTS 18 <enter>
```

Note Enter the required bandwidth in number of 64kbps time slots for the serial port, the 3086 automatically assigns the rest of the bandwidth to the Ethernet ports. For example, if the total DSL bandwidth is 2.3 Mbps (36 TS), assigning 1.152 Mbps (18 TS) to the TDM port, automatically assigns the rest of the DSL bandwidth (18 TS) for Ethernet traffic.

When the 3086 carries both TDM and Ethernet traffic, it places serial data in the upper timeslots of the DSL frame, and Ethernet timeslots to the lower portion of the DSL frame. In the example above, Ethernet data (18 TS) occupies timeslots from 1–18, while TDM data (18 TS) is carried in TS 19–36 of the DSL frame.

Central or Remote terminal (Master/Slave)

In a point-to-point deployment, one the two 3086s IAD must be set to Central (master), and the other to Remote (slave).

- For 3086 A at the prompt type

```
gshdsl set terminal central <enter>
```

- For 3086 B type

```
→ gshdsl set terminal remote
```

Interface Type

Selects between HDLC and ATM transport. To select HDLC for both 3086 type:

```
→ gshdsl set interface hdlc <enter>
```

Annex Type

Select between Annex A and Annex B.

To select Annex B type:

```
→ gshdsl set ghsannex AnnexB
```

Web Browser Configuration

The web browser offers the easiest way to configure the 3086. Log on the 3086 web server (default username: superuser, default password: superuser). From the main menu, click on the G.SHDSL option, select the “Con-

figuration option”. Use the drop down menus to enter the required configuration. Once all settings have been selected, click on the **Configure** button at the bottom of the screen.

G.SHDSL Attributes:	
Speed Class:	Speed class is 4.6Mbps
Key Feature:	2
Circuit ID	Circuit ID **30Byte Maxi
Clear Error Counters	Do not Clear
Intended DSL Data Rate	2304K
Actual DSL Data Rate (kbps)	1992
Intended Serial Interface Data Rate	1152K
DSL Rate: Number of i Bit	0
Terminal Type	Remote
Interface Type	hdlc
PCM Mode	Ethernet and Serial
Clocking Options	Internal
PCM Transmit Clock Polarity	Normal
PCM Receive Clock Polarity	Normal
Loopback	off
Annex Type	Annex B

Circuit ID

User can enter up to 30 alphanumeric characters for circuit identification

Clear Error Counters

Selecting “Clear” will reset the error counters displayed in the “Status” screen.

Intended DSL Data Rate

This is the DSL line rate at which you wish to connect. In a point-to-point deployment, the unit designated as “Central” will impose the line rate on the unit designated as “Remote”. The model 3086 offers nx64 kbps speeds from 192 kbps to 4.6 Mbps.

Actual DSL Rate

This field displays the DSL rate connection; it displays the payload rate plus 8kbps automatically assigned to a DSL management channel. For instance, if a DSL rate of 1984 kbps is selected in the “Intended DSL Data Rate” window, the actual DSL data rate field will display 1992 kbps, this corresponds to 1984 kbps payload plus 8 kbps management channel.

Intended Serial Interface Data Rate

Selects the data rate assigned to the serial port in nx64 kbps increments from 64 kbps to a maximum of 2.3 Mbps. The following conditions apply when configuring the 3086 serial port:

- When the 3086 is operating as a simple modem – serial port operation only, the data rate assigned to the serial port must match the DSL rate (except when selecting 64 or 128kbps, DSL line rate at these speeds is 192kbps).
- When the 3086 transports serial and Ethernet traffic simultaneously, total data rate assigned to both Serial and Ethernet must match the DSL rate.
- When using the 3086 for simultaneous Serial and Ethernet data transport, assign partial bandwidth to the serial port only, the 3086 will automatically assign the remaining DSL bandwidth to the Ethernet port.
- When using the 3086 for simultaneous Serial and Ethernet data transport, timeslots (64kbps slots) carrying serial data are placed in the upper slots of the DSL frame, while Ethernet data is placed in the lower DSL frame timeslots.
- When the serial port is not used, set the “Intended Serial Interface” to “Not used”. The 3086 will automatically assign all DSL bandwidth to the Ethernet port.
- When using a 3086 with T1/E1 interface, the “Intended Serial Interface” field must match the speed selected for the T1/E1 port in the T1/E1 configuration menu.

DSL Rate: Number of i Bit

The *i* bit increments DSL speed by 8kbps in addition to the DSL rate selected in the “Intended DSL Data Rate” window. Most applications use nx64kbps DSL speeds, leave this setting at “0”, unless your application calls for a non-nx 64 speed. Selections for the I bit are 0 through 7 as follows:

- 0—No increment
- 1—Intended DSL data rate + 8 kbps
- 2—Intended DSL data rate + 16 kbps
- 3—Intended DSL data rate + 24 kbps
- 4—Intended DSL data rate + 32 kbps
- 5—Intended DSL data rate + 40 kbps
- 6—Intended DSL data rate + 48 kbps
- 7—Intended DSL data rate + 56 kbps

Terminal Type

Select between Remote and Central. Use the “Remote” setting for 3086s located at customer premises. Use “Central” setting for units located at a Central Office or ISP.

Note The unit set to “Central” will act as master and will impose DSL rate on the unit set as “Remote”

Interface Type

Selects between HDLC or ATM transports. This setting must match the transport selected in the “WAN connection” menu. When using the 3086 to transport serial data only, select HDLC transport.

PCM Mode

The PCM mode selection tells the Model 3086 whether the DSL link will carry Serial data (from serial port), Ethernet data (from Ethernet port), or both Serial and Ethernet. Make sure to assign bandwidth to the serial port in the “Intended Serial Interface Data Rate” when selecting “Serial” or “Serial and Ethernet” traffic.

Clocking Options

When using the serial port, the 3086 can transmit to the attached DTE using its internal clock, or using external clock from the DTE (this option is only available to units set for “Central”). Most applications use internal clock.

PCM Transmit Polarity

When using long cables on the serial port side, it is possible that the clock and data arriving at the DTE may be out of synchronization, causing data errors. Inverting the polarity of the transmit clock at the 3086 may solve this problem. Use the “Normal” setting when using short serial cables (less than 6 feet or 1.8 meters).

PCM Receive Polarity

When using long cables on the serial port side, it is possible that the clock and data arriving at the 3086 may be out of synchronization, causing data errors. Inverting the polarity of the receive clock at the 3086 may solve this problem. Use the “Normal” setting when using short serial cables (less than 6 feet or 1.8 meters).

Loopback

The 3086 uses a series of loopbacks to test the serial, Ethernet, and DSL links, Refer to Chapter 9, “Diagnostics” on page 135 for more information.

Annex Type

Annex type refers to spectral compatibility between DSL and T1 or E1 signals. For North America and other areas where T1 lines are used, select *Annex A*, for areas where E1 lines are used select *Annex B*.

Line Probe

Line probe is a tool used to determine maximum achievable rate when initially connecting 3086s to a copper line of unknown quality. Set this feature to “Enable” on both 3086s at each end of the link. Once line probe measurements have been completed set this feature to “Disabled”

Once you have completed your selections or changes, click on the **Configure** button at the bottom of the screen. Additionally, go to the G.SHDSL > Action link on the left side of the screen, and click action to start the DSL interface with the new settings.


This concludes the basic DSL configuration for Ethernet and serial ports.

If your application calls for **Ethernet only**, or **Serial and Ethernet** traffic you need to configure the Model 3086 Ethernet transport between HDLC or ATM encapsulation. In addition, select between bridged or routed configuration options, whichever meets your network needs. The following section steps through the various application configurations options possible with the 3086.

Using the 3086 in Routed or Bridged applications

Two stand-alone units directly connected

Ethernet extension (HDLC – PPPOH) Bridged



Model 3086 (Remote) Configuration Steps (PPPoH Bridged)

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called *ip1* with an IP address of 192.168.1.1

Let's change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.2

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0

1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to **Configuration**, then to **WAN Connections**. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Bridged** and click on the **Configure** button.

WAN connection: create service

Please select the type of service you wish to create:

ATM: ☐ RFC 1483 routed ☐ RFC 1483 bridged
☐ PPPoA routed ☐ PPPoA bridged
☐ IPoA routed ☐ PPPoE routed
 HDLC: ☐ PPPoH routed ☒ PPPoH bridged

Configure

3. In the Description field, enter the description you wish. In this example, it is called *PPPoH Bridged*.

WAN connection: PPPoH bridged

The screenshot shows a configuration page titled "WAN connection: PPPoH bridged". The page contains the following fields and options:

- Description:
- Interface:
- LLC header mode:
- LLC header mode:
- HDLC header mode:
- ☒ No authentication
- ☐ PAP
- ☐ CHAP
- User name:
- Password:
-

Verify the settings to be:

- Interface = 1
- LLC header mode = dialout
- LLC header mode = off
- HDLC header mode = on
- No authentication
- Leave *User name* and *Password* blank.

Click on **Apply**.

4. Go to **G.SHDSL** in the **Configuration Menu**, then the submenu **Configuration**.

G.SHDSL Attributes:

Circuit ID	Circuit ID ***30Byte Maxim
Clear Error Counters	Normal
Intended DSL Data Rate	36
Actual DSL Data Rate (kbps)	2312
DSL Rate: Number of i Bit	0
Terminal Type	Central
Interface Type	hdlc
PCM Mode	Ethernet Only
Clocking Options	Internal
PCM Transmit Clock Polarity	Normal
PCM Receive Clock Polarity	Normal
Loopback	Off
Annex Type	Annex A
Remote Circuit ID	
<input type="button" value="Configure"/>	
Action	

Change Terminal Type to *Central* and Interface Type to *hdlc*. Click on the **Configure** button.

In the Action submenu under G.SHDSL, change Action to **Deactivate**, then click on **Action**.

Return to Action, select **Start** and click on **Action**.

Model 3086 (Central) Configuration Steps (PPPoH Bridged)

See the Web page images for the Remote Model 3086 configuration above.

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called *ip1* with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as both PCs. For example, to *192.168.100.3*

→ ip set interface ip1 ipaddress 192.168.100.3 255.255.255.0

1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to **Configuration**, then to **WAN Connections**. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Bridged** and click on the **Configure** button.

In the **Description** field, enter the description you wish. In this example, it is called *PPPoH Bridged*.

Verify the settings to be:

- Interface = 1
- LLC header mode = dialout

- LLC header mode = off
- HDLC header mode = on
- No authentication
- Leave User name and Password blank.

Click on **Apply**.

3. Go to **G.SHDSL** in the Configuration Menu, then the submenu **Configuration**.


Leave Terminal Type as *Remote*.

Change Interface Type to **hdlc**. Click on the **Configure** button.

In the Action submenu under G.SHDSL, change Action to **Deactivate**, then click on **Action**.

Return to Action, select **Start** and click on **Action**.

Network Extension (HDLC—PPPoH Routed)




Model 3086 (Remote) Configuration Steps (PPPoH Routed)

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface was called ip1 with an IP address of 192.168.1.1 Change it to an IP address which is in the same subnet as the Desktop PC. For example, to 192.168.100.2. The default IP mask is 255.255.255.0.

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0



1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on **G.SHDSL** in the **Configuration Menu > Configuration** > verify that Terminal Type is **Central** and Interface Type is "**hdlc**." If changed, then click on **Configure**.

Click on **Action** > Select **deactivate** for Action > Click on the **Action** button.

2. On the Menu, go to **Configuration**, then to **WAN Connections**

Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Routed** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *PPPoH Routed*.

- Description: PPPoH Routed
- Interface: 1
- WAN IP address: 192.168.164.2
- LLC Header Mode: off
- HDLC Header Mode: ON
- No authentication
- Username: [blank]
- Password: [blank]

WAN connection:


Description:	PPPoH Routed
Interface:	1
WAN IP address:	192.168.164.2
LLC header mode:	off
HDLC header mode:	on
<input checked="" type="radio"/> No authentication <input type="radio"/> PAP <input type="radio"/> CHAP	
User name:	
Password:	
<input type="button" value="Configure"/>	

Click on **Configure**.

- Go to **Configuration Menu > Configuration > WAN connections > Edit (for PPPoH Routed service) > Edit 'IP Interface' > Ipaddr:** [enter the WAN IP Address, in this example = 192.168.164.2] > Click on **Change**.

Edit Ip Interface

Options	
Name	Value
Ipaddr:	192.168.164.2
Mask:	255.255.255.0
Dhcp:	false
MTU:	1500
Enabled:	true
Layer2Session:	
<input type="button" value="Change"/> <input type="button" value="Reset"/>	




4. **Configuration Menu > Configuration > IP Routes > Click on Create new Ip V4 Route > Create the gateway to the remote 3086 by entering the WAN IP address of the remote 3086, in this example, enter 192.168.164.3 in the Gateway field > OK**

Create Ip V4Route

Name	Value
Destination	0.0.0.0
Gateway	192.168.164.3
Netmask	0.0.0.0
Cost	1
Interface	

The other fields should be:

- Destination: 0.0.0.0
- Gateway: 192.168.164.3 [already configured in first part of step 4).]
- Mask: 0.0.0.0
- Cost: 1
- Interface: [blank]



5. Go to G.SHDSL in the Configuration Menu, then the submenu Status. The Modem State should be “deactivated.” (If not, go to the Action and change it to deactivate.)

Then in the Action submenu under G.SHDSL, change Action to Start, then click on **Action**.

Model 3086 (Central) Configuration Steps (PPPoH Routed)

See the web pages for the desktop above. Some parametric values are different although the process is the same.

From the command line interface (CLI) via the RS-232 control port,


```
→ ip list interfaces
→ ip clear routes
→ pppoh clear transports

→ ethernet add transport eth1 ethernet
```

One IP interface was called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as the laptop PC. The laptop's IP address is 192.168.172.229, so in this example, change the IP address of the 3086 to 192.168.172.3. The default IP mask is 255.255.255.0.

```
→ ip set interface ip1 ipaddress 192.168.172.3 255.255.255.0
```



1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on **G.SHDSL** in the **Configuration Menu > Configuration** > verify that Terminal Type is *remote* and Interface Type is "*hdlc*." If changed, then click on **Configure**.

Click on **Action** > Select **deactivate** for Action > Click on the **Action** button.

2. On the Menu, go to **Configuration**, then to **WAN Connections**.

Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Routed** and click on the **Configure** button.


In the Description field, enter the description you wish. In this example, it is called *PPPoH Routed*.

Description:PPPoH Routed

- Interface:1
- WAN IP address: 192.168.164.3
- LLC Header Mode:off
- HDLC Header Mode:ON
- No authentication
- Username:[blank]
- Password:[blank]

Click on **Configure**.

3. Go to **Configuration Menu > Configuration > WAN connections > Edit (for PPPoH Routed service) > Edit 'IP Interface' > Ipaddr:** [enter the WAN IP Address, in this example = 192.168.164.3] > Click on **Change**.




4. **Configuration Menu > Configuration > IP Routes** > Click on **Create new Ip V4 Route** > Create the gateway to the remote 3086 by entering the WAN IP address of the remote 3086, in this example, enter 192.168.164.2 in the Gateway field > OK

The other fields should be:

- Destination:0.0.0.0
- Gateway:192.168.164.2 [already changed in the first part of step 5).]
- Mask:0.0.0.0

- Cost:1
- Interface:[blank]



- Go to **G.SHDSL** in the Configuration Menu, then the submenu **Status**. The Modem State should be “deactivated.” (If not, go to the Action and change it to deactivate.)

Then in the Action submenu under G.SHDSL, change Action to Start, then click on **Action**.

DSLAM Connections with remote CPE units

Bridged application configurations to a DSLAM


Three bridged services are offered, *RFC 1483 Bridged*, *PPPoA Bridged*, and *HDLC Bridged*.

The configurations show a desktop on one end and a laptop on the other. The laptop and its Model 3086 would be replaced with a DSLAM.

RFC 1483 Bridged Configuration.

No additional IP addresses are needed other than the IP address chosen earlier. In fact, if you are configuring and managing the model 3086 only from the CLI (Command Line Interface), an IP address is not needed at all. The limitation of no IP address precludes the user from doing web management of the 3086 since management is done via the Ethernet port.

As in the PPPoA Bridged application, both sides of the RFC 1483 bridged connection are on the same subnet.



Model 3086 (Remote) Configuration Steps (RFC 1483 Bridged)

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.2

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0

1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to Configuration, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **RFC_1483_Bridged** and click on the **Configure** button.

WAN connection:

Description:	<input type="text" value="RFC1483 B"/>
VPI:	<input type="text" value="0"/>
VCI:	<input type="text" value="35"/>
Encapsulation method:	<input type="text" value="LLC/SNAP"/>
<input type="button" value="Apply"/>	

In the Description field, enter the description you wish. In this example, it is called *RFC 1483 B*.

Leave VCI as 35 and Encapsulation Method as LLC/SNAP. Then click on **Apply**.

3. Go to **G.SHDSL** in the Configuration Menu, then the submenu **Configuration**.

G.SHDSL Attributes:

Speed Class:	Speed class is 4.6Mbps
Key Feature:	2
Circuit ID	Circuit ID ***30Byte Maxi
Clear Error Counters	Do not Clear
Intended DSL Data Rate	2304K
Actual DSL Data Rate (kbps)	1992
Intended Serial Interface Data Rate	Not In Use
DSL Rate: Number of i Bit	0
Terminal Type	Remote
Interface Type	hdlc
PCM Mode	Ethernet Only
Clocking Options	Internal
PCM Transmit Clock Polarity	Normal
PCM Receive Clock Polarity	Normal
Loopback	off
Annex Type	Annex B

Change Terminal Type to *Remote* and Interface Type to *atm*. Click on the **Configure** button.

In the Action submenu under G.SHDSL, change Action to **Deactivate**, then click on Action.

Return to Action, select **Start** and click on **Action**.

Model 3086 (Central) Configuration Steps (RFC 1483 Bridged)

Although the some parametric values may vary from the desktop's Model 3086, the process is identical.

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.3

→ ip set interface ip1 ipaddress 192.168.100.3 255.255.255.0

1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to Configuration, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **RFC_1483_Bridged** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *RFC 1483 B*.

Leave VCI as 35 and Encapsulation Method as LLC/SNAP. Then click on **Apply**.

- Go to G.SHDSL in the Configuration Menu, then the submenu Configuration.

Leave Terminal Type as *Remote*, but change Interface Type to *atm*. Click on the **Configure** button.

G.SHDSL Actions:




In the Action submenu under G.SHDSL, change Action to **Deactivate**, then click on **Action**.

G.SHDSL Actions:



Return to Action, select **Start** and click on **Action**.

PPPoH Bridged Configuration



Model 3086 (Remote) Configuration Steps (PPPoH Bridged)

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called ip1 with an IP address of 192.168.1.1. Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.2

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0

- Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
- On the Menu, go to **Configuration**, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Bridged** and click on the **Configure** button.

WAN connection: create service

Please select the type of service you wish to create:

ATM: ☐ RFC 1483 routed ☐ RFC 1483 bridged
☐ PPPoA routed ☐ PPPoA bridged
☐ IPoA routed ☐ PPPoE routed
 HDLC: ☐ PPPoH routed ☒ PPPoH bridged

Configure

In the Description field, enter the description you wish. In this example, it is called *PPPoH Bridged*.

WAN connection: PPPoH bridged

Description:

Interface:

LLC header mode:

LLC header mode:

HDLC header mode:

☒ No authentication
☐ PAP
☐ CHAP

User name:

Password:

Apply

- Interface = 1
 - LLC header mode = dialout
 - LLC header mode = off
 - HDLC header mode = on
 - No authentication
 - Leave User name and Password blank.
 - Click on **Apply**.
3. Go to **G.SHDSL** in the Configuration Menu, then the submenu **Configuration**.
- Change Terminal Type to *Remote* and Interface Type to *hdlc*. Click on the **Configure** button.
 - In the Action submenu under G.SHDSL, change Action to Deactivate, then click on **Action**.
 - Return to Action, select **Start** and click on **Action**.

Model 3086 (Central) Configuration Steps (PPPoH Bridged)

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.3

→ ip set interface ip1 ipaddress 192.168.100.3 255.255.255.0

1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to Configuration, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Bridged** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *PPPoH Bridged*.

- Interface = 1
- LLC header mode = dialout
- LLC header mode = off
- HDLC header mode = on
- No authentication
- Leave User name and Password blank.

Click on **Apply**.

3. Go to G.SHDSL in the Configuration Menu, then the submenu Configuration.

Leave Terminal Type as *Central*.


Change Interface Type to *hdlc*. Click on the Configure button.

In the Action submenu under G.SHDSL, change Action to Deactivate, then click on **Action**.

Return to Action, select Start and click on **Action**.

PPPoA Bridged (RFC 2364) Configuration

The user data for transmission is in the form of IP packets but encapsulated in a PPP packet, transmitted and received through a PPP session to the connection. The PPP packets are encapsulated according to RFC 2364 for transmission over the ATM link. The packets are de-encapsulated on the receive side so that the IP data can be delivered to the end user.

**Model 3086 (Remote) Configuration Steps (PPPoA Bridged)**

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.2

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0

1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to Configuration, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoA_Bridged** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *PPPoA Bridged*.

WAN connection:

Description:	PPPoA Bridged
VPI:	0
VCI:	300
LLC header mode:	off
HDLC header mode:	off
<input checked="" type="radio"/> No authentication <input type="radio"/> PAP <input type="radio"/> CHAP	
User name:	
Password:	
<input type="button" value="Apply"/>	

- VPI = 0
- VCI = 300
- LLC header mode = off
- HDLC header mode = off
- No authentication
- Leave User name and Password blank.

Click on **Apply**.

3. Go to G.SHDSL in the Configuration Menu, then the submenu Configuration. Change Terminal Type to *Remote* and Interface Type to *atm*. Click on the **Configure** button. In the Action submenu under G.SHDSL, change Action to **Deactivate**, then click on **Action**.



Return to Action, select **Start** and click on **Action**.

Model 3086 (Central) Configuration Steps (PPPoA Bridged)

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface is called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.3

→ ip set interface ip1 ipaddress 192.168.100.3 255.255.255.0

1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to Configuration, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoA_Bridged** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *PPPoA Bridged*.

- VPI = 0
- VCI = 300
- LLC header mode = off
- HDLC header mode = off

- No authentication
- Leave User name and Password blank.

Click on **Apply**.

3. Go to G.SHDSL in the Configuration Menu, then the submenu Configuration.

Leave Terminal Type as *Central*.


Change Interface Type to *atm*. Click on the **Configure** button.

In the Action submenu under G.SHDSL, change Action to Deactivate, then click on **Action**.

Return to Action, select **Start** and click on **Action**.

Routed application configurations to a DSLAM

Five **routed** WAN services are offered, *RFC 1483*, *PPPoH*, *IPoA*, *PPPoA*, and *PPPoE Routed*.



RFC 1483 Routed

RFC 1483 provides the simplest method of connecting end stations over an ATM network. User data in the form of Ethernet packets is encapsulated into AAL-5 PDUs for transport over ATM. RFC 1483 provides no authentication and configuration that would be provided by PPP.


Model 3086 (Remote) Configuration Steps (RFC 1483 Routed)

From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface was called ip1 with an IP address of 192.168.1.1 Change it to an IP address which is in the same subnet as the Desktop PC. For example, to 192.168.100.2. The default IP mask is 255.255.255.0.

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0



1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on G.SHDSL in the Configuration Menu > Configuration > verify that Terminal Type is *Central* and Interface Type is *atm*. If changed, then click on **Configure**.

G.SHDSL Actions:



Click on Action > Select deactivate for Action > Click on the Action button.

2. On the Menu, go to Configuration, then to WAN Connections.

Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **RFC 1483 Routed** and click on the **Configure** button.

WAN connection: create service

Please select the type of service you wish to create:

ATM:	<input checked="" type="radio"/> RFC 1483 routed	<input type="radio"/> RFC 1483 bridged
	<input type="radio"/> PPPoA routed	<input type="radio"/> PPPoA bridged
	<input type="radio"/> IPoA routed	<input type="radio"/> PPPoE routed
HDLC:	<input type="radio"/> PPPoH routed	<input type="radio"/> PPPoH bridged

Configure

In the Description field, enter the description you wish. In this example, it is called *RFC 1483 Routed*. Change the configuration parameters to match the following.

WAN connection:


Description:	RFC 1483 Routed
VPI:	0
VCI:	35
Encapsulation method:	LLC/SNAP
<input type="radio"/> Use DHCP	
<input checked="" type="radio"/> WAN IP address:	192.168.164.2

Apply

Description:RFC 1483 Routed

- VPI:0
- VCI:35
- Encapsulation Method: LLC/SNAP
- WAN IP Address:192.168.164.2

Click on **Configure**.




3. Configuration Menu > Configuration > IP Routes > Click on Create new Ip V4 Route > Create the gateway to the remote 3086 by entering the WAN IP address of the remote 3086, in this example, enter 192.168.164.3 in the Gateway field > OK

Create Ip V4Route

Name	Value
Destination	0.0.0.0
Gateway	192.168.164.3
Netmask	0.0.0.0
Cost	1
Interface	

The other fields should be:

- Destination:0.0.0.0
- Gateway:192.168.164.3
- Mask:0.0.0.0
- Cost:1
- Interface:[blank]



4. Go to G.SHDSL in the Configuration Menu, then the submenu Status. The Modem State should be “deactivated.” (If not, go to the Action and change it to deactivate.)

Then in the Action submenu under G.SHDSL, change Action to **Start**, then click on **Action**.

Model 3086 (Central) Configuration Steps (RFC 1483 Routed)


From the command line interface (CLI) via the RS-232 control port,

- ip list interfaces
- pppoh clear transports

One IP interface was called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as the laptop PC. The laptop's IP address is 192.168.172.229, so in this example, change the IP address of the 3086 to 192.168.172.3. The default IP mask is 255.255.255.0.

```
→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0
```



1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on G.SHDSL in the Configuration Menu > Configuration > verify that Terminal Type is *Remote* and Interface Type is *atm*. If changed, then click on **Configure**.

G.SHDSL Attributes:

Speed Class:	Speed class is 4.6Mbps
Key Feature:	2
Circuit ID	Circuit ID ***30Byte Maxi
Clear Error Counters	Do not Clear
Intended DSL Data Rate	2304K
Actual DSL Data Rate (kbps)	1992
Intended Serial Interface Data Rate	Not In Use
DSL Rate: Number of i Bit	0
Terminal Type	Remote
Interface Type	hdlc
PCM Mode	Ethernet Only
Clocking Options	Internal
PCM Transmit Clock Polarity	Normal
PCM Receive Clock Polarity	Normal
Loopback	off
Annex Type	Annex B

Click on Action > Select deactivate for Action > Click on the Action button.

G.SHDSL Actions:



A dialog box titled "G.SHDSL Actions:". It contains a label "Action" next to a dropdown menu currently showing "Deactivate". Below this is a button labeled "Action".


2. On the Menu, go to Configuration, then to WAN Connections.

Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **RFC 1483 Routed** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *RFC 1483 Routed*.

WAN connection:




A configuration form titled "WAN connection:". It contains the following fields and options:

- Description: RFC 1483 Routed
- VPI: 0
- VCI: 35
- Encapsulation method: LLC/SNAP (dropdown menu)
- ☐ Use DHCP
- ☒ WAN IP address: 192.168.164.2
- Apply button

Description:RFC 1483 Routed

- VPI:0
- VCI:35
- Encapsulation Method: LLC/SNAP
- WAN IP Address:192.168.164.3

Click on **Configure**.



3. Configuration Menu > Configuration > IP Routes > Click on Create new Ip V4 Route > Create the gateway to the remote 3086 by entering the WAN IP address of the remote 3086, in this example, enter 192.168.164.2 in the Gateway field > OK


Create Ip V4Route

Name	Value
Destination	0.0.0.0
Gateway	192.168.164.2
Netmask	0.0.0.0
Cost	1
Interface	

OK Reset
Cancel

The other fields should be:

- Destination:0.0.0.0
- Gateway:192.168.164.2
- Mask:0.0.0.0
- Cost:1
- Interface:[blank]



- Go to G.SHDSL in the Configuration Menu, then the submenu Status. The Modem State should be “deactivated.” (If not, go to the Action and change it to deactivate.)

Then in the Action submenu under G.SHDSL, change Action to Start, then click on Action.


G.SHDSL Actions:

Action Start

Action

The modems should link up within 30 seconds or so and the link is ready for communication.

PPPoH Routed




Model 3086 (Remote) Configuration Steps (PPPoH Routed)

From the command line interface (CLI) via the RS-232 control port,

- ip list interfaces
- ip clear routes
- pppoh clear transports

One IP interface was called ip1 with an IP address of 192.168.1.1 Change it to an IP address which is in the same subnet as the Desktop PC. For example, to 192.168.100.2. The default IP mask is 255.255.255.0.

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0



1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on G.SHDSL in the Configuration Menu > Configuration > verify that Terminal Type is *Central* and Interface Type is *hdlc*. If changed, then click on **Configure**.

Click on Action > Select deactivate for Action > Click on the Action button.

2. On the Menu, go to Configuration, then to WAN Connections

Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Routed** and click on the **Configure** button.

WAN connection: create service

Please select the type of service you wish to create:

ATM: ☐ RFC 1483 routed ☐ RFC 1483 bridged
☐ PPPoA routed ☐ PPPoA bridged
☐ IPoA routed ☐ PPPoE routed
 HDLC: ☒ PPPoH routed ☐ PPPoH bridged

Configure

In the Description field, enter the description you wish. In this example, it is called *PPPoH Routed*.


- Description:PPPoH Routed
- Interface:1
- WAN IP address: 192.168.164.2
- LLC Header Mode:off
- HDLC Header Mode:ON
- No authentication

- Username:[blank]
- Password:[blank]

Click on **Configure**.

The screenshot shows a configuration window for a PPPoH Routed service. The fields are as follows:

Description:	PPPoH Routed
Interface:	1
WAN IP address:	192.168.164.2
LLC header mode:	off
HDLC header mode:	on
<input checked="" type="radio"/> No authentication	
<input type="radio"/> PAP	
<input type="radio"/> CHAP	
User name:	
Password:	
Configure	



3. Go to Configuration Menu > Configuration > WAN connections > Edit (for PPPoH Routed service) > Edit 'IP Interface' > Ipaddr: [enter the WAN IP Address, in this example = 192.168.164.2] > Click on Change.

Edit Ip Interface

Options	
Name	Value
Ipaddr:	192.168.164.2
Mask:	255.255.255.0
Dhcp:	false
MTU:	1500
Enabled:	true
Layer2Session:	
<input type="button" value="Change"/> <input type="button" value="Reset"/>	

4. Configuration Menu > Configuration > IP Routes > Click on Create new Ip V4 Route > Create the gateway to the remote 3086 by entering the WAN IP address of the remote 3086, in this example, enter 192.168.164.3 in the Gateway field > OK

The other fields should be:

Destination:0.0.0.0

Gateway:192.168.164.3 [already configured in first part of step 5).]


Mask:0.0.0.0

Cost:1

Interface:[blank]

Create Ip V4Route

Name	Value
Destination	0.0.0.0
Gateway	192.168.164.3
Netmask	0.0.0.0
Cost	1
Interface	
<input type="button" value="OK"/> <input type="button" value="Reset"/>	
<input type="button" value="Cancel"/>	



- Go to G.SHDSL in the Configuration Menu, then the submenu Status. The Modem State should be “deactivated.” (If not, go to the Action and change it to deactivate.)

Then in the Action submenu under G.SHDSL, change Action to Start, then click on **Action**.

G.SHDSL Actions:

The screenshot shows a web-based configuration interface for G.SHDSL. It features a dropdown menu with 'Start' selected and an 'Action' button below it. The interface is titled 'G.SHDSL Actions:'.

Model 3086 (Central) Configuration Steps (PPPoH Routed)


From the command line interface (CLI) via the RS-232 control port,

- ip list interfaces
- pppoh clear transports

One IP interface was called ip1 with an IP address of 192.168.1.1

Change the IP address so it is in the same subnet as the laptop PC. The laptop's IP address is 192.168.172.229, so in this example, change the IP address of the 3086 to 192.168.172.3. The default IP mask is 255.255.255.0.

- ip set interface ip1 ipaddress 192.168.172.3 255.255.255.0



1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on G.SHDSL in the Configuration Menu > Configuration > verify that Terminal Type is *Central* and Interface Type is *hdlc*. If changed, then click on **Configure**.

Click on Action > Select deactivate for Action > Click on the **Action** button.

2. On the Menu, go to Configuration, then to WAN Connections.


Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoH_Routed** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *PPPoH Routed*.

- Description:PPPoH Routed
- Interface:1
- WAN IP address: 192.168.164.3
- LLC Header Mode:off
- HDLC Header Mode:ON
- No authentication
- Username:[blank]
- Password:[blank]


Click on **Configure**.



3. Go to Configuration Menu > Configuration > WAN connections > Edit (for PPPoH Routed service) > Edit 'IP Interface' > Ipaddr: [enter the WAN IP Address, in this example = 192.168.164.3] > Click on Change.
4. Configuration Menu > Configuration > IP Routes > Click on Create new Ip V4 Route > Create the gateway to the remote 3086 by entering the WAN IP address of the remote 3086, in this example, enter 192.168.164.2 in the Gateway field > OK

The other fields should be:

- Destination:0.0.0.0
- Gateway:192.168.164.2 [already changed in the first part of step 5).]
- Mask:0.0.0.0
- Cost:1
- Interface:[blank]



5. Go to G.SHDSL in the Configuration Menu, then the submenu Status. The Modem State should be "deactivated." (If not, go to the Action and change it to deactivate.)


Then in the Action submenu under G.SHDSL, change Action to Start, then click on **Action**.

PPPoA Routed (RFC 2364)

This routed application is very similar to the PPPoA Bridged application. The user data for transmission is in the form of IP packets but encapsulated in a PPP packet, transmitted and received through a PPP session to the connection. The PPP packets are encapsulated according to RFC 2364 for transmission over the ATM link. The packets are de-encapsulated on the receive side so that the IP data can be delivered to the end user.

The Central (Model 3086) end functions as a local ISP which will authenticate the Remote user (Model 3086). The CPE side, with Remote and 3086-A, may represent a home PC which is connecting to a centralized PPP server (Local and 3086—B).

Since this is a routed application, there are differences to be noted. Referring to the application diagram, three unique subnets exist. The Ethernet LAN on the 3086 and Remote side, the Ethernet LAN on the 3086 and Central side, and lastly, the subnet of the ATM's PVC link between the two modems, 3086-A and 3086-B. The 3086-B and Local end (the Central side) may also be a DSLAM.


**Model 3086 (Remote—Client) Configuration Steps (PPPoA Routed)**

1. From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface was called ip1 with an IP address of 192.168.1.1. Change it to an IP address which is in the same subnet as the Desktop PC. For example, to 192.168.100.2. The default IP mask is 255.255.255.0.

→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0



Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on G.SHDSL in the Configuration Menu > Configuration > verify that Terminal Type is *Central* and Interface Type is *atm*. If changed, then click on **Configure**.

Click on Action > Select deactivate for Action > Click on the **Action** button.

2. On the Menu, go to Configuration, then to WAN Connections


Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoA Routed** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *PPPoA Routed*. Change the configuration parameters to match the following.

- Description:PPPoA Routed
- VPI:0
- VCI:800
- WAN IP Address:0.0.0.0
- LLC Header Mode:off
- HDLC Header Mode:off
- CHAP
- User Name:fred
- Password:fredspass

Click on **Configure**.




3. In the Configuration Menu, click on Configuration then > WAN Connections > Edit (for the WAN Service ppp1) > Edit 'PPP' and verify or change the following parameters on the Edit PPP webpage.

- Server:false
- Create Route:true
- Specific Route:false
- Subnet Mask:0.0.0.0
- Route Mask:0.0.0.0
- Hdlc:false
- LLC:false
- Lcp Max Configure:10
- Lcp Max Failure:5
- Lcp Max Terminate:2
- Dialin Auth:none
- Dialout Username:fred
- Dialout Password:fredspass
- Confirmation Password:fredspass
- Dialout Auth:chap
- Interface ID:1
- Remote IP:192.168.164.2
- Local IP:0.0.0.0
- Magic Number:0
- MRU:0
- IP Addr from IPCP:true

- Discover Primary DNS:true
- Discover Secondary DNS:true
- Give DNS to Relay:true
- Give DNS to Client:true
- Remote DNS:0.0.0.0
- Remote Secondary:0.0.0.0
- LCP Echo Every:10
- Auto Connect:false
- Idle Timeout:0
- Termination:true

Click on **Change** button.



4. Click on Edit 'ATM Channel.'

Verify the Options to match the following. (Change if necessary.)

- Tx Vci:800
- Tx Vpi:0
- Rx Vci:800
- Rx Vpi:0
- Peak Cell Rate:2000
- Burst Tolerance:0
- MCR:0
- MBS:0
- Sustainable Cell Rate:0

- Class:UBR

- Port:atm

Click on the **Change** button if changes were made.

5. Click on Edit 'IP Interface.'

Verify or change if necessary the following Options parameters.

- Ipaddr:0.0.0.0

- Mask:0.0.0.0

- Dhcp:false

- MTU:1500

- Enabled:true

Click on the **Change** button if changes were made.

6. There is no gateway created in the IP routes submenu. Upon connecting, the server will provide this information while setting up the PPP connection.

7. Go to G.SHDSL in the Configuration Menu, then the submenu Status. The Modem State should be "deactivated." (If not, go to the Action and change it to deactivate.)

Then in the Action submenu under G.SHDSL, change Action to Start, then click on **Action**.


Model 3086 (Central—Server) Configuration Steps (PPPoA Routed)

1. From the command line interface (CLI) via the RS-232 control port,

→ ip list interfaces

One IP interface was called ip1 with an IP address of 192.168.1.1 Change it to an IP address which is in the same subnet as the Desktop PC. For example, to 192.168.172.3. The default IP mask is 255.255.255.0.

→ ip set interface ip1 ipaddress 192.168.172.3 255.255.255.0



Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.

Click on G.SHDSL in the Configuration Menu> Configuration > verify that Terminal Type is *Central* and Interface Type is *atm*. If changed, then click on **Configure**.

G.SHDSL Attributes:

Circuit ID	Circuit ID ==30Byte Maxim
Clear Error Counters	Normal
Intended DSL Data Rate	36
Actual DSL Data Rate (kbps)	2312
DSL Rate: Number of i Bit	0
Terminal Type	Central
Interface Type	hdlc
PCM Mode	Ethernet Only
Clocking Options	Internal
PCM Transmit Clock Polarity	Normal
PCM Receive Clock Polarity	Normal
Loopback	Off
Annex Type	Annex A
Remote Circuit ID	
<input type="button" value="Configure"/>	
Action	

Click on Action > Select deactivate for Action > Click on the **Action** button.

G.SHDSL Actions:

Action	Deactivate
<input type="button" value="Action"/>	

- On the Menu, go to Configuration, then to WAN Connections

Delete both default WAN services already defined.

Click on **Create a new service** in the main window, select **PPPoA Routed** and click on the **Configure** button.

WAN connection: create service

Please select the type of service you wish to create:

ATM: ☐ RFC 1483 routed ☐ RFC 1483 bridged
☒ PPPoA routed ☐ PPPoA bridged
☐ IPoA routed ☐ PPPoE routed
 HDLC: ☐ PPPoH routed ☐ PPPoH bridged

In the Description field, enter the description you wish. In this example, it is called *PPPoA Routed*. Change the configuration parameters to match the following.

- Description: PPPoA Routed
- VPI: 0
- VCI: 800
- WAN IP Address: 192.168.164.2
- LLC Header Mode: off
- HDLC Header Mode: off

Note The following items are for dial-out service only, for when a remote is establishing a connection with a server.

- CHAP
- User Name: [leave blank]
- Password: [leave blank]

WAN connection: PPPoA routed

Description:

VPI:

VCI:

WAN IP address:

LLC header mode:


HDLC header mode:

☒ No authentication
☐ PAP
☐ CHAP

User name:

Password:

Click on **Configure**.



3. In the Configuration Menu, click on Configuration then > WAN Connections > Edit (for the WAN Service ppp1) > Edit 'PPP' and verify or change the following parameters on the Edit PPP webpage.

Parameters in *red italics* are those requiring changes from the default configuration.


- Server: *true*
- Create Route: true
- Specific Route: false
- Subnet Mask: 0.0.0.0
- Route Mask: 0.0.0.0
- Hdlc: false
- LLC: false
- Lcp Max Configure: 10
- Lcp Max Failure: 5
- Lcp Max Terminate: 2
- Dialin Auth: *pap*
- Dialout Username: [blank]
- Dialout Password: [blank]
- Confirmation Password: [blank]
- Dialout Auth: none
- Interface ID: 2
- Remote IP: *192.168.164.3*
- Local IP: 192.168.164.2
- Magic Number: 0
- MRU: 0

- IP Addr from IPCP: true
- Discover Primary DNS: *false*
- Discover Secondary DNS: *false*
- Give DNS to Relay: false
- Give DNS to Client: false
- Remote DNS: 0.0.0.0
- Remote Secondary: 0.0.0.0
- LCP Echo Every: 10
- Auto Connect: false
- Idle Timeout: 0
- Termination: true

Edit PPP

Name	Value
Server:	<input type="checkbox"/>
Create Route:	<input type="checkbox"/>
Specific Route:	<input type="checkbox"/>
Subnet Mask:	<input type="text"/>
Route Mask:	<input type="text"/>
Hdlc:	<input type="checkbox"/>
LLC:	<input type="checkbox"/>
Lcp Max Configure:	<input type="text"/>
Lcp Max Failure:	<input type="text"/>
Lcp Max Terminate:	<input type="text"/>
Dialin Auth:	<input type="text"/>
Dialout Username:	<input type="text"/>
Dialout Password:	<input type="text"/>
Confirmation Password:	<input type="text"/>
Dialout Auth:	<input type="text"/>
Interface ID:	<input type="text"/>
Remote Ip:	<input type="text"/>
Local Ip:	<input type="text"/>
Magic Number:	<input type="text"/>
MRU:	<input type="text"/>
Ip Addr From IPCP:	<input type="checkbox"/>
Discover Primary DNS:	<input type="checkbox"/>
Discover Secondary DNS:	<input type="checkbox"/>
Give DNSto Relay:	<input type="checkbox"/>
Give DNSto Client:	<input type="checkbox"/>
Remote DNS:	<input type="text"/>
Remote Secondary DNS:	<input type="text"/>
Lcp Echo Every:	<input type="text"/>
Auto Connect:	<input type="checkbox"/>
Idle Timeout:	<input type="text"/>
Enabled:	<input type="checkbox"/>
Termination:	<input type="text"/>

Click on **Change** button.



4. Click on Edit 'ATM Channel.'

Verify the Options to match the following. (Change if necessary.)

- Tx Vci:800
- Tx Vpi:0
- Rx Vci:800
- Rx Vpi:0
- Peak Cell Rate:2000
- Burst Tolerance:0
- MCR:0
- MBS:0
- Sustainable Cell Rate:0
- Class:UBR
- Port:atm


Options	
Name	Value
Tx Vci:	800
Tx Vpi:	0
Rx Vci:	800
Rx Vpi:	0
Peak Cell Rate:	2000
Burst Tolerance:	0
MCR:	0
MBS:	0
Sustainable Cell Rate:	0
Class:	UBR
Port:	atm
<input type="button" value="Change"/> <input type="button" value="Reset"/>	

Click on the Change button if changes were made.

5. Click on Edit 'IP Interface.'

Verify or change if necessary the following Options parameters.

- Ipaddr:192.168.164.2
- Mask:255.255.255.0
- Dhcp:false
- MTU:1500
- Enabled:true




Name	Value
Ipaddr:	192.168.164.2
Mask:	255.255.255.0
Dhcp:	false
MTU:	1500
Enabled:	true
Layer2Session:	

Change Reset

Click on the Change button if changes were made.

6. Again, **Configuration Menu > Configuration > IP Routes > Click on Create new Ip V4 Route > Create** the gateway to the remote 3086 by changing or verifying the following parameters in the webpage Edit—Advanced Settings.

- Destination:0.0.0.0
- Gateway:192.168.164.3
- Mask:0.0.0.0
- Cost:1
- Interface:[blank]



Name	Value
Destination	0.0.0.0
Gateway	192.168.164.3
Netmask	0.0.0.0
Cost	1
Interface	

OK Reset Cancel

7. From the Configuration Menu, click on Configuration > Authentication > Create a new user > enter the information for the following parameters in the webpage Details for the new user. One of these authentication records is created for each remote end user connecting to the Server.

- Username:fred
- Password:fredspass
- May dialin:true
- Comments: [may leave blank or enter any comments for this user.]


Click on the **Create** button.

8. Go to G.SHDSL in the Configuration Menu, then the submenu Status. The Modem State should be “deactivated.” (If not, go to the Action and change it to deactivate.)

Then in the Action submenu under G.SHDSL, change Action to Start, then click on **Action**.

IPoA Routed (RFC 1577)

User data in the form of IP packets is encapsulated into AAL-5 PDUs for transport over ATM. The fact that the user data is routed at an IP layer instead of bridged at a MAC layer allows the source and destination to be on different subnets. A notable drawback of IPoA is the lack of authentication and configuration that would be provided by PPP.




Model 3086 (Remote) Configuration Steps (IPoA Routed)

From the command line interface (CLI) via the RS-232 control port,

```
→ ip list interfaces
```

One IP interface was called ip1 with an IP address of 192.168.1.1 Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.100.2. The default IP mask is 255.255.255.0.

```
→ ip set interface ip1 ipaddress 192.168.100.2 255.255.255.0
```



1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to Configuration, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **IPoA_Routed** and click on the **Configure** button.

WAN connection: create service

Please select the type of service you wish to create:

ATM: ☐ RFC 1483 routed ☐ RFC 1483 bridged

☒ PPPoA routed ☐ PPPoA bridged

☐ IPoA routed ☐ PPPoE routed

HDLC: ☐ PPPoH routed ☐ PPPoH bridged

In the Description field, enter the description you wish. In this example, it is called *IPoA Routed*.

- VPI:0
- VCI:700
- WAN IP address: 192.168.164.2

WAN connection: IPoA routed

Description:


VPI:

VCI:

☐ Use DHCP

☒ WAN IP address:

Click on **Apply**.




3. Returning to the 3086 Configuration Menu, click on Configuration, then IP Routes.
 - Click on “Create new Ip V4 Route.”
 - Destination:0.0.0.0
 - Gateway:192.168.164.3
 - Mask:0.0.0.0
 - Cost:1
 - Interface:[leave blank]

Create Ip V4Route

Name	Value
Destination	0.0.0.0
Gateway	192.168.164.3
Netmask	0.0.0.0
Cost	1
Interface	

Click on **OK**.



4. Go to G.SHDSL in the Configuration Menu, then the submenu Configuration.

Change Terminal Type to **Central** and Interface Type to **atm**. Click on the Configure button.

G.SHDSL Attributes:

Speed Class:	Speed class is 4.6Mbps
Key Feature:	2
Circuit ID	Circuit ID **30Byte Maxi
Clear Error Counters	Do not Clear
Intended DSL Data Rate	2304K
Actual DSL Data Rate (kbps)	1992
Intended Serial Interface Data Rate	Not In Use
DSL Rate: Number of i Bit	0
Terminal Type	Remote
Interface Type	hdlc
PCM Mode	Ethernet Only
Clocking Options	Internal
PCM Transmit Clock Polarity	Normal
PCM Receive Clock Polarity	Normal
Loopback	off
Annex Type	Annex B

In the Action submenu under G.SHDSL, change Action to Deactivate, then click on **Action**.

G.SHDSL Actions:

Return to Action, select Start and click on **Action**.


Model 3086 (Central) Configuration Steps (IPoA Routed)

From the command line interface (CLI) via the RS-232 control port:

→ ip list interfaces

One IP interface was called ip1 with an IP address of 192.168.1.1 Change the IP address so it is in the same subnet as both PCs. For example, to 192.168.172.3. The default IP mask is 255.255.255.0.

→ ip set interface ip1 ipaddress 192.168.172.3 255.255.255.0




1. Now you can bring up the web-page management system on your browser by entering the IP address of the 3086.
2. On the Menu, go to Configuration, then to WAN Connections. Delete the factory default WAN services already defined.

Click on **Create a new service** in the main window, select **IPoA_Routed** and click on the **Configure** button.

In the Description field, enter the description you wish. In this example, it is called *IPoA Routed*.

- VPI:0
- VCI:700
- WAN IP address: 192.168.164.3

Click on **Apply**.




3. Returning to the 3086 Configuration Menu, click on Configuration, then IP Routes.

Click on “Create new Ip V4 Route.”

- Destination:0.0.0.0
- Gateway:192.168.164.2
- Mask:0.0.0.0
- Cost:1
- Interface:[leave blank]

Click on **OK**.



4. Go to G.SHDSL in the Configuration Menu, then the submenu Configuration.

Leave Terminal Type as *Remote*.

Change Interface Type to *hdlc*. Click on the **Configure** button.

In the Action submenu under G.SHDSL, change Action to Deactivate, then click on **Action**.

Return to Action, select Start and click on **Action**.

Chapter 5 **Specialized Configurations**

Chapter contents

IP Configurations	114
Router	114
DHCP Server and Relay	114

IP Configurations

Router

RIP and RIPv2

Name	Value
Accept V1:	true
Accept V2:	false
Send V1:	true
Send V2:	false
Send Multicast:	true

Static Route

1. Click on > Configuration, then > IP Routes on the Configuration Menu.
2. On the main web page entitled “Edit Routes,” click on **Create new Ip V4 Route.**

Name	Value
Destination	192.168.171.24
Gateway	192.168.164.3
Netmask	255.255.255.0
Cost	1
Interface	

3. Enter the destination IP address in the Value field of “Destination.”
4. Enter the IP address of the gateway which is the WAN IP address of the device on the other end of the DSL link in the Value field of “Gateway.”
5. Enter the appropriate netmask in the Value field of “Netmask.”
6. Leave Cost as “1.”
7. “Interface” is an ASCII field which you may leave blank or fill in for your identification.
8. Click **OK**.
9. Add additional static routes using the same procedure.

DHCP Server and Relay

The DHCP Server or Relay are simply configured via the web page management pages.

1. Go to > Configuration Menu > Configuration > DHCP Server and the DHCP Server page is displayed.

At the bottom of the web page are three options for the DHCP Server Mode: Disabled, DHCP server (default), and DHCP Relay Agent.

DHCP server

DHCP server status:

Default Lease Time: 43200

Allow Bootp: true

Max Lease Time: 86400

Allow Unknown Clients: true

Enabled: true

Subnet definitions:

Subnet Value: 192.168.1.0

Subnet Mask: 255.255.255.0

Max Lease Time: 86400

Default Lease Time: 43200

Host Is Dns Server: true

Host Is Default Gateway: true

Subnet From Interface: ip1an

IP range: 192.168.1.2 - 192.168.1.21

DHCP Server Mode

☐ Disabled

☒ DHCP server

☐ DHCP relay agent

- Click on **Configure** on the DHCP Server web page to change the configuration for any of the DHCP parameters.

The three categories of configuration parameters on this web page are the Address Range of the DHCP Server, the Lease Times in seconds, the selection of Domain Name Servers (if desired), and whether to use the router as the default gateway.

DHCP: enable server

DHCP Server Setup

Please enter details for DHCP server configuration:

Address Range

Note that your LAN interface has IP address 192.168.100.2, with subnet mask 255.255.255.0; the IP address range should be within this subnet.

Use Default Range (192.168.100.3 - 192.168.100.22) ☐

Starting IP Address:

Ending IP Address:

Lease Times

Default Lease Time: seconds

Maximum Lease Time: seconds

Domain Name Servers

Use the primary and secondary domain name servers to be provided to LAN clients.

Use Router as DNS Server: ☐

Primary DNS Server Address:

Secondary DNS Server Address:

Default Gateway

Use Router as Default Gateway: ☐

Advanced Options: [0](#)

- Clicking on **Advanced Options** offers additional options for configuration. They are displayed in the following figure.

Name	Value
Default Lease Time:	43200
Allow Bootp:	true
Max Lease Time:	86400
Allow Unknown Clients:	true
Enabled:	true

Change Reset

- The IAD may be used as a DHCP Relay Agent if desired. Go to > Configuration Menu > Configuration > DHCP Server. Select DHCP Relay Agent at the bottom of the web page and click on Configure. The DHCP Relay agent page is displayed.

DHCP: enable relay agent

The DHCP server (or relay) is disabled.

Please enter details for DHCP relay configuration:

DHCP server IP address: 192.167.100.2

Apply

- Enter the DHCP server's IP address and click on **Apply**.

The router is now ready to operate as a DHCP Relay agent.

DNS Client

The DNS client provides a method for retrieving a list of IP addresses for a host name as well as acquiring the host name for a given IP address. The DNS client will cache any results from the name server which reduces network traffic.

- Enter the DNS Servers by entering the IP address in the field next to the Add button.
- Click on **Add**.

More than one DNS Server may be added.

An alternative is to create a domain search list. The DNS Client uses this list when a user asks for the IP address list for an incomplete domain name. There may be up to a maximum of 6 incomplete domain names in the search list.

Enter the domain name and click on **Add** to add it to the list.




The screenshot shows the 'DNS client' configuration page. It has two main sections: 'DNS servers:' and 'Domain search order:'. The 'DNS servers:' section contains a text input field with '192.168.102.20' and a 'Delete' button. Below it is an empty text input field with an 'Add' button. The 'Domain search order:' section contains a text input field with 'universal.com' and a 'Delete' button. Below it is an empty text input field with an 'Add' button.

DNS Relay Mode

In the DNS Relay web page, up to 10 DNS server addresses may be added to utilize the DNS servers already being used by the network.

1. Select **Enabled**.
2. Click on **Configure**.
3. Enter the DNS server address in the field following DNS server IP address:
4. Click on **Apply**.
5. Repeat to add more DNS server addresses, not to exceed the maximum of 10.



The screenshot shows the 'DNS: enable relay' configuration page. It has two main sections: 'DNS Relay Settings' and 'DNS server IP address:'. The 'DNS Relay Settings' section contains a text input field with 'The DNS relay is disabled.' and a 'Delete' button. Below it is an empty text input field with an 'Add' button. The 'DNS server IP address:' section contains a text input field with '192.168.102.3' and an 'Apply' button.

Chapter 6 **Security**

Chapter contents

Introduction	120
Configuring the IAD	120
Configuring the security interfaces.....	121
Deleting a Firewall Policy	122
Enabling the Firewall.....	123
Firewall Portfilters	123
Security Triggers.....	124
Intrusion Detection System (IDS)	126

Introduction

Security provides the ability to setup and enforce security policies. The policies define the types of traffic permitted to pass through a gateway, either inbound, outbound, or both, and from which origins the traffic may be allowed to enter.

Within the security configuration is a stateful firewall. A stateful firewall utilizes a security mechanism to maintain information concerning the packets it receives. This information is used for deciding dynamically whether or not a packet may pass through.

Port filters are rules that determine how a packet should be handled. The rules define the protocol type, the range of source and destination port numbers and an indication whether the packet is allowed or not.

Security triggers are used with applications that require and create separate sessions. The most common example is FTP. An FTP client establishes a connection to a server using port 21, but data transfers are done on a separate connection or port. The port number, and who makes the connection, can vary depending on the FTP client. To allow FTP to work without triggers, you would need to set up port filters allowing the correct port numbers through. This is a significant security risk.

This risk can be avoided by using security triggers. Triggers tell the security mechanism to expect these secondary sessions and how to handle them. Rather than allowing a range of port numbers, triggers handle the situation dynamically, opening the secondary sessions only when appropriate. The triggers work without needing to understand the application protocol or reading the payload of the packet, although this does happen when using NAT.

Triggering allows you to set up a trigger for different application protocols that use multiple sessions. The timeout between sessions and whether or not session chaining are allowed are configurable. Session chaining is not needed for FTP but is for NetMeeting.

See Chapter 7, “NAT (Network Address Translation)” on page 129.

Configuring the IAD

The configuration of security assumes that the 3086/IAD already has a valid IP address for the Ethernet port so that the user may access the modem via the web page. If the IP address is still the factory default, go to the section in Chapter 3 entitled IP Address Quick Start Modification.

In this example the WAN transport between the two 3086/IADs will be IPoA.

1. Click on **WAN Connections** under Configuration on the 3086's Menu.
2. Click on **Create a New Service**.
3. Select **IPoA Routed** and click on the **Configure** button.
4. For this example, enter **IPoA Security Firewall** in the Description field.
5. VPI remains at 0. Change VCI to be 100.
6. Click on **WAN IP address** and enter 192.168.101.1 in the adjacent box. The default IP mask is 255.255.255.0.
7. Click on **Apply**.

The next step in configuring the IAD is adding the default gateway route. Since the WAN IP address of the 3086 modem at the CO site is 192.168.101.2, this will be the gateway for the 3086 modem at the CPE site, the modem we are currently configuring.

1. Click on **IP Routes** under Configuration on the 3086 modem's Menu.
2. Click on **Create a New IP Route**.
3. Enter *192.168.101.2* in the box adjacent to Gateway.
4. Leave Destination and Netmask both as *0.0.0.0* because this is the gateway default route.
5. Click on **Create** and the route will be entered.
6. The default gateway can be verified by clicking on **IP Routes** under Status in the menu.

Configuring the security interfaces

The interfaces and routes have been configured on the 3086 IAD which will function as the firewall. The Ethernet side of the 3086 will be configured to be an internal security interface whereas the WAN side is configured as an external security interface since it is on "public" side of the modem connection.

Security Interface Configuration

Security State

Security: ☒ Enabled ☐ Disabled

Firewall: Disabled

Intrusion Detection Enabled: Disabled

[Change State](#)

Security Level

Security Level: n/a (Enable Firewall to set level)

Security Interfaces

There are currently no interfaces defined. (Interfaces must be defined and Security enabled to configure NAT.)

[Add Interface](#)

Policies, Triggers and Intrusion Detection

[Firewall Policy Configuration](#)

[Firewall Trigger Configuration](#) ("Why can't I configure this?")

[Configure Intrusion Detection](#) ("Why can't I configure this?")

1. Click on **Security** under Configuration on the 3086 modem's menu.
2. Under Security Interfaces, click on **Add Interface**.
3. Select Name of the WAN port (*ipoa-0*) and Interface Type to be *external*. Click on **Apply**.

4. Add one more security interface by repeating step 2.
5. Select Name of the LAN port (*ip1*) and Interface Type to be *internal*. Click on **Apply**.

Now the Firewall policies will be added between the security interfaces. Only one Firewall policy, called *etoi*, is added between the external and internal interfaces.

1. Under Policies, Triggers and Intrusion Devices on the Security page, click on **Firewall Policy Configuration**.
2. In the Current Firewall Policies page, click on **New Policy**.

3. Select the parameters so the policy applies **between interface of types: external internal**.
Also **Validators will block traffic**. This blocks all hosts.
4. Click on **Apply**.

Deleting a Firewall Policy

To delete a Firewall Policy, follow these Command Line Interface (CLI) commands via the Console port.

```
→ firewall list policies
```

Firewall Policies:

ID	Name	Type 1	Type 2	Validator Allow Only
1	item0	external	internal	false

→ firewall delete policy item0

The firewall policy named *item0* is now deleted.

Enabling the Firewall

At this point, both security and the firewall can be enabled and the network is secure. All the interfaces which have been defined are protected: all traffic blocked between the internal and external interfaces.

1. Return to the Security page.
2. Under Security State select **Enabled for Security** and click on **Change State**.
3. Then select **Enabled for the Firewall** and click on **Change State**.

The network is now secure. All the interfaces which have been defined are protected and all traffic is blocked between different the different interface types. That is, all traffic is blocked between the external and internal interfaces.

The next section describes how to configure the Firewall for allowing certain types of data transfer to occur between the PC's on different networks.

Firewall Portfilters

Next, we configure the Firewall to permit certain types of data transfer between the PCs on the different networks. This is done by the implementation of Firewall portfilters. Portfilters are individual rules that determine what kind of traffic can pass between two interface types.

For the Transport Type below, the different types are:

Transport Type	Abbreviation
1	ICMP
2	IGMP
3	GGP
4	IP
6	TCP
8	EGP
9	IGP
17	UDP
46	RSVP
47	GRE
89	OSPF/IGP
92	MTP

Transport Type	Abbreviation
94	IPIP

To allow pings between the two PCs:

1. From the Configuration Menu, > Configuration > Security > Firewall Policy Configuration > Port Filters > Add Raw IP Filter
2. Enter *1* (for ICMP) in Transport Type.
3. Both Inbound and Outbound should be allowed.
4. Click on **Apply**.

Transport Type	Direction
1	Allow
	Allow

Apply

You can now ping between the two networks

Security Triggers

Security triggers are used to allow an application to open a secondary port in order to transport data. The most common example is FTP. This procedure is to set up a trigger on the Firewall to have an FTP session from PC A to PC B, but not the reverse.

1. First, create an outbound-only portfilter for FTP and add it to the item0 policy.
2. Following the path given in step 1 for the ping portfilter, click on **Add TCP Filter**.
3. The Port Range is entered as *21* for both Start and End.
4. Set Inbound as **Block**, but Outbound as **Allow**.
5. Click on **Apply**.

Transport Type	Port Range	Direction
TCP	21	Block
	21	Allow

Apply

After configuring the FTP portfilter, you can open an ftp session from Remote to Local, however you can issue ftp commands (e.g., login, cd, etc.) but transfer data (e.g., ls, dir, get, put commands). The portfilter allows an ftp control channel but does not allow the use of a secondary data channel for passing data by ftp.

To enable the ftp data channel, add a trigger which will open a secondary channel only when data is being passed. This prevents the need to open too many ports which offer a security risk.

1. From the Configuration Menu, > Configuration > Security > Firewall Trigger Configuration > New Trigger.
2. Set the parameters as follows:
 - Transport Type = tcp
 - Port Number Start = 21
 - Port Number End = 21
 - Allow Multiple Hosts = Block
 - Max Activity Interval = 3000
 - Enable Session Chaining = Block
 - Enable UDP Session Chaining = Block
 - Binary Address Replacement = Block
 - Address Translation Type = none
3. Click on **Apply**.

Transport Type	Port Number Start	Port Number End	Allow Multiple Hosts	Max Activity Interval	Enable Session Chaining	Enable UDP Session Chaining	Binary Address Replacement	Address Translation Type
tcp	21	21	Block	3000	Block	Block	Block	none

Apply

You should now be able to use ftp commands to pass data between Remote and Local.

Intrusion Detection System (IDS)

The security feature in the 3086 IAD provides protection from a number of attacks. Some attacks cause a host to be blacklisted (i.e., no traffic from that host is accepted under any circumstances) for a period of time. Other attacks are simply logged. The subsequent table is a summary of the attacks detected.

Attack Name	Protocol	Attacking Host Blacklisted?
Ascend Kill	UDP	yes
Echo/Chargen	UDP	no
Echo Scan	UDP	yes
WinNuke	TCP	yes
Xmas Tree Scan	TCP	yes
IMAP SYN/FIN Scan	TCP	yes
Smurf	ICMP	If victim protection set
SYN/FIN/RST Flood	TCP	If scanning threshold exceeded
Net Bus Scan	TCP	yes
Back Orifice Scan	UDP	yes

1. To enable IDS, click on Enabled for “Intrusion Detection Enabled” on the “Security Interface Configuration” page. Then click on **Change State(s)**.
2. Click on **Configure Intrusion Detection**.
3. You may choose which of the parameters to configure and for which value.

- Use Blacklist:Default = 10 minutes when enabled.

If IDS has detected an intrusion an external host, access to the network is denied for ten minutes.

- Use Victim Protection:Default = Disabled.

Enables Victim Protection. Victim Protection protects the victim from an attempted spoofing attack. Web spoofing allows an attacker to create a ‘shadow’ copy of the world wide web (WWW). All access to the shadow Web goes through the attacker’s machine, so the attacker can monitor all of the victim’s activities and send false data to or from the victim’s machine. When enabled, packets destined for the victim host of a spoofing style attack are blocked.

- DOS Attack Block Duration:Default = 1800 seconds (30 minutes).

A Denial of Service (DOS) attack is an attempt by an attacker to prevent legitimate users from using a service. If a DOS attack is detected, all suspicious hosts are blocked by the firewall for a set time limit

- Scan Attack Block Duration:Default = 86400 seconds

Sets the duration for blocking all suspicious hosts. The firewall detects when the system is being scanned by a suspicious host attempting to identify any open ports.

- Victim Protection Block Duration:Default = 600 seconds (10 minutes).

Sets the duration of the block in seconds.

- Maximum TCP Open Handshaking Count:Default = 100

Sets the maximum number of unfinished TCP handshaking sessions per second that are allowed by a firewall before a SYN Flood is detected. SYN Flood is a DOS attack. When establishing normal TCP connections, three packets are exchanged: (1) A SYN (synchronize) packet is sent from the host to the network server. (2) A SYN/ACK packet is sent from the network server to the host. (3) An Ack (acknowledge) packet is sent from the host to the network server. If the host sends unreachable source addresses in the SYN packet, the server sends the SYN/ACK packets to the unreachable addresses and keeps resending them. This creates a backlog queue of unacknowledged SYN/ACK packets. Once the queue is full, the system will ignore all incoming SYN request and no legitimate TCP connections can be established.

- Once the maximum number of unfinished TCP handshaking sessions is reached, an attempted DOS attack is detected. The firewall blocks the suspected attacker for the time limit specified in the DOS Attack Block Duration parameter.
- Maximum Ping Count:Default = 15

Sets the maximum number of pings per second that are allowed by the firewall before an Echo Storm is detected. Echo Storm is a DOS attack. An attacker sends oversized ICMP datagrams to the system using the 'ping' command. This can cause the system to crash, freeze, or reboot, resulting in denial of service to legitimate users.

- Maximum ICMP Count:Default = 100

Sets the maximum number of ICMP packets per second that are allowed by the firewall before an ICMP Flood is detected. An ICMP Flood is a DOS attack. The attacker tries to flood the network with ICMP packets in order to prevent transmission of legitimate network traffic.

4. After selecting the chosen parameters, click on **Apply**.

Chapter 7 **NAT (Network Address Translation)**

Chapter contents

Introduction	130
Enabling NAT	130
Global address pool and reserved map	131

Introduction

The basic steps for configuring NAT are:

1. Enable NAT between the internal and external interfaces of the firewall.
2. Create global addresses which will be added to the global pool of IP addresses on the WAN interface.
3. Create a reserved mapping between a global IP address and the IP address of an internal PC.

A Global Address Pool is a pool of addresses seen from the outside network. Each external interface creates a Global Address Pool with a single address—the address assigned to that interface. For outbound sessions, an address is picked from a pool by hashing the source IP address for a pool index and then hashing again for an address index. For inbound sessions, it is necessary to create a reserved mapping.


A reserved mapping is used so that NAT knows where to route packets on inbound sessions. The reserved mapping will map a specific global address and port to an inside address and port. Reserved mappings can also be used so that different inside hosts can share a global address by mapping different ports to different hosts. For example, Host A is an FTP server and Host B is a web server. By mapping the FTP port to Host A and the HTTP port to Host B, both inside hosts can share the same global address. Setting the protocol number to 255 (0xFF) means that the mapping will apply to all protocols. *Setting the port number to 65535 (0xFFFF) for TCP or UDP protocols means that the mapping will apply to all port numbers for that protocol.*

Some applications embed address and/or port information in the payload of the packet. The most notorious of these is FTP. For most applications, it is sufficient to create a trigger with address replacement enabled. However there are three applications for which a specific ALF is provided: FTP, NetBIOS, and DNS.

Enabling NAT

The configuration of NAT in this example follows on the preceding configuration completed in the chapter, “Security.”

1. Go to the “Security Interface Configuration” page by clicking on **Security** under Configuration in the menu.
2. Click on **Enable NAT to internal interfaces** in the table, Security Interfaces. NAT is now enabled between the internal (LAN) and the external (WAN) interfaces of the firewall.



Security Interface Configuration

Security State

Security: ☒ Enabled ☐ Disabled

Firewall: ☒ Enabled ☐ Disabled

Intrusion Detection Enabled: ☐ Enabled ☒ Disabled

[Change State](#)

Security Level


Security Level: [Change Level](#)

Security Interfaces

Name	Type	NAT	
ip1	internal	May be configured on external or DMZ interfaces	Delete Interface: 0
ipoa-0	external	Disable NAT to internal interfaces Advanced NAT Configuration 0	Delete Interface: 0

Global address pool and reserved map

1. Click on **Advanced NAT Configuration...** on the web page, “Security Interface Configuration.”



Firewall Add Global Address Pool: ipoa-0

Add Global Address Pool

Interface Type	Use Subnet Configuration	IP Address	Subnet Mask/IP Address 2
<input type="text" value="internal"/>	<input type="text" value="Use IP Address Range"/>	<input type="text" value="100.100.100.101"/>	<input type="text" value="100.100.100.102"/>

[Add Global Address Pool](#)

2. Click on the hyperlink **Add Global Address Pool**. The global IP addresses need to be created and put into the Global Address Pool.
3. Set the parameters to the following values:
 - Interface Type: internal
 - Use Subnet Configuration: Use IP Address Range
 - IP Address: 100.100.100.101
 - Subnet Mask/IP Address 2: 100.100.100.102

Click on **Add Global Address Pool**.

4. Next, create a reserved mapping between a global IP address from the global pool and an internal PC's IP address (in this example, 10.1.1.2)
5. Click on **Add Reserved Mapping...**

Firewall Add Reserved Mapping: ipoa-0

Add Reserved Mapping

Global IP Address	Internal IP Address	Transport Type	Port Number
100.100.100.101 <small>(Set to 0.0.0.0 to use the primary IP address of the interface "ipoa-0")</small>	10.1.1.2	all	65535

Add Reserved Mapping

6. Set the parameters to the following values:

- Global IP Address:100.100.100.101
- Internal IP address:10.1.1.2
- Transport Type:all
- Port Number:65535(This port number means all port numbers for TCP or UDP protocols will be mapped.)

7. Click on **Add Reserved Mapping**.

Chapter 8

Monitoring Status

Chapter contents

Status LEDs.....134

Status LEDs

The LEDs indicate the status of the Power, the WAN (DSL) inter-modem link, Sync Serial or T1/E1 port, the Ethernet connection, and Status.

All LED indicators will present the same looking profile (e.g., clear) when unlit due to being single color, water clear, high efficiency LEDs.

Table 9. Status LED descriptions

Power		Green	ON indicates that power is applied. Off indicates that no power is applied.
WAN (DSL)	Link	Green	Solid green: connected Off: disconnected
Sync Serial	TD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
	RD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
	CTS	Green	ON: indicates the CTS signal from the IAD is active, binary '1' off: indicates CTS is binary '0'
	DTR	Green	ON: indicates the DTR signal from the DTE device attached to the serial port is active, binary '1'
T1/E1	Link	Green	On: indicates the T1/E1 interface is connected to a live T1/E1 line
	LOS	Red	On: indicates the T1/E1 interface is not connected to an active T1/E1 line
	TD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
	RD	Green	Green: indicates a binary '0' condition off: indicates a binary '1' or idle condition
Ethernet	Link	Green	ON: indicates an active 10/100 BaseT connection
	100M	Green	ON: connected to a 100BaseT LAN Off: connected to a 10BaseT LAN
	Tx	Green	Flashing: when transmitting data from the IAD to the Ethernet
	Rx	Green	Flashing: when transmitting data from the Ethernet to the IAD.
Status	NS	Red	ON: indicates absence of a valid DSL connection
	ER	Red	flashes once: indicates bit errors occurring during 511/511E tests
	TM	Yellow	ON: is under one of the test modes (local loop, remote loop, or V.54 BER pattern)

Chapter 9 **Diagnostics**

Chapter contents

Introduction	136
Ping.....	136
Software Upgrades.....	136
Configuration	136
Procedure	136
Operating Local Analog Loopback (LAL)—Serial Port Loop.....	137
Operating Remote Digital Loopback (RDL)—DSL Loop	137
T1/E1 Diagnostics.....	138
Network Loop	138
T1/E1 Local Loop	139
QRSS—BIT Error Rate Diagnostics	140
T1/E1 connection Status	141
Alarms	141
Transceiver Status.	141
FDL statistics (T1 only)	141
E1/T1 DS0 Monitor	141
BIT Error Rate (V.52) Diagnostics.....	142

Introduction

The Model 3086 offers three sets of diagnostics: Local Analog Loopback (serial port loop), Remote Digital Loopback (DSL loop), and T1/E1 Loops for the Model 3086/K. Some tests can be activated physically from the front panel, or via the CLI/Web management menus

Ping

The ping command is executed from the Command Line Interface (CLI). Ping in the 3086 is executed from the “ip” command. Here is the ping format followed by a valid response.

```
ip ping 192.168.100.11
ping: PING 192.168.100.11: 32 data bytes
ping: 40 bytes from 192.168.100.11: seq=0, ttl=128, rtt<10ms
```

→

Software Upgrades

Software upgrades are required in two scenarios. First, for new features. Second, for standard software upgrades (at an additional cost).

For standard software upgrades, which are at no charge, contact **upgrades.patton.com** for the location of the new firmware and follow these instructions.

1. Get the firmware image from Patton and save on your PC. It is a .tar file and MUST NOT be unzipped!
2. Login to the 3086's web page on the browser.
3. Click on > System, then > Upgrade
4. Locate the firmware image on this web page.
5. Click on Upgrade.
6. Wait until the upgrading is complete, and then restart the 3086.
7. It is now ready to use with the new firmware.

If you encounter problems with the firmware upgrade, do the following to upload software image into the Patton 3086 via TFTP. .

Note The Patton 3086 products have a TFTP server built-in, a TFTP client will be require on the user side to connect to the TFTP server

Configuration

The Patton products are configured as a TFTP server with the default IP address 192.168.200.10.

Procedure

1. Go to Upgrade.patton.com and download the software upload package. The package contains the following files:
 - Tftplock.key
 - Tftpupdt.beg
 - Image

- Npimage
 - Key
 - Initbun
 - Im.conf
 - Tftpupdt.rbt
 - Tftpupdt.end
 - Script.bat
2. Connect the control (console) port of the unit to a PC.
 3. Connect the Ethernet port to the appropriate device where the upload package will be stored.
 4. On a Window 2000 or WinXP machine, open a Command Prompt and run the script. (The script will connect to the default 192.168.200.10 IP address). If using Win9x, a TFTP client will be needed.
 5. The TFTP process takes about 90 seconds, the unit will reboot automatically when done.

Operating Local Analog Loopback (LAL)—Serial Port Loop

The Local Line Loopback (LAL) applies to serial port data traffic, it does not affect traffic from the Ethernet port. The local Loop test checks the operation of the local Model 3086, and is performed separately on each unit. Any data sent to the local Model 3086 in this test mode will be echoed (returned) to the user device (i.e., characters typed on the key-board of a terminal will appear on the terminal screen).




Figure 12. Local Line Loop

To perform a Local Analog Loopback test, follow these steps:

1. Move the front panel toggle switch UP to *Local*.
2. Verify that the data terminal equipment is operating properly and can be used for a test.
3. Perform a V.52 BER (bit error rate) test as described in section “BIT Error Rate (V.52) Diagnostics” If the BER test equipment indicates no faults, but the data terminal indicates a fault, follow the manufacturer’s checkout procedure for the data terminal. Also check the interface cable between the terminal and the Model 3086.

Operating Remote Digital Loopback (RDL)—DSL Loop

The Remote Digital Loopback (RDL) test checks the performance of both the local and remote Model 3086s, as well as the communication link between them. Any characters originating at the serial port and sent to the remote Model 3086 in the test mode will be returned to the originating device (i.e., characters typed on the

keyboard of the local terminal will appear on the local terminal screen after having been passed to the remote Model 3086 and looped back). See Figure 13.




Figure 13. Remote Digital Loop

To perform an RDL test, follow these steps:

1. Activate the RDL by moving the front panel toggle switch DOWN to remote.
2. Perform a bit error test (BERT) using the internal V.52 generator (as described in section “BIT Error Rate (V.52) Diagnostics” on page 142), or using a separate BER Tester. If the BER test indicates a fault, and the Local Line Loopback test was successful for both Model 3086s, you may have a problem with the twisted pair line between the modems. You should then check the twisted pair line for proper connections and continuity.

T1/E1 Diagnostics

The 3086/K offers two diagnostics loops for the T1/E1 interface: Network (line) loopback, and local loop. These tests can be activated via the CLI/Web management menus

Network Loop

The Network (line) Loopback applies to the T1/E1 interface data traffic; it does not affect traffic from the Ethernet port. The network Loop test verifies the operation of the T1/E1 interface of the local unit and the T1/E1 line. Any data received by the 3086 T1/E1 interface in this test mode will be echoed (returned) to the originating device. This test is useful when the device connected to the 3086's T1/E1 interface is unable to send loop codes to the local 3086's T1/E1 CSU/DSU interface.





Figure 14. 3086 Line Loop

To set the 3086 T1/E1 port in Network Loopback test, do the following:

1. Go to the 3086 Main page, select *E1/T1*. Next, click on *Test Modes*, select *network Loop* using the drop down menu, click on the **Activate Test Mode** button.
2. Perform a BER (bit error rate) test. Replace the Local T1/E1 equipment (PBX) with a T1/E1 tester, and initiate a BER test to verify integrity of the cable and operation of the 3086's T1 interface.



T1/E1 Local Loop

When set to local loop, the 3086/K loops DSL timeslots assigned to carry T1/E1 data to far end 3086 or 3096RC T-DACS.




Figure 15. 3086/K T1/E1 local loop

To set the 3086 in T1/E1 local loop test, follow these steps:

1. Go to the 3086 Main page, select *E1/T1*. Next, click on *Test Modes*, select local Loop using the drop down menu, click on the **Activate Test Mode** button.
2. Perform a BER (bit error rate) test. This test can be initiated from the far end using a T1/E1 BER tester to verify the T1/E1 path over the DSL line and 3086s involved.

QRSS—BIT Error Rate Diagnostics

The 3086/K offers a Bit Error Rate (BER) QRSS test pattern. This test pattern may to be used to test the communication link and the T1/E1 interface of the device attached to the 3086. When a QRSS test is invoked, the 3086 generates a pseudo-random pattern using a mathematical polynomial. The pattern is sent over the T1/E1 interface to the far end device and looped to the 3086 (originator), the far end device i.e. PBX or routers's T1/E1 port must be set to line loop. The local 3086 decodes the received bits using the same polynomial. If the received bits match the agreed upon pseudo-random pattern, then the 3086 and the communication link are functioning properly. The 3086 can also initiate a built-in QRSS pattern with errors. This test pattern generator injects intentional errors approximately once per second in the transmitted stream.

To perform a BER test, follow these steps:

1. From the Main page T1/E1 option, select the QRSS or QRSS Errs option, and then click on the Activate Test Mode button. This will start the internal test pattern generator for data sent and looped at the far end device.
2. Monitor the BER test results. The Test Mode Status window will display the number of bit errors, if any, detected in the received stream.

Note The above BER tests will not work if the 3086's T1/E1 interface has been placed in Network loop.

Patton Home Page

CONFIGURATION MENU

- Home
- Status
- Quick Start
- System
- Configuration
- E1/T1
 - Status
 - Test Modes
 - DSO Monitor
 - Configuration

E1/T1 Status:

Alarms

Detailed Error List

Red Alarm	n/a	Carrier Loss	inactive
Yellow Alarm	inactive	Sync Loss	inactive
Blue Alarm	inactive		
Remote Alarm	inactive		

Reset Data Path

Transceiver Status

Search FAS	found	Frame Sync Errs	0
Search CRC	n/a	Line Code Errs	0
Search CAS	n/a	Path Code Errs	0

FDL Statistics

Near End Line Statistics

Current History Total

T1/E1 connection Status

The 3086 E1/T1 status page displays a number of alarms conditions, Transceiver status, and statistics. The information displayed in this page is of use for monitoring and troubleshooting network problems when the 3086 T1/E1 interface is connected directly to a Telco network

Alarms

The status page shows condition and alarm for the following:

Red Alarm, Yellow alarm, Blue Alarm, Remote Alarm, carrier loss, and Sync Loss.

Transceiver Status.

This section displays status for the following:

Search FAS, Search CRC, Search CAS, Frame Sync errors, Line Code errors, and Path Code errors

FDL statistics (T1 only)

The FDL section provides statistics on T1 link performance, this include Current and historical near end line statistics.

E1/T1 DSO Monitor

The DSO monitor page allows monitoring of a particular timeslot in the E1/T1 stream. To enable this feature, click on the *DSO Monitor* link under the E1/T1 menu, and select the desired receive and transmit timeslot.

BIT Error Rate (V.52) Diagnostics

The Model 3086 offers a V.52 Bit Error Rate (BER) 511 test pattern. This test pattern may be invoked along with the LAL and RDL tests to evaluate the unit(s) and the DSL communication links. When a 511 test is invoked, the 3086 generates a pseudo-random pattern of 511 bits using a mathematical polynomial. The receiving Model 3086 then decodes the received bits using the same polynomial.

If the received bits match the agreed upon pseudo-random pattern, then the 3086(s) and the communication link(s) are functioning properly. 511 Initiates a built-in 511 bit pseudo-random pattern generator and detector. 511 with Errors Initiates a built-in 511 bit pseudo-random pattern generator and detector. The test pattern generator also injects intentional errors approximately once per second, causing the Error LED to blink.

To perform a V.52 BER test, follow these steps:

1. Locate the toggle switch group on the right side on the front panel and place it in the middle where it is marked "Normal". This activates the V.52 transmission and reception of the selected test pattern. If there are errors in the received pattern, the error LED will blink accordingly.
2. If the above test indicates no errors are present, move the toggle switch UP to 511/E, activating the BER test with intentional errors. If the test light is working properly, the local modem's red error LED will blink approximately once per second.

Note The above V.52 BER tests can be used independently of the Remote Digital Loopback tests.

Chapter 10 **Contacting Patton for assistance**

Chapter contents

Introduction	144
Contact information	144
Warranty Service and Returned Merchandise Authorizations (RMAs)	144
Warranty coverage	144
Out-of-warranty service	144
Returns for credit	144
Return for credit policy	145
RMA numbers	145
Shipping instructions	145

Introduction

This chapter contains the following information:

- “Contact information”—describes how to contact PATTON technical support for assistance.
- “Warranty Service and Returned Merchandise Authorizations (RMAs)”—contains information about the RAS warranty and obtaining a return merchandise authorization (RMA).

Contact information

Patton Electronics offers a wide array of free technical services. If you have questions about any of our other products we recommend you begin your search for answers by using our technical knowledge base. Here, we have gathered together many of the more commonly asked questions and compiled them into a searchable database to help you quickly solve your problems.

- Online support—available at www.patton.com.
- E-mail support—e-mail sent to support@patton.com will be answered within 1 business day
- Telephone support—standard telephone support is available 5 days a week, from 8:00am to 5:00pm EST by calling +1 (301) 975-1007

Warranty Service and Returned Merchandise Authorizations (RMAs)

Patton Electronics is an ISO-9001 certified manufacturer and our products are carefully tested before shipment. All of our products are backed by a comprehensive warranty program.

Note If you purchased your equipment from a Patton Electronics reseller, ask your reseller how you should proceed with warranty service. It is often more convenient for you to work with your local reseller to obtain a replacement. Patton services our products no matter how you acquired them.

Warranty coverage

Our products are under warranty to be free from defects, and we will, at our option, repair or replace the product should it fail within one year from the first date of shipment. Our warranty is limited to defects in workmanship or materials, and does not cover customer damage, lightning or power surge damage, abuse, or unauthorized modification.

Out-of-warranty service

Patton services what we sell, no matter how you acquired it, including malfunctioning products that are no longer under warranty. Our products have a flat fee for repairs. Units damaged by lightning or other catastrophes may require replacement.

Returns for credit

Customer satisfaction is important to us, therefore any product may be returned with authorization within 30 days from the shipment date for a full credit of the purchase price. If you have ordered the wrong equipment or you are dissatisfied in any way, please contact us to request an RMA number to accept your return. Patton is not responsible for equipment returned without a Return Authorization.

Return for credit policy

- Less than 30 days: No Charge. Your credit will be issued upon receipt and inspection of the equipment.
- 30 to 60 days: We will add a 20% restocking charge (crediting your account with 80% of the purchase price).
- Over 60 days: Products will be accepted for repairs only.

RMA numbers

RMA numbers are required for all product returns. You can obtain an RMA by doing one of the following:

- Completing a request on the RMA Request page in the *Support* section at www.patton.com
- By calling +1 (301) 975-1000 and speaking to a Technical Support Engineer
- By sending an e-mail to returns@patton.com

All returned units must have the RMA number clearly visible on the outside of the shipping container. Please use the original packing material that the device came in or pack the unit securely to avoid damage during shipping.

Shipping instructions

The RMA number should be clearly visible on the address label. Our shipping address is as follows:

Patton Electronics Company

RMA#: xxxx

7622 Rickenbacker Dr.

Gaithersburg, MD 20879-4773 USA

Patton will ship the equipment back to you in the same manner you ship it to us. Patton will pay the return shipping costs.

Appendix A **Compliance information**

Chapter contents

- Compliance148
 - EMC148
 - Safety148
 - PSTN Regulatory148
- Radio and TV Interference (FCC Part 15)148
- CE Declaration of Conformity148
- Authorized European Representative149
- FCC Part 68 (ACTA) Statement149
- Industry Canada Notice149

Compliance

EMC

- FCC Part 15, Class A
- EN55022, Class A
- EN55024

Safety

- UL60950-1/CSA C22.2 No. 60950-1
- IEC/EN 60950-1
- AS/NZS 60950-1

PSTN Regulatory

- FCC Part 68
- CS-03
- AS/ACIF S043

Radio and TV Interference (FCC Part 15)

This equipment generates and uses radio frequency energy, and if not installed and used properly—that is, in strict accordance with the manufacturer's instructions—may cause interference to radio and television reception. This equipment has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection from such interference in a commercial installation. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by disconnecting the cables, try to correct the interference by one or more of the following measures: moving the computing equipment away from the receiver, re-orienting the receiving antenna, and/or plugging the receiving equipment into a different AC outlet (such that the computing equipment and receiver are on different branches).

CE Declaration of Conformity

We certify that the apparatus identified in this document conforms to the requirements of Council Directive 1999/5/EC on the approximation of the laws of the member states relating to Radio and Telecommunication Terminal Equipment and the mutual recognition of their conformity.

The safety advice in the documentation accompanying this product shall be obeyed. The conformity to the above directive is indicated by the CE sign on the device.

Authorized European Representative

D R M Green

European Compliance Services Limited.

Avalon House, Marcham Road

Abingdon,

Oxon OX14 1UD, UK

FCC Part 68 (ACTA) Statement

This equipment complies with Part 68 of FCC rules and the requirements adopted by ACTA. On the bottom side of this equipment is a label that contains—among other information—a product identifier in the format *US: AAAEQ##TXXXX*. If requested, this number must be provided to the telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA.

This equipment uses a Universal Service Order Code (USOC) jack: RJ-11C.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, for repair or warranty information, please contact our company. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

Industry Canada Notice

This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

This Declaration of Conformity means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction. Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above condition may not prevent degradation of service in

some situations. Repairs to some certified equipment should be made by an authorized maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment. Users should ensure for their own protection that the ground connections of the power utility, telephone lines and internal metallic water pipe system, are connected together. This protection may be particularly important in rural areas.

Appendix B **Specifications**

Chapter contents

General Characteristics	152
G.SHDSL Characteristics	152
Ethernet	152
Sync Serial Interface	153
T1/E1 Interface (3086/RIK and RIT models only)	153
64K/G.703 Port (3086/RIF Model)	153
Protocol Support	153
PPP Support	154
ATM Protocols	154
Management	154
Security	155
Compliance Standard Requirements	155
Australia Specific	155
Dimensions	155
Power and Power Supply Specifications	155
AC universal power supply	155
48 VDC power supply	155

General Characteristics

- Compact low-cost plug and play IAD
- 10/100 Ethernet
- Unlimited host support.
- Comprehensive hardware diagnostics, works with any operating system, easy maintenance and effortless installation.
- Plug-and-Play operation for fast and seamless turn-up with pre-configured WAN and LAN options.
- Built-in web configuration.
- Setup allows for standard IP address and unique method for entering an IP address and mask WITHOUT use of a console connection. Default IP address of 192.168.1.1/24.
- Simple software upgrade using FTP into FLASH memory.
- Eight front panel LEDs indicate Power, DSL WAN, Ethernet LAN speed and status.
- Convenient and standard RJ connectors for Ethernet, Line, and Console.
- Field Factory Default Option.
- Standard 1 year warranty.

G.SHDSL Characteristics

- Full duplex 2.3 Mbps speed over 2-wire (in accordance with ETSI/ITU standard G.991.2). 2.3 Mbps to 4.6 Mbps, full duplex, over 2-wire.
- DTE Rates 64 kbps to 2.32 Mbps operation. With nx64 with n=1 support.
- Distance from 24,900 feet (7,590 meters) at 192 kbps to 10,200 feet (3,109 meters) at 2.3 Mbps on 26 AWG (0.4 mm) wire
- Annex A (ANSI), Annex B (ETSI) PSD selection.
- 2 wire or 4 wire support (4-wire support to be keyed) for multiple line codes per ITU G.991.2 and ETSI TS 101524 with G.994.1 Handshake.
- CO and CP modes are supported
- TC-PAM based DSL modulations.
- EOC Management channel for remote end-to-end management.

Ethernet

- Auto-sensing Full-Duplex 10Base-T/100Base-TX Ethernet.
- Standard RJ-45 and built-in MDI-X cross-over switch.
- IEEE 802.1d transparent learning bridge up to 1,024 addresses and Spanning Tree.
- 8 IP address/subnets on Ethernet interface.

Sync Serial Interface

- ITU X.21 or V.35 interface
- Available with Female M34, DB-25, and DB-15 connectors
- User configurable DTE/DCE for X.21

T1/E1 Interface (3086/RIK and RIT models only)

- Line Rate 1.544 Mbps (T1), and 2.048 Mbps (E1)
- RJ-48C connector (with optional Dual BNC for RIK version)
- DSX-1 levels for connection to local T1/E1 device (PBX).
- Nx56/64 kbps with full DS0 mapping
- AMI/B8ZS (T1), AMI/HDB3 (E1)
- D4/ESF coding and framing (T1)

64K/G.703 Port (3086/RIF Model)

- Line rate 256 kbps
- Data rate 64 kbps
- RJ-48C connector
- AMI Line Coding

Protocol Support

- Complete internetworking with IP (RFC 741), TCP (RFC 793), UDP (RFC 768), ICMP (RFC 950), ARP (RFC 826).
- IP Router with RIP (RFC 1058), RIPv2 (RFC 2453),
- Up to 64 static routes with user selectable priority over RIP/OSPF routes.
- Built-in ping facilities.
- Integrated DHCP Server (RFC 2131). Selectable general IP leases and user specific MAC/IP parings. Selectable lease period.
- DHCP relay agent (RFC 2132/RFC 1542) with 8 individual address pools.
- DNS Relay with primary and secondary Name Server selection.
- NAT (RFC 3022) with Network Address Port Translation (NAPT) for cost-effective sharing of a single DSL connection. Integrated Application Level Gateway with support for over 80 applications.
- NAT MultiNat with 1:1 mapping.
- NAT Many:1.
- NAT Many:Many mapping.
- NAT Port/IP redirection and mapping.

- uPNP controlled device for seamless networked device interconnectivity and Windows XP integration.
- IGMPv2 Proxy support (RFC 2236).
- Frame Relay with Annex A/D/LMI, RFC 1490 MpoFR and FRF.12 Fragmentation.

PPP Support

- Point-to-Point Protocol over HDLC
- PPPoA (RFC 2364) Point-to-Point Protocol over ATM.
- PPPoE (RFC 2516) Client for autonomous network connection. Eliminates the requirement of installing client software on a local PC and allows sharing of the connection across a LAN.
- User configurable PPP PAP (RFC 1661) or CHAP (RFC 1994) authentication.
- PPP BCP (RFC 1638) support for bridged networking support.

ATM Protocols

- Multiprotocol over ATM AAL5 and Multiprotocol Bridged encapsulation RFC 2684 (Formerly RFC 1483) and RFC 1577 Classical IP over ATM. Default RFC-1483 route mode. Logical Link Control (LLC)/ Subnetwork Access Protocol (SNAP) encapsulation. Default VC mux mode.
- ATM UNI 3.0, 3.1, and 4.0 signaling ATM QoS with UBR, CBR, nrt-VBR, and rt-VBR and per-VC queuing and shaping. IISP V.1.0 Q.2931 UNI L3 and Q.2971 UNI L3 support.
- LAN Emulation Client (LEC) V.1 with LEC via PVC or ILMI connection.
- Peak cell rate shaping on a per-VCC basis up to 32 active VCCs across VPI 0-255, VCI 0-65525. Single default PVC: 8/35 with PCR=5,500 cells.
- I.610 OAM network management including AIS/RDI, loop-back and performance monitoring.
- Enhanced ILMI 4.0 for auto-configuration of ATM PVCs.

Management

- User selectable ATM, PPP, or Frame Relay WAN datalink connection.
- Web-Based configuration via embedded web server
- CLI menu for configuration, management, and diagnostics.
- Local/Remote CLI (VT-100 or Telnet).
- SNMPv1 (RFC 1157) MIB II (RFC 1213)
- Quick Start Setup runs through common options to simplify circuit turn-up.
- Logging via SYSLOG, and VT-100 console. Console port set at 9600 bps 8/N/1 settings no flow control.
- EOC access for End-To-End management, configuration, and control.

Security

- Packet filtering firewall for controlled access to and from LAN/WAN. Support for 255 rules in 32 filter sets. 16 individual connection profiles.
- DoS Detection/protection. Intrusion detection, Logging of session, blocking and intrusion events and Real-Time alerts. Logging or SMTP on event.
- Password protected system management with a username/password for console and virtual terminal. Separate user selectable passwords for SNMP RO/RW strings.
- Access list determining up to 5 hosts/networks which are allowed to access management system SNMP/HTTP/TELNET.
- Logging or SMTP on events: POST, POST errors, line/DSL, PPP/DHCP, IP.

Compliance Standard Requirements

- FCC part 15 Class A (US EMC)
- CE per RTTE 99/5/EC (EMC & LVD)
- FCC Part 68 (– US Permission to connect)
- CTR 12 & CTR 13
- IC-CS03 (Canadian Permission to connect)
- Safety – EN60950

Australia Specific

- TS016 (E1 Telecom)
- AZ/NZS 3260 Safety)
- AZ/NZS 35-48 EMC

Dimensions

1.58H x 4.16W x 3.75D in. (10.6H x 4.1W x 8.8D cm)

Power and Power Supply Specifications

The 3086 may come with either an AC or DC power supply.

AC universal power supply

The Model 3086 offers internal or external AC power supply options.

- The internal power supply connects to an AC source via an IEC-320 connector (100–240 VAC, 200 mA, 50/60 Hz)
- The external power supply connects to an external source providing +5 VDC via a barrel-type connector

48 VDC power supply

- Rated voltage and current: 36–60 VDC, 400 mA

- Fuse rating: 250 Volts, 400 mA, time delay



Connect the equipment to a 36–60 VDC source that is electrically isolated from the AC source. The 36–60 VDC source is to be reliably connected to earth.

Appendix C **Cable Recommendations**

Chapter contents

DSL Cable.....	158
Ethernet Cable	158
Adapter.....	158

DSL Cable

10 foot (3 m), RJ-11/RJ-11 (refer to “RJ-11 non-shielded port” on page 160)

Ethernet Cable

Ethernet cable (P/N 10-2500) (refer to “RJ-45 shielded 10/100 Ethernet port” on page 160)

Adapter

EIA-561 to DB-9 (P/N 16F-561) (refer to “RJ-45 non-shielded RS-232 console port (EIA-561)” on page 160)

Appendix D **Physical Connectors**

Chapter contents

RJ-45 shielded 10/100 Ethernet port.....	160
RJ-11 non-shielded port	160
RJ-45 non-shielded RS-232 console port (EIA-561)	160
Serial port.....	161
V.35 (M/34 Connector)	161
V.35 (DB-25 Female Connector)	161
X.21 (DB-15 Connector)	162
E1/T1 (RJ-48C Connector)	162
Power input.....	162

RJ-45 shielded 10/100 Ethernet port

Assuming the MDI-X switch is in the out position.

Pin No.	Signal Direction	Signal Name
1	Output	TX+
2	Output	TX-
3	Input	RX+
4		
5		
6	Input	RX-
7		
8		

RJ-11 non-shielded port

Single twisted-pair (TP) for full-duplex transmission. The signals are not polarity sensitive.

Pin No.	Signal Direction	Signal Name
1		
2	In/Out	Tip
3	In/Out	Ring
4		

RJ-45 non-shielded RS-232 console port (EIA-561)

Pin No.	Signal Direction	Signal Name
1	Out	DSR
2	Out	CD
3	In	DTR
4	–	Signal Ground
5	Out	RD
6	In	TD
7	Out	CTS
8	In	RTS

Serial port

V.35 (M/34 Connector)


Pin #	Signal
A	GND (Earth Ground/Shield)
B	SGND (Signal Ground)
D	CTS (DCE Source)
E	DSR (DCE Source, Always On)
F	CD (DCE Source)
L	LL (Local Loop, DTE Source)
M	TM (Test Mode Indicator, DCE Source)
N	RL (Remote Loop, DTE Source)
P	TD (Transmit Data +, DTE Source)
R	RD (Receive Data +, DCE Source)
S	TD/ (Transmit Data -, DTE Source)
T	RD/ (Receive Data -, DCE Source)
U	XTC (Transmit Clock +, DTE Source)
V	RC (Receiver Clock +, DCE Source)
W	XTC/ (Transmit Clock -, DCE Source)
X	RC/ (Receiver Clock -, DCE Source)
Y	TC (Transmitter Clock +, DTE Source)
AA	TC/ (Transmitter Clock -, DTE Source)
KK	Aux. Power Input (+5VDC @ 300mA)

V.35 (DB-25 Female Connector)


Pin #	Signal
1	FG (FrameGround)
2	TD (Transmit Data-A, DTE Source)
3	RD (Receive Data-A, DCE Source)
4	RTS (Request to Send-A, DTE Source)
5	CTS (Clear to Send-A, DCE Source)
6	DSR (Data Set Ready-A, DCE Source)
7	SGND (Signal Ground)
8	CD (Carrier Detect-A, DCE Source)
9	RC/ (Receiver Clock-B, DCE Source)
10	CD/ (Carrier Detect-B, DCE Source)
11	XTC/(External Transmitter Clock-B, DTE Source)
12	TC/(Transmitter Clock-B, DTE Source)
13	CTS/(Clear to Send-B, DCE Source)

Pin #	Signal
14	TD/(Transmit Data-A, DTE Source)
15	TC(Transmitter Clock-B, DCE Source)
16	RD (Receive Data-A, DCE Source)
17	RC (Receiver Clock-A, DCE Source)
18	LL (Local Line Loop)
19	RTS/(Request to Send-B, DTE Source)
20	DTR (Data Terminal Ready-A, DTE Source)
21	RL (Remote Loopback)
22	DSR/ (Data Set Ready-B, DCE Source)
23	DTR/(Data Terminal Ready-B, DTE Source)
24	XTC (External Transmitter Clock-A, DTE Source)
25	TM (Test Mode)

X.21 (DB-15 Connector)



E1/T1 (RJ-48C Connector)



Power input

IEC 320 connector (two prong).

Appendix E **Command Line Interface (CLI) Operation**

Chapter contents

Introduction	164
CLI Terminology	164
Local (VT-100 emulation)	164
Remote (Telnet)	164
Using the Console	165
Administering user accounts	166
Adding new users	166
Setting user passwords	166
Changing user settings	167
Controlling login access	167
Controlling user access	167
G.SHDSL Commands:	167
To establish the DSL link	168

Introduction

The modem configuration and status can also be view and modified through the console, which is accessible through the RS-232 serial port or through a Telnet session over Ethernet.

CLI Terminology

In order to use the CLI commands, you need to understand the following CLI terms:

- **Transport:** A transport is a layer 2 session and everything below it. You can create a transport and attach it to a bridge or router so that data can be bridged or routed via the attached transport. The CLI supports the following transports:
- PPPoA: Point-to-Point Protocol over ATM
- PPPoE: Point-to-Point Protocol over Ethernet
- Frame Relay
- RFC1483
- IPoA: IP over ATM
- PPPoH: Point-to-Point over HDLC
- Ethernet
- **Interface:** bridges and routers both have interfaces. A single transport is attached to a bridge or router via an interface.
- **Object:** an object is anything that you can create and manipulate as a single entity, for example, interfaces, transports, static routes and NAT rules.
- **List:** Objects are numbered entries in a list. For example, if you have created more than one ethernet transport, the following command:

ethernet list transports

produces a list of numbered transport objects:

```
ID Name Port
1 eth2 ethernet
2 eth1 ethernet
```

Local (VT-100 emulation)

A connection is made with the DB9-RJ45 adapter and an RJ45-RJ45 straight-through cable. Set the data rate to 9,600 baud, 8 data bits, one stop bits, and no parity. You may use a dumb terminal or a VT-100 emulation such as HyperTerminal.

Remote (Telnet)

Establishing a Telnet session displays the same CLI configuration and status parameters on the display.

Using the Console

The console commands needed for the various modes of operation are described in later sections. In this subsection are the most basic commands needed for console operation.

By entering “?” all the high level commands (the keywords) are seen.

By entering a keyword followed by a space and “?” the options available will print immediately without pressing enter. The previously entered commands are reprinted on the next lines. For example:

```

Æ ethernet ?[After typing the "?" you will not see the "?"]
    add
    delete
    set
    show
    list
    clear
Æ ethernet

```

Then you may enter one of the keywords on the displayed list followed by a space and “?”

To continue our example:

```

Æ ethernet list ?
    ports
    transports
Æ ethernet list

```

Then

```

Æ ethernet list transports ?
Æ ethernet list transports <enter>

```

```

Ethernet transports:
ID | Name | Port
-----|-----|-----
1 | eth1 | ethernet
-----|-----|-----

```

```

Æ

```

Another example shows when the user must provide a parameter.

```

Æ ip ?
    list
    clear
    add
    delete
    set
    attach
    attachbridge
    detach
    show
    interface
    ping
Æ ip interface ?
    <name>

```

The <name> of the interface. In this instance the interface name is ip1. It is important that you do the “?” inquiry to determine whether additional parameters follow.

```

Æ ip interface ip1 ?
    add
    delete

```

```

clear
list
A ip interface ip1 list ?
  secondaryipaddresses
A ip interface ip1 list secondaryipaddresses ?
ip interface ip1 list secondaryipaddresses <enter>

Secondary IP addresses for interface: ip1
ID |   IP Address
----|-----
-----

```

In this example there was not a secondary IP address. Now save the entire configuration in nonvolatile FLASH memory with the following command.

```
A system config save
```

Wait for the message that says “Configuration Saved”, then reboot the modem with this command.

```
A system restart
```

Administering user accounts

As admin user you can administer user accounts. This section summarizes the CLI commands which can be used to administer user accounts.

Adding new users

To add a new user username, use the command: *system add user < username > <“Comment”>*

```
system add login user < username > <“Comment”>
```

The first command creates a user who can access the system via a dialin connection using PPP for example. The second command creates a user who can login to the system.

For example, the commands:

```
system add user fred “user with dialin access”
```

```
system add login joe “user with login access”
```

creates two new users called fred and joe. The accounts are created with no passwords. To view details about the new users, enter:

```
system list users
```

The following information is returned:

```

Users:
May May Access
ID | Name   | Conf. | Dialin | Level | Comment
-----|-----|-----|-----|-----|-----
1 | fred   | disabled | ENABLED | default | user with dialin access
2 | joe    | ENABLED | disabled | default | user with login access
3 | admin  | ENABLED | disabled | superuser | Default admin user
-----

```

Setting user passwords

To change the password for the user you are currently logged in as, use the command:

```
user password
```

Enter the new password twice as prompted:

```
Enter new password: ***  
Again to verify: ***  
→
```

Note No check is made for any current password which may have been set for the user.

If you wish to change the password for another user, enter the command:

```
user change <username>
```

This command logs you into the system as another user. You can then use the user password command to change the password for this user.

Note Changing to another user means that you lose all superuser privileges.

Note Only superusers can use the user change command.

Changing user settings

To change any of the default settings for a user, use the following commands. For example, to change the settings for user fred:

```
system set user fred access {default|engineer|superuser}  
system set user fred maydialin {enabled|disabled}  
system set user fred mayconfigure {enabled|disabled}
```

For example, to change the security level for fred, enter:

```
system set user fred access engineer
```

Note Only superusers can use the user change command.

Controlling login access

To set user login access for user username, use the command (all on one line):

```
system set login < username > access {default|engineer|superuser}
```

Controlling user access

To set user access for user username, use the command (all on one line):

```
system set user < username > access {default|engineer|superuser}
```

G.SHDSL Commands:

Command format: 'gshdsl Action Attribute Value'

- Action – Two types of actions are available: 'set' or 'show'
- Set – set attributes with a value.
- Show – get information from the box
- Attribute – The name of the attributes to access.
- Value – The new value for the attribute (Set command only)

Example: To read the attribute 'Version': `gshdsl show Version`

To set data rate to 256K (4 * 64K): `gshdsl set DSLRateTS`

To set terminal type to CPE mode: `gshdsl set terminal remote`

To show the current terminal type: `gshdsl show terminal`

Attribute	Type	Value	Description
Version	RO	-	The version number of the DSL driver
Platform	RO	-	The platform name of the unit e.g. 3086 or 3086
ModemState	RO	Idle Deactivated Norm Oper In-Progress	Show the state of the handshaking process: Idle – The DSL chip is in idle state Deactivated – The DSL chip is deactivated Normal Operation – The DSL chip is in operating (Link established) In-Progress – Handshaking in process
DSLRateTS	RW	3-36	Data rate N number N=3-36. e.g. 256K data rate is N=4. The composite data rate is the chosen number N times 64 kbps. E.g., 32 x 64 kbps = 2.048 Mbps.
DataRateI	RW	0-7	This attribute controls the size of the overhead channel. Valid input is 0-7. Default value is 0. (!!Keep it as 0)
terminal	RW	Central Remote	Central – CO unit Remote – CPE unit
Interface	RW	Hdlc	Utopia – Data will be packaged in ATM cell format and send through the UTOPIA interface of the processor Hdlc – Data will be packaged in HDLC frame and send through the PCM Bus
Action	WO	Start Deactivate	Start – Command the box to configure the DSL chip and start the handshaking process Deactivate – Command the box to disconnect and deactivate the DSL link.

To establish the DSL link

1. One unit needs to be set to CO (central) and the other unit as CP (remote)
2. The Data rate of the 2 units have to be the same (DatarateN)
3. The interface type needs to be the same to pass data (Interface)
4. Issue the 'Action' command to start the handshaking process (Action Start)

Example: To set up the units to run at 2.048Mbps using ATM interface.

For CO (central) unit

```
→ gshdsl set terminal central
→ gshdsl set interface utopia
→ gshdsl set dataRateN 32
→ gshdsl set dataRateI 0
→ gshdsl set Action Start
```

For CPE (remote) unit

```
→ gshdsl set terminal remote
→ gshdsl set interface utopia
→ gshdsl set dataRateN 32
→ gshdsl set dataRateI 0
→ gshdsl set Action Start
```


Default Setting of the unit

Terminal: Remote

Interface: Hdlc

DataRateN: 24

DataRateI: 0

Appendix F **Interworking Functions Information**

Chapter contents

Introduction	173
Frame Relay Local Management Interface	173
LMI Configuration Options:	173
managementType: (Default Value: no_maintenance)	173
MgtState	174
mgtAutoStart: (Default Value: FALSE)	174
T391_Value: (Default Value: 10)	174
T392_Value: (Default Value: 16)	174
fullReportCycle: (Default Value: 6)	174
netErrorWindowSize: (Default Value: 4)	174
netMaxErrors: (Default Value: 3)	174
userErrorWindowSize: (Default Value: 4)	174
userMaxErrors: (Default Value: 3)	174
CLI Configuration Methods	175
Show current configuration	175
Set configuration variable	175
Web Configuration Methods	176
Frame Relay Service Interworking (FRF.8)	176
FRS Configuration Options	176
DE Mapping	176
FECN Mapping	177
Translation Mode:	177
FRS Name	178
CLI Configuration Method	179
Show one of the eight groups	179
Set variable attributes on a specified group	179
Set variable attributes on a specified channel	180
Web Configuration Methods	180
FRS Overview Screen	180
Group/Channel Level Configuration Screen	181
Frame Relay Network Interworking (FRF.5)	182
FRN Configuration Options	182
Port Level Configuration Options:	183
Channel Level Configuration Options	184
CLI Configuration Methods for Port Level Management	185
List all ports available to the system	185
Show detailed information about a specific port	185
Set configuration variables associated with the specified port	186
Configuration Management of the Channel Level Variables	186

Understanding the Channel Level View	186
Set Configuration Variables associated with the Channels	187
Web Configuration Methods for FRF.5 Port and Channel Level Configuration	187
Port Level Information Screen	188
Channel Level Information Screen	189
Packet Information Screen	189
Frame Relay (Ethernet Based) Operations	190
Frame Relay Configuration Options	190
Channel Segment Size	190
DLCI: Data Link Connection Identifier	190
Encapsulation Type	190
Port	190
Rxmaxpdu	190
Txmaxpdu	190
Frame Relay CLI Configuration Options	190
Build a new Frame Relay Transport	190
Clear all Frame Relay Transports	191
Delete the specified transport	191
List all active Frame Relay Channels	191
Set configuration variables for the specified frame relay transport	191
Show detailed configuration information on the specified channel:	191
Web Based Configuration of the Frame Relay Channel	192
Serial Interface Configuration	192
Configuration Variables Available	192
Clock Mode	192
Clock Invert Functions: (rxClkInv – receive clock, txClkInv – transmit clock)	192
Speed	192
CLI Configuration Methods	193
Set configuration variable	193
Show current configuration settings	193
Gain help about the Serial Interface	193
Web Interface Configurations	194
Ping and Trace Route	194
Ping commands from the CLI Interface	194
Trace Route from the CLI Interface	195
Define Usage: “ip traceroute”	195
Start Trace Route: “ip traceroute start 192.168.50.2”	195
Ping and traceroute from the web interface:	196
Backup and Restore Features	196
Backup Configuration	196
Restore Configuration	196

Introduction

This appendix describes the Frame Relay Interworking functions (IWF) that are available on the Model 3086. The following information describes how to use and operate the following Frame Relay Interworking feature sets:

- LMI information and user interface (see section “Frame Relay Local Management Interface”).
- FRS (FRF.8) information and user interface (see section “Frame Relay Service Interworking (FRF.8)” on page 176).
- FRN (FRF.5) information and user interface (see section “Frame Relay Network Interworking (FRF.5)” on page 182).
- Frame Relay (Ethernet based) information and user interface (see section “Frame Relay (Ethernet Based) Operations” on page 190).
- Serial Interface Management (see section “Serial Interface Configuration” on page 192).
- Ping and Trace route (see section “Ping and Trace Route” on page 194).

Note Each section describes the CLI and web interface for the feature set.

Frame Relay Local Management Interface

The Frame Relay Local Management Interface (LMI) is a mechanism that enables two separate frame relay systems to communicate the status of the interface. The LMI interface supports dynamic updates on the status of the DLCI connections and the congestion state of the network. The Model 3086 fully the LMI version listed in Table 10.

Table 10. LMI Implementation on the 3086FR

Protocol	Specification	Options Available
LMI	Frame Relay Forum Implementation Agreement (IA) FRF.1 superceded by FRF.1.1	<ul style="list-style-type: none"> • Network side • User side • Both
Annex D	ANSI T1.617	<ul style="list-style-type: none"> • Network side • User side • Both
Annex A	ITU Q.933 referenced in FRF.1.1	<ul style="list-style-type: none"> • Network side • User side • Both

LMI Configuration Options:

LMI is configurable via the CLI or web interface. The following variables are available for configuration.

managementType: (Default Value: no_maintenance)

the managementType variable defines the LMI protocol that will be used. The following options are available.

- **no_maintenance:** No maintenance interface will be used for this frame relay connection.

- **933A_Network:** The ITU Q.933 protocol will be used. The unit will operate as the Network side of the connection
- **933A_User:** The ITU Q.933 protocol will be used. The unit will operate as the User side of the connection
- **933A_Both:** The ITU Q.933 protocol will be used. The unit will operate as both the Network and User side of the connection.
- **617D_Network:** The ANSI T1.617 protocol will be used. The unit will operate as the Network side of the connection
- **617D_User:** The ANSI T1.617 protocol will be used. The unit will operate as the User side of the connection
- **617D_Both:** The ANSI T1.617 protocol will be used. The unit will operate as both the Network and User side of the connection.

MgtState

Defines the current state of the DTE side LMI. Possible options are as follows:

- **Mgt_Port_DOWN:** Currently the LMI on the DTE side is DOWN
- **Mgt_Port_UP:** Currently the LMI on the DTE side is UP

mgtAutoStart: (Default Value: FALSE)

The management *Auto Start* variable allows the user to start the LMI session before any DLCI connections are created within the unit. If this variable is set to *FALSE*, the LMI session will begin when the first DLCI channel is created. If this variable is set to *TRUE* the LMI session will begin immediately.

T391_Value: (Default Value: 10)

This variable sets the T391 timers in seconds.

T392_Value: (Default Value: 16)

This variable sets the T392 timers in seconds.

fullReportCycle: (Default Value: 6)

This variable represents the N391 protocol value

netErrorWindowSize: (Default Value: 4)

Network side N393 protocol value

netMaxErrors: (Default Value: 3)

Network side N392 protocol value

userErrorWindowSize: (Default Value: 4)

User side N393 protocol value

userMaxErrors: (Default Value: 3)

Network side N392 protocol value

CLI Configuration Methods

The following describes how to configure the LMI using the CLI. All LMI commands are contained under the “lmi” directive of the CLI interface. The following options are available:

Show current configuration

Command: “lmi show”

```
→ lmi show
      FR_Mgt Type : no_maintenance
      FR_Mgt State : Mgt_Port_DOWN
      Full Report Cycle : 6
      User Max Errors : 3
      Net Max Errors : 3
      User Error Window Size : 4
      Net Error Window Size : 4
      T391_Value : 10
      T392_Value : 16
      Mgt Auto Start : false
```

Set configuration variable

Command: “lmi set <variable> <value>”

Variable: Any variable from the above list <<<<<<< WHAT LIST??

Value: Value as defined by the variable

```
→ lmi set managementType 933A_Network
```

Web Configuration Methods

The following describes how to configure the LMI using the web interface. All LMI configuration variables are contained under the “LMI Management” window found through the IWF link. The following image shows the configuration variables available.

LMI Configuration	
Management Type	no_maintenance
Management State	Mgt_Port_DOWN
Management Auto Start	false
Full Report Cycle	6
User Max Errors	3
Net Max Errors	3
User Error Window Size	4
Network Error Window Size	4
T391_Value	10
T392_Value	16
<input type="button" value="Configure"/>	

Frame Relay Service Interworking (FRF.8)

FRF.8 is a conversion mechanism by which Frame Relay networks can communicate directly with ATM-based networks. Neither the ATM nor the Frame Relay networks require any understanding of the other network protocols involved. This conversion is performed within the Model 3086's IWF at the transport service level. Frame Relay Service Interworking functions are defined by the Frame Relay Forum specification “Frame Relay/ATM PVC Service Interworking Implementation Agreement FRF.8.1”.

FRS Configuration Options

The Model 3086 supports 64 FRF.8 connections (divided into eight groups of eight channels each). The IWF are configured by group and channel. The group level configuration options are applied to eight channels that are related to that group. The following list of variables are configured at the group level.

DE Mapping

The DE Mapping variable is used to determine how the Frame Relay DE field (Discard Eligibility) will be mapped to the ATM CLPI (Cell Loss Priority Indication) and vice versa. The following options are available:

- **Always_zero:**
 - Frame Relay: All Frame Relay packets will have the DE field in the header set to a constant value of 0.
 - ATM: All ATM cells will have the CLPI field set to a constant value of 0.

- **Always_one:**
 - Frame Relay: All Frame Relay packets will have the DE field in the header set to a constant value of 1.
 - ATM: All ATM cells will have the CLPI field set to a constant value of 1.
- **Convert:**
 - Frame Relay to ATM Direction: The system will convert the DE field received from the Frame Relay packet into the CLPI field of the outgoing ATM cell.
 - ATM to Frame Relay Direction: The system will convert the CLPI bit received from the ATM cells into the DE field of the outgoing Frame Relay packet.

FECN Mapping

The FECN Mapping variable is used to determine how the Frame Relay FECN (Forward Explicit Congestion Notification) bit will be mapped to the ATM EFCI (Explicit Forward Congestion Indication) bit and vice versa. The following options are available:

- **Always_zero:**
 - Frame Relay: All Frame Relay packets will have the FECN bit in the header set to a constant value of 0.
 - ATM: All ATM cells will have the EFCI bit set to a constant value of 0.
- **Always_one:**
 - Frame Relay: All Frame Relay packets will have the FECN bit in the header set to a constant value of 1.
 - ATM: All ATM cells will have the EFCI bit set to a constant value of 1.
- **Convert:**
 - Frame Relay to ATM Direction: The system will convert the FECN bit received from the Frame Relay packet into the EFCI bit of the outgoing ATM cell.
 - ATM to Frame Relay Direction: The system will convert the EFCI bit received from the ATM cells into the FECN bit of the outgoing Frame Relay packet.

Translation Mode:

The Translation Mode variable defines the encapsulation mechanism that will be required to convert the ATM cells (encapsulated per RFC1483) to the Frame Relay packets (encapsulated per RFC1490) and back. This is required because ATM and Frame Relay encapsulate packets in different formats as defined by their respective RFC. There are two options available for the Translation Mode setting within the Model 3086 as defined below:

- **Translate:** When the connection channel is set to translate, the IWF converts between Frame Relay encapsulated packets and the ATM encapsulated cells. This conversion is performed by inspecting each packet/cell and determining the PID (Protocol Identification) field within the packet. Using this information, the packet/cell is routed through an encapsulation conversion utility that creates the encapsulation required for the destination network. The Model 3086 supports all 22 encapsulation types as defined by the FRF.8.1

specification. See figure 16 for the encapsulation types and includes an example where a Routed IP packet is received on both the Frame Relay and ATM sides of the connection. When the packet is received is checked against the known PID fields, and then the packet is routed to the appropriate encapsulation conversion station before being sent out the opposite interface.




Figure 16. FRS encapsulation conversion using Translate Mode

- **Transparent:** The second translation mode option is to set the protocol value to transparent. Transparent is used when the Protocol being used is not one of the 22 predefined encapsulation types, such as is the case for voice based systems. When the translation mode is set to transparent, the packet data will be transparently passed from one network to the other without any encapsulation conversions.

FRS Name

Allows the user to name the FRS channel. This is helpful when viewing multiple connections to determine which DLCI/VPI/VCI combination is associated with each channel.

- **FRS state:** The state variable allows the user to enable or disable the channel for operation.

The Frame Relay Service Interworking functions on the Patton Electronics Model 3086FR are also defined as sixty-four channels. Each channel creates a connection between a single DLCI on the Frame Relay network and a VPI/VCI on the ATM network. The following configuration options are available for each channel in the system.

- **VPI—Virtual Path Identifier:** ATM side Virtual Path Identifier for the specified connection.
- **VCI—Virtual Channel Identifier:** ATM side Virtual Channel Identifier for the specified connection
- **DLCI—Data Link Connection Identifier:** Frame Relay side DLCI for the specified connection

CLI Configuration Method

The following section describes how to configure FRS channel connections using the CLI interface.

The system is made up of eight groups and 64 channels. The group configuration variables apply to all eight channels within that group. Each channel is configured independently and will all run over as single LMI session or with no LMI running. The FRS (FRF.8) connections are configured using the “frs” directive in the CLI interface. The following commands are available:

Show one of the eight groups

Command: frs show group #

The frs show group # command shows the configuration of the group defined by the # directive. Possible options are 1–8. The following shows an example setup:

```
→ frs show group 1
Group Level Information: Group A
Group Name:
Group DE Mapping: zero
Group Trans Mode: translate
Group FECN Mapping: zero

Channel Level Information: Channels 1 - 8
-----
|Chn |VPI |VCI |DLCI| Activate | Tx Pkt G/B      | Rx Pkt G/B
|chn1 |100 |200 |172 |enable  | 0/0             | 0/0
|chn2 |1   |101 |101 |disable | N/A             | N/A
|chn3 |2   |102 |102 |disable | N/A             | N/A
|chn4 |3   |103 |103 |disable | N/A             | N/A
|chn5 |4   |104 |104 |disable | N/A             | N/A
|chn6 |5   |105 |105 |disable | N/A             | N/A
|chn7 |6   |106 |106 |disable | N/A             | N/A
|chn8 |7   |107 |107 |disable | N/A             | N/A
```

Set variable attributes on a specified group

Command: frs set group # <variable> <value>

Note At any point during the typing of the command selecting the “?” will display the possible options available to the user.

Note After the first several letters of the command are typed pressing the Tab key will tell the system to complete the variable or command name.

The frs set group command allows the user to setup the configuration of the group variables. The following example could be used to set the DEMapping variable to “convert”.

Note At the end of the first line the “?” was selected and the system prompted the user with the possible options available.

```
→ frs set group 1 DEMapping ?
convert
one
zero
→ frs set chn1 DEMapping convert
```

Set variable attributes on a specified channel

Command: frs set channel # <variable> <value>

The following example could be used to set the DLCI variable to 171.

```
→ frs set channel 1 DLCI 171
```

Web Configuration Methods

The following documentation defines how to configure the FRS channel connections using the web interface on the x Model 3086. All web interface screens are found under the IWF link.

FRS Overview Screen

By selecting the “FRS Setup (FRF.8)” link below the IWF heading will bring up an overview of the FRS connection available within the system. This page shows a top level view of the eight groups available. The

“Group #” column along the left side of the screen is a hyperlink that will bring up detailed configuration information about each group and the channels available in the group.

Group	Channels	Group Name	
Group A	Channels 1 - 8	<input type="text"/>	Submit
Group B	Channels 9 - 16	<input type="text"/>	Submit
Group C	Channels 17 - 24	<input type="text"/>	Submit
Group D	Channels 25 - 32	<input type="text"/>	Submit
Group E	Channels 33 - 40	<input type="text"/>	Submit
Group F	Channels 41 - 48	<input type="text"/>	Submit
Group G	Channels 49 - 56	<input type="text"/>	Submit
Group H	Channels 57 - 64	<input type="text"/>	Submit

Group/Channel Level Configuration Screen

By selecting the “Group #” link in the FRS Overview screen, the detailed channel level information screen is displayed as shown below. This screen allows configuration of all variables associated with the group and channels. The screen is broken down into three sections; the first section allows configuration of the group level information, the second section allows configuration of the channels associated with the group, the last screen shows the packet counters.

Group A Configuration: Channels 1 - 8

Group Level Configuration: Group Name:

Translation Mode: DE Mapping: FECN Mapping:

Figure 17. RF.8 Group Level Configuration window

Channel Level Configuration

Chnl #	Channel Name	VPI	VCI	DLCI	Enable	Submit	Tx Pkts	Rx Pkts	Clear
Chn 1		100	200	172	enable	Submit	0/0	0/0	Clear
Chn 2		1	101	101	disable	Submit	N/A	N/A	Clear
Chn 3		2	102	102	disable	Submit	N/A	N/A	Clear
Chn 4		3	103	103	disable	Submit	N/A	N/A	Clear
Chn 5		4	104	104	disable	Submit	N/A	N/A	Clear
Chn 6		5	105	105	disable	Submit	N/A	N/A	Clear
Chn 7		6	106	106	disable	Submit	N/A	N/A	Clear
Chn 8		7	107	107	disable	Submit	N/A	N/A	Clear

Figure 18. FRF.8 Channel Level Configuration Screen

Channel 1 Packet Information

Tx Packets Good/Bad	Rx Packets Good/Bad	Clear Counters
N/A	N/A	Clear Counters

Figure 19. FRF.8 Channel Level Packet Information

Frame Relay Network Interworking (FRF.5)

Frame Relay Networking Interworking (FRF.5) is a conversion mechanism by which Frame Relay networks can communicate with ATM networks and the conversion is not visible to the Frame Relay side of the network. On the ATM side of the network, the ATM device must support the Frame Relay Service Specific Convergence Sublayer (FR-SSCS). The Patton Electronics Model 3086 support all of the required Inter-Working Functions that are required to supply a Frame Relay Network Interworking function.

The Frame Relay Network Interworking functions are defined by the Frame Relay Forum specification “Frame Relay/ATM PVC Network Interworking Implementation Agreement FRF.5”

FRN Configuration Options

The Frame Relay Network Interworking functions on the Patton Electronics Model 3086 are defined by both ports and channels. Ports are used to define the lower level Interworking Functions. First a port must be created that defines such items as the ATM VPI/VCI and the type of mapping that will be used to make the connection. Once the port is created, channels can be attached to the ports that will allow data channels to pass from the Frame Relay interface to the ATM interface. Channel configuration variables options include the Frame Relay DLCI that will be used to communicate with the Frame Relay Network.

Port Level Configuration Options:

Ports are used to define the lower level Interworking Functions. The port configuration will define the following variables:

- **VPI—Virtual Path Identifier:** ATM side Virtual Path Identifier for the specified connection.
- **VCI—Virtual Channel Identifier:** ATM side Virtual Channel Identifier for the specified connection
- **DE Mapping:** The DE Mapping variable is used to determine how the Frame Relay DE field (Discard Eligibility) will be mapped to the ATM CLPI (Cell Loss Priority Indication). This variable is only used in the Frame Relay to ATM mapping direction. Note that the DE bit from the core Q.922 (Frame Relay) packet will *always* be copied unchanged into the FR-SSCS PDU header cell. The following options define how the DE will be mapped to the ATM CLPI bit:
 - **Always_zero:** All ATM cells will have the CLPI field set to a constant value of 0.
 - **Always_one:** ATM: All ATM cells will have the CLPI field set to a constant value of 1.
 - **Convert:** The system will convert the DE field received from the Frame Relay packet into the CLPI field of the outgoing ATM cell that is generated by the segmentation process.
- **CLPI Mapping:** The CLPI Mapping variable is used to determine how the ATM CLPI (Cell Loss Priority Indication) bit in the ATM cell will be mapped to the DE (Discard Eligibility) bit of the resulting Frame Relay packet. There are two options available.
 - **Fr_sscs_only:** The FR-SSCS removed from the ATM header PDU is used to set the DE bit in the output Frame Relay packet. The CLPI bit from the ATM cell is ignored.
 - **Fr_sscs_and_clpi:** Both the DE bit from the ATM header PDU and the CLPI bit from the received ATM cells are used to determine the output state of the resulting Frame Relay packet. The following table defines how .

CLPI received from ATM cell	DE from FR-SSCS of ATM cell	Outgoing DE bit of FR Packet
0	0	0
1	X	1
X	1	1

- **Multiplexing Mode:** The MuxMode variable allows multiple channels to be multiplexed onto a single port. A port is defined by its' VPI/VCI of the ATM rfc1483 data path. Channels are defined by their Frame Relay DLCI. Thus, the multiplexing mode will allow multiple Frame Relay channels to be transported over a single ATM VPI/VCI link. There are two options available.
 - **Mux_many_to_one:** The “many to one” option allows multiple DLCI channels to be transported over a single ATM rfc1483 connection. Note that if the MuxMode is not set to “many to one” trying to add multiple DLCI connections will result in errors.
 - **Mux_one_to_one:** The “one to one” option notifies the system that there will be a one to one mapping between a single ATM port VPI/VCI and a single Frame Relay DLCI.
- **FRN Name:** Allows the user to name the FRN port. This is helpful when viewing multiple connections to determine which VPI/VCI is associated with each port.

- **FRS state:** The state variable allows the user to enable or disable the port for operation. Note that port level configuration variables are not changeable “on the fly”. If it is required that configuration changes are required, the user should disable the port, make the configuration changes, and then re-enable the port.
- **Port Level Maintenance:** Port level maintenance creates an LMI session across the ATM link. This is useful to determine the status of the link. There are three options available for Port Level Maintenance. The description of these variables is identical to that described in the beginning of this document. Note that in each case the only option available is “both”. This means that the system is performing both “Network” and “User” side LMI functions.
 - 933A_both
 - 617D_both
 - LMI_both
- **Port Level Mgt State:** This variable defines the state of the Port Level Maintenance.
 - **Mgt_Port_DOWN:** Currently the LMI on the DTE side is DOWN
 - **Mgt_Port_UP:** Currently the LMI on the DTE side is UP

Channel Level Configuration Options

The Channel Level Configuration variables are used to define the channels that are attached to the ATM port. The following variables are used to define each channel configuration.

- **DLCI—Data Link Connection Identifier:** Frame Relay side DLCI for the associated channel.
- **FRN Channel Name:** Allows the user to name the FRN channel. This is helpful when viewing multiple channel connections to determine which DLCI is associated with each channel.
- **FRN Channel State:** The state variable allows the user to enable or disable the channel for operation. Note that the port that the channel is connected to must be enabled before the channel can be enabled for operation.
- **Network DLCI:** The network DLCI allows the system to transport data over the atm link using a different DLCI than is used on the DTE side. If the network DLCI is set to “0”, then the DTE side DLCI will be used. If the Network DLCI is set to any other value, that value will be used to transport data across the link using the FR-SSCS.
- **Mgt State:** The Mgt State variables defines the state of the Channel using the Port Level Management information. The following options are available
 - **N/A:** The port associated with this channel is disabled.
 - **n/a:** There is no Port Level Management function enabled for the port associated with this channel.
 - **Down:** The Port Level Management is currently in the “down” state.
 - **active-congested:** The Port Level Management is reporting that this channel is active and it has detected that the channel is congested.
 - **Active:** The Port Level Management is reporting that this channel is active
 - **Deleted:** The Port Level Management is reporting that this channel has been deleted. This could also result if the associated channel at the remote end is not configured

- **not active:** No information has been received from the management port related to this channel

CLI Configuration Methods for Port Level Management

The following information can be used to configure the Port Level information associated with the FRN connections. The CLI uses the “frn” directive of the CLI interface for Port Level configuration.

List all ports available to the system

Command: frn list

The “frn list” command will display the current high level state of each port available in the system. More information about each specific port can be gained by the “show port” command described below. The following shows the output of the “frn list” command.

→ frn list

```
-----
```

Port	Name	VPI	VCI	DLCI	Activate	Mux Mode
port1	main	0	100	100	disable	mux_one_to_one
port2	backup	10	110	110	disable	mux_one_to_one
port3	none	20	120	120	disable	mux_one_to_one
port4	none	30	130	130	disable	mux_one_to_one
port5	none	40	140	140	disable	mux_one_to_one
port6	none	50	150	150	disable	mux_one_to_one
port7	none	60	160	160	disable	mux_one_to_one
port8	none	70	170	170	disable	mux_one_to_one

```
-----
```

Show detailed information about a specific port

Command: frn show port#

The “frn show port#” command will display detailed information about the port defined in the command. The following shows the actual output of the configuration of port 3. Note that the “frn show port” will also display information about the channels that are associated with that port.

frn show port1 command output

```
Port Level Information: Port 1
FRN Port Name:      none
FRN VPI:            0
FRN VCI:            100
FRN DE Mapping:     zero
FRN CLPI Mapping:   fr_scs_only
FRN Mux Mode:       mux_one_to_one
FRN Header Type:    2_byte
FRN DC Mapping:     zero
FRN State:          enable
FRN Core Name:      FRN0
FRN Tx Packets:     146/1
```

```

FRN Rx Packets:      145/0
FRN Network Mgt:     lmi_both
FRN Net Mgt State:   port_mgt_UP

```

Channel Level Information:

```

-----
|Chn1 |DLCI|Net DLCI|Activate| Tx Pkt G/B | Rx Pkt G/B |Status
|chn1 |100 |0      |enable  | 0/0      | 0/0      |active
|chn2 |101 |0      |disable | N/A      | N/A      |N/A
|chn3 |102 |0      |disable | N/A      | N/A      |N/A
|chn4 |103 |0      |disable | N/A      | N/A      |N/A
|chn5 |104 |0      |disable | N/A      | N/A      |N/A
|chn6 |105 |0      |disable | N/A      | N/A      |N/A
|chn7 |106 |0      |disable | N/A      | N/A      |N/A
|chn8 |107 |0      |disable | N/A      | N/A      |N/A
-----

```

Set configuration variables associated with the specified port

Command: frn set port# <variable> <value>

The “frn set port#” command allows the user to set port level specific variables to their optional values. All variables described above for the port level configurations are available from the “frn set port#” command screen. The following example shows the setting of port #5 MuxMode to mux_many_to_one. NOTE that after the first line the “?” was used to determine the possible configuration options available to the user.

Note At any point during the typing of the command selecting the “?” will display the possible options available to the user.

Note After the first several letters of the command are typed pressing the Tab key will tell the system to complete the variable or command name.

```

→ frn set port5 MuxMode
mux_many_to_one
mux_one_to_one
→ frn set port5 MuxMode mux_many_to_one

```


Configuration Management of the Channel Level Variables

The following information can be used to configure the Channel Level information associated with the FRN connections. The CLI uses the “frn” directive of the CLI interface for Channel Level configuration. Note that the “frn show port” and “frn list” commands already discussed at the port level are also useful to gain detailed and overview information about the channels.

Understanding the Channel Level View

The Patton Electronics Model 3086 supports up to eight individual FRN Ports. Each port can support up to eight Channels while set to the “many to one” multiplexing mode. To access the port level information the user

must first define the port number that is being configured and then the channel number that is being configured. The following chart shows how the ports and channels are viewed by the system:



Set Configuration Variables associated with the Channels

Command: frn set port# channel # <variable> <value>

The “frn set port# channel #” command allows the user to set channel level variables. Note that the port number must be specified along with the channel # as described in the above chart. The following screen capture shows the setting of the DLCI for port #5 channel #1. Note that after the channel number was input the “?” key was used to request that the system displays the possible variables that the user has access to.

```

→ frn set port5 channel 1
ChannelName
DLCI
state
→ frn set port5 channel 1 DLCI 180

```

Web Configuration Methods for FRF.5 Port and Channel Level Configuration

The following information can be used to configure and manage the Frame Relay Network Interworking functions using the web interface. All FRN configuration options can be found under the IWF link.

Once “FRN Setup (FRF.5)” is selected the Port Level Overview screen is displayed as shown below.

FRN Configuration:									
Port Level Configuration									
Port	Name	VPI	VCI	DLCI	State	Mgt State	Tx Pkt	Rx Pkt	Clear Counters
Port 1	none	0	100	100	enable	port_mgt_UP	171/1	170/0	Clear Counters
Port2	none	10	110	110	enable	port_mgt_DOWN	0/0	0/0	Clear Counters
Port3	none	20	120	120	disable	port_mgt_DOWN	N/A	N/A	Clear Counters
Port4	none	30	130	130	disable	port_mgt_DOWN	N/A	N/A	Clear Counters
Port5	none	40	140	140	disable	port_mgt_DOWN	N/A	N/A	Clear Counters
Port6	none	50	150	150	disable	port_mgt_DOWN	N/A	N/A	Clear Counters
Port7	none	60	160	160	disable	port_mgt_DOWN	N/A	N/A	Clear Counters
Port8	none	70	170	170	disable	port_mgt_DOWN	N/A	N/A	Clear Counters

The screen gives an overview of the FRN connections that are available. Each Port Number in the left column is a hyperlink that will display a more detailed view of the port along with the configuration of the channel level information. This screen is broken down into three sections. Each section is shown below.

Port Level Information Screen

The Port Level configuration information allows the user to configure Port Level variables. After configuration changes have been made, use the “Configure Port” button to set those parameters.

Port 1 Configuration:			
Port 1 Configuration Previous Port Refresh Page Next Port			
Port Name	<input type="text" value="none"/>	Port State	<input type="text" value="enable"/>
VPI	<input type="text" value="0"/>	VCI	<input type="text" value="100"/>
DE Mapping	<input type="text" value="zero"/>	CLPI Mapping	<input type="text" value="fr_sscs_only"/>
Mux Mode	<input type="text" value="mux_one_to_one"/>	DC Mapping	<input type="text" value="zero"/>
Port Mgt	<input type="text" value="lmi_both"/>	Mgt State	<input type="text" value="port_mgt_UP"/>
Tx Packets	<input type="text" value="182/1"/>	Rx Packets	<input type="text" value="181/0"/>
<input type="button" value="Configure Port"/>	<input type="button" value="Disable Port"/>	<input type="button" value="Clear Counters"/>	

Channel Level Information Screen

The Channel Level configuration section of the screen allows the user to setup and configure the individual channels associated with the specified port. Note that in the screen show below only a single channel is available for configuration. This is because the port, shown above, is set to a MuxMode of one to one.

Channel Level Configuration						
Channel Number	Channel Name	DLCI	Net DLCI	Channel State	Mgt State	Submit
Channel 1	none	100	0	enable	active	Submit 1
Channel 2	none	N/A	disable	N/A		
Channel 3	none	N/A	disable	N/A		
Channel 4	none	N/A	disable	N/A		
Channel 5	none	N/A	disable	N/A		
Channel 6	none	N/A	disable	N/A		
Channel 7	none	N/A	disable	N/A		
Channel 8	none	N/A	disable	N/A		

Packet Information Screen

The following screen capture shows the packet information that is available for each channel. Note that the direction of the data is referenced to the ATM link. Thus Tx Data is data that is received on the Frame Relay link and transmitted out the ATM Link.

Channel Level Packet Information				
Channel Number	Channel Name	Tx Pkt - Good/Bad	Rx Pkt - Good/Bad	Clear Counters
Channel 1	none	0/0	0/0	Clear Counters
Channel 2	none	N/A	N/A	Clear Counters
Channel 3	none	N/A	N/A	Clear Counters
Channel 4	none	N/A	N/A	Clear Counters
Channel 5	none	N/A	N/A	Clear Counters
Channel 6	none	N/A	N/A	Clear Counters
Channel 7	none	N/A	N/A	Clear Counters
Channel 8	none	N/A	N/A	Clear Counters

Frame Relay (Ethernet Based) Operations

Ethernet based (or basic) Frame Relay is also available within the Patton Electronics Model 3086. This Frame Relay service can be used in a similar fashion to other Ethernet based transports within the system such as PPP or the Ethernet transport. Multiple Frame Relay transports, with different DLCI numbers, can be built upon the HDLC controller that is available with the 3086. The Frame Relay Interface is available at the Serial Interface for transport out of the Ethernet Interface or the ATM link.

Frame Relay Configuration Options

The Frame Relay transport is configurable from both the CLI and the web interface. The following configurable variables are available through both interfaces.

Channel Segment Size

The channel segment size is used to define fragmentation of the packets based on the Frame Relay Forum IA FRR.12. If this variable is set to 0 then FRR.12 “Frame Relay Fragmentation” will be disabled. If set to any other value it will set the fragmentation size used.

DLCI: Data Link Connection Identifier

The Frame Relay DLCI used for the specified channel. Must be set to a non-zero number as agreed upon by the Frame Relay connection.

Encapsulation Type

Defines the FRC1490 encapsulation type that will be used by the channel.

Port

Defines the port that should be used to setup the Frame Relay Connection. For routed applications the port should be set to “frf”. For bridged applications the port should be set to “fr”.

Rxmaxpdu

Receive side max PDU

Txmaxpdu

Transmit side max PDU

Frame Relay CLI Configuration Options

The following information describes how to configure the frame relay transport on the 3086 through the CLI interface.

Build a new Frame Relay Transport

Command: framerelay add transport <name> <port> <dci>

Add a new frame relay transport to the system

- **Name:** Any name can be given to the transport. This name will be used to reference the transport in later commands.

- **Port:** This variable defines the low layer port that will be used to transport data across the frame relay interface. For routed application the “frf” port should be used. For bridged applications the “fr” port should be used.
- **DLCI:** This variable can be set to any positive value less than 8196

Clear all Frame Relay Transports

Command: framerelay clear transport

This command can be used to clear all of the transports in the system

Delete the specified transport

Command: framerelay delete transport <name | number>

Delete a single frame relay connection using either the connection name or number

- **name:** the name used when creating the transport
- **number:** the ID number found when listing the transports

List all active Frame Relay Channels

Command: framerelay list transports

List all transports currently defined in the system

Set configuration variables for the specified frame relay transport

Command: framerelay set transport <name | number> <variable> <value>

Set a value for a specific frame relay variable

1. **name | number:** specify the connection that you would like to change
2. **variable:** any variable from the above list
3. **value:** value that you would like to set


Show detailed configuration information on the specified channel:

Command: framerelay show transport <name | number>

Display specific information about the frame relay connection

Web Based Configuration of the Frame Relay Channel

This section defines the configuration of the Frame Relay Service through the web interface. The Frame Relay channel is created through the Configuration->WAN link.



Serial Interface Configuration

This section defines the configuration options available for the serial interface on the Model 3086. This information could be used to configure the V.35 or X.21 interface available on the unit.

Configuration Variables Available

The following variables are configurable through either the CLI or web interface on the unit.

Clock Mode

Determines the source of timing for the unit.

- **Internal:** The unit will generate the appropriate clock speed defined by the speed setting of the interface.
- **External:** The unit will accept the clock from the interface and will use that clock to receive and transmit data across the interface

Clock Invert Functions: (rxClkInv – receive clock, txClkInv – transmit clock)

Setting this variable will invert the appropriate clock at the interface. This should only be used under direction of Patton Electronics technical support in order to trouble shoot system installations. Possible settings include both normal and inverted

Speed

The speed setting function will determine the clock rate that will be used by the interface. Appropriate settings include any n x 64K speed setting between 64KHz – 2048KHz.

CLI Configuration Methods

The following section defines how to configure the serial interface using the CLI. All serial interface functions are available under the “serial” directive of the CLI.

Set configuration variable

Command: serial set <variable> <value>

The following shows the user setting the speed of the serial interface to a value of 2048MHz.

```
→ serial speed 2048
```

Show current configuration settings

Command: serial show

The “serial show” command will tell the system to display the current configuration settings for the serial interface. The following shows the output of the “serial show” command.

```
→ serial show
    Clock Source : internal
    Intf Speed : 2048
    Tx Sample Point : txclk
    Tx Clk Inv : normal
    Rx Clk Inv : normal
```

Gain help about the Serial Interface

Command: serial help

This command will request that the system provide help about each of the configuration variables that are available in the serial interface. The following shows the output of the “serial help” command.

```
→ serial help
```

Serial Interface Help Screen

```
>serial show:
>      Show the current configuration of the
>      serial interface
>serial help:
>      Show this help screen
>serial clock:
>      Defines the clock mode or source of timing
>      for the serial interface.
>      options: internal - internal timing
>               external - external timing
>      notes:  For X.21 devices this setting must match
>               the DTE/DCE jumper inside the unit
>serial speed:
>      Defines the clock speed for the serial interface
>      options: n x 64K speed (n= 1..32), example: "1536" or "256"
>
> serial txClkInv:
>      Allows the user to invert the clock source
>      options: normal - use normal clock
>               inverted - use the inverted version of the clock
```


```

> serial rxClkInv:
>     Allows the user to invert the clock source
>     options: normal - use normal clock
>             inverted - use the inverted version of the clock
> serial txSamplePoint:
>     Determines whether the TxData will use the External
>     Clock or the Transmit clock to sample data
>     options: txClk - use Transmit Clock
>             extClk - use External Clock
>

```

Web Interface Configurations

The serial interface can be configured using the web interface by following the “Serial” hyperlink on the web management screen. The following screen shot shows the configuration variables as they are displayed on the web management screen.



Ping and Trace Route

The ping and trace route features are now available from both the web and CLI of the Patton Electronics' Model 3086. The following sections describe how to operate both the ping and trace route features from the CLI and web interface.

Ping commands from the CLI Interface

The ping command can be initiated from the CLI interface using the “ip” directive. The following screen shot show a ping sent and successfully received on the Ethernet interface. Then following shows an unsuccessful ping to the Ethernet interface.

```

→ ip ping 192.168.50.2
ping: PING 192.168.50.2: 32 data bytes
ping: 40 bytes from 192.168.50.2: seq=0, ttl=255, rtt=10ms

→ ip ping 192.168.50.21
ping: PING 192.168.50.21: 32 data bytes
ping: Request timed out.

```

Trace Route from the CLI Interface

The Trace Route feature is also available from the “ip” directive in the CLI interface. There are three commands available as shown below:

Define Usage: “ip traceroute”

After the command is given the system will return how to use the command and all options that are available. This is shown in the following screen capture

```
→ ip traceroute
→ usage: traceroute [-n] [-v] [-m max_ttl] [-q nqueries] [-w waittime] <ipaddr or hostname>
```

Start Trace Route: “ip traceroute start 192.168.50.2”

The “traceroute start” command will initiate the traceroute feature. The following screen shot show a successful traceroute on a local IP address.

```
→ ip traceroute start 192.168.50.2
→ traceroute to 192.168.50.2 (192.168.50.2), 30 hops max, 12 byte packets
  1  192.168.50.2 (192.168.50.2)  0 ms  0 ms  0 ms
```


If the traceroute is unsuccessful it can be canceled using the “ip traceroute stop” directive. The following screen capture shows a traceroute command that is not able to find its’ remote ip address.

```
→ ip traceroute start 192.178.15.23

→ traceroute to 192.178.15.23 (192.178.15.23), 30 hops max, 12 byte packets
  1  traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *
  2  traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *
  3  traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *traceroute: wrote 192.178.15.23 12 chars, ret=-1
    *
  4  traceroute: wrote 192.178.15.23 12 chars, ret=-1
ip traceroute stop
traceroute: cancelled
```


Ping and traceroute from the web interface:

Both the Ping and Traceroute features are available from the web interface on the Model 3086. The following screen capture show the output of a ping command that was initiated. The ping and traceroute commands can be found by following the “System” link and then the “Ping” link.



Backup and Restore Features

The backup and restore feature allows the user to store the current configuration off line on a local PC for later retrieval by the system. This feature can be found on the web under the “System” link. The following screen capture shows the “backup and restore” web page.



Backup Configuration

To backup the configuration of the unit select the “Backup” button on the configuration page. You will be prompted to save the file on the local PC. Once the file has been downloaded it is available to be restored at a later date.

Restore Configuration

To restore the configuration either type the file location or name in the box provided or select the “Browse” button on the screen. Once the file is found select the “Restore” button on the configuration page. When the configuration is loaded it will automatically set the uploaded file as the running configuration. If the configuration is required for future setup, save the configuration in the unit.