

Model 3324 VDSL Carrier-Class Aggregator

Getting Started Guide



Sales Office: +1 (301) 975-1000
Technical Support: +1 (301) 975-1007
E-mail: support@patton.com
WWW: www.patton.com

Document Number: **05813U1-001 Rev. A**
Part Number: **07MD3324-GSG**
Revised: **May 21, 2004**

Patton Electronics Company, Inc.

7622 Rickenbacker Drive
Gaithersburg, MD 20879 USA
tel: +1 (301) 975-1000
fax: +1 (301) 869-9293
support: +1 (301) 975-1007
web: www.patton.com
e-mail: support@patton.com

Copyright © 2003, Patton Electronics Company. All rights reserved.

The information in this document is subject to change without notice. Patton Electronics assumes no liability for errors that may appear in this document.

Contents

Contents	3
Compliance Information	7
Radio and TV interference	7
CE Notice	7
Service	7
About this guide	9
Audience.....	9
Structure.....	9
Precautions	9
Safety when working with electricity	10
Preventing electrostatic discharge damage	10
General observations	11
Typographical conventions used in this document.....	11
General conventions	11
Mouse conventions	12
1 General Information	13
Model 3324 overview	14
Hardware overview	15
Ethernet uplink	16
POTS/ISDN	16
VDSL ports	17
RS-232 control port	17
Power system	17
Management services	17
LED display	17
Approvals	18
2 Hardware installation	19
Introduction	20
Unpacking the Model 3324.....	20
Model 3324 chassis installation	20
Cable installation.....	21
Installing the power cables—AC power supply	21
Connecting the Ethernet uplink ports	21
Cascading configuration	22
Optional GBIC Ethernet uplink slot	24
GBIC fiber optics	24
Connecting the EIA-574, RS-232 configuration port (DCE configured)	24
Connecting the POTS/ISDN Ports	25
Connecting the VDSL Ports	25
Completing the hardware installation	26

- 3 Configuring the 3324 for operation 27**
 - Introduction29
 - Configuration prerequisites29
 - Initial configuration through the RS-232 control port30
 - Connecting the DB9-RJ45 adapter with the included cable30
 - Setting up the HyperTerminal (or similar program) session30
 - Set IP address33
 - Remote Network Management.....35
 - Controlling the Model 3324 remotely through TELNET35
 - Controlling the Model 3324 remotely through SNMP35
 - Port Status36
 - State36
 - Link Status36
 - SNR (Signal to Noise Ratio)36
 - Speed Status37
 - Duplex Status37
 - Flow Control37
 - Rate Control37
 - Port Security37
 - Port Statistics38
 - Administrator38
 - IP Address Configuration39
 - Basic Switch Settings39
 - Description39
 - MAC Address39
 - Firmware Version39
 - Default Config Value Version39
 - Advanced Switch Settings39
 - Mac Address Age-out Time39
 - Max Bridge Transit Delay Bound Control40
 - Broadcast Storm Filter40
 - Priority Queue Service Settings40
 - First Come First Service40
 - All High Before Low40
 - WRR (Weighted Round-Robin)40
 - Enable Delay Bound41
 - QoS Policy High Priority Levels41
 - Protocol Enable Settings41
 - Enable STP41
 - Enable IGMP41
 - Console Port Settings41
 - Port Control Settings42
 - State42
 - Negotiation42

Speed	42
Link Watch Dog(LWD) function:	42
Procedure for Changing VDSL Ports Speed Settings:	42
Rate Control	43
Port Security	43
Duplex	43
Flow Control	44
Trunking	44
System Priority	44
State Activity	46
Filter Database	46
IGMP Snooping	46
Static MAC Address	47
MAC Filtering	48
VLAN Configurations	48
Support Port-based VLAN	49
Tagged-based VLAN	50
Port VID	53
Ingress Filtering	53
Spanning Tree Protocol Settings	53
Port Sniffer	55
SNMP Settings	56
Security Manager	57
System Configuration (802.1X)	57
Per port Configuration	58
Misc. Configuration	58
TFTP Update Firmware	58
Using TFTP	59
TFTP Restore Configuration	59
TFTP Backup Configuration	60
Resetting the Model 3324	60
Rebooting the Model 3324	60
4 Applications	61
MxU multi-service delivery.....	62
High bandwidth backbone	63
5 Troubleshooting.....	65
Diagnosing VDSL indicators.....	66
System Diagnostics.....	66
Power and Cooling Problems	66
Installation	67
Transmission Mode	67
Cabling	67
Physical Configuration	67

System Integrity	67
CPE (Customer Premise/Remote) Side Starts Link Watch Dog	67
6 Contacting Patton for assistance	69
Introduction	70
Contact information	70
Warranty Service and Returned Merchandise Authorizations (RMAs)	70
Warranty coverage	70
Out-of-warranty service	70
Returns for credit	70
Return for credit policy	71
RMA numbers	71
Shipping instructions	71
A Specifications	73
VDSL line interface	75
POTS-ISDN interface	75
Modulation	75
Frequency range	75
Transmission	75
Management	75
Ethernet standards	75
Management standards	75
LED indicators	75
Power supply	75
Compliance	75
Environment	75
Operating temperature	75
Humidity	76
Dimensions	76
Weight	76
B Cabling	77
Introduction	78
C VDSL Spectrum	81
Introduction	82
D Example of VLAN Setting	83
Introduction	84

Compliance Information

Radio and TV interference

The Model 3324 generates and uses radio frequency energy, and if not installed and used properly—that is, in strict accordance with the manufacturer's instructions—may cause interference to radio and television reception. The Model 3324 has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection from such interference in a commercial installation. However, there is no guarantee that interference will not occur in a particular installation. If the Model 3324 does cause interference to radio or television reception, which can be determined by disconnecting the cables, the user is encouraged to try to correct the interference by one or more of the following measures: moving the computing equipment away from the receiver, re-orienting the receiving antenna, and/or plugging the receiving equipment into a different AC outlet (such that the computing equipment and receiver are on different branches).

CE Notice

The CE symbol on your Patton Electronics equipment indicates that it is in compliance with the Electromagnetic Compatibility (EMC) directive and the Low Voltage Directive (LVD) of the Union European (EU). A Certificate of Compliance is available by contacting Technical Support.

Service

All warranty and non-warranty repairs must be returned freight prepaid and insured to Patton Electronics. All returns must have a Return Materials Authorization number on the outside of the shipping container. This number may be obtained from Patton Electronics Technical Services at:

- Tel: **+1 (301) 975-1007**
- Email: **support@patton.com**
- URL: **www.patton.com**

Note Packages received without an RMA number will not be accepted.

About this guide

This guide describes installing and configuring a Patton Electronics Model 3324 VDSL Carrier Class Aggregator. By the time you are finished with this guide, your Model 3324 will be connected to the remote VDSL modems and transferring data. The instructions in this guide are based on the following assumptions:

- The Model 3324 will connect to an 10/100/1000Base-TX Network Uplink or Device
- There is a LAN connected to the Ethernet port of the 3324
- Users will be connected to remote VDSL modems.

Audience

This guide is intended for the following users:

- Operators
- Installers
- Maintenance technicians

Structure

This guide contains the following chapters and appendices:

- [Chapter 1](#) describes the 3324
- [Chapter 2](#) describes installing the 3324 hardware
- [Chapter 3](#) describes configuring the 3324 for use
- [Chapter 4](#) describes Model 3324 applications
- [Chapter 5](#) contains troubleshooting information
- [Chapter 6](#) contains information on contacting Patton technical support for assistance

For best results, read the contents of this guide *before* you install the router.

Precautions

Notes and cautions, which have the following meanings, are used throughout this guide to help you become aware of potential Router problems. *Warnings* relate to personal injury issues, and *Cautions* refer to potential property damage.

Note Calls attention to important information.



WARNING

The shock hazard symbol and WARNING heading indicate a potential electric shock hazard. Strictly follow the warning instructions to avoid injury caused by electric shock.



WARNING

The alert symbol and WARNING heading indicate a potential safety hazard. Strictly follow the warning instructions to avoid personal injury.



CAUTION

The shock hazard symbol and CAUTION heading indicate a potential electric shock hazard. Strictly follow the instructions to avoid property damage caused by electric shock.



CAUTION

The alert symbol and CAUTION heading indicate a potential hazard. Strictly follow the instructions to avoid property damage.

Safety when working with electricity



CAUTION

Mains Voltage: Do not open the case when the power cord is connected. For systems without a power switch, line voltages are present within the power supply when the power cord is connected.



WARNING

Hazardous network voltages are present in WAN ports regardless of whether power to the SmartNode is ON or OFF. To avoid electric shock, use caution when near WAN ports. When detaching cables, detach the end away from the SmartNode first.



WARNING

Do not work on the system or connect or disconnect cables during periods of lightning activity.



CAUTION

Before opening the chassis, disconnect the telephone network cables to avoid contact with telephone line voltages.



WARNING

Ultimate disposal of this equipment must be handled according to all applicable national laws and regulations.

Preventing electrostatic discharge damage

When starting to install interface cards place the interface card on its shielded plastic bag if you lay it on your bench.



Electrostatic Discharge (ESD) can damage equipment and impair electrical circuitry. It occurs when electronic printed circuit cards are improperly handled and can result in complete or intermittent failures. Do the following to prevent ESD:

- Always follow ESD prevention procedures when removing and replacing cards.
- Ensure that the SmartNode chassis is electrically connected to earth ground.
- Wear an ESD-preventive wrist strap, ensuring that it makes good skin contact. Connect the clip to an unpainted surface of the chassis frame to safely channel unwanted ESD voltages to ground.
- To properly guard against ESD damage and shocks, the wrist strap and cord must operate effectively. If no wrist strap is available, ground yourself by touching the metal part of the chassis.

General observations

- Clean the case with a soft slightly moist anti-static cloth
- Place the unit on a flat surface (or optionally in a rack for the SN2x00) and ensure free air circulation
- Avoid exposing the unit to direct sunlight and other heat sources
- Protect the unit from moisture, vapors, and aggressive liquids

Typographical conventions used in this document

This section describes the typographical conventions and terms used in this guide.

General conventions

The procedures described in this manual use the following text conventions:

Table 1. General conventions

Convention	Meaning
Garamond blue type	Indicates a cross-reference hyperlink that points to a figure, graphic, table, or section heading. Clicking on the hyperlink jumps you to the reference. When you have finished reviewing the reference, click on the Go to Previous View button  in the Adobe® Acrobat® Reader toolbar to return to your starting point.
Futura bold type	Commands and keywords are in boldface font.
Futura bold-italic type	Parts of commands, which are related to elements already named by the user, are in boldface italic font.
Italicized Futura type	Variables for which you supply values are in <i>italic</i> font
Futura type	Indicates the names of fields or windows.
Garamond bold type	Indicates the names of command buttons that execute an action.

Table 1. General conventions

Convention	Meaning
< >	Angle brackets indicate function and keyboard keys, such as <SHIFT>, <CTRL>, <C>, and so on.
[]	Elements in square brackets are optional.
{a b c}	Alternative but required keywords are grouped in braces ({ }) and are separated by vertical bars ()
blue screen	Information you enter is in blue screen font.
screen	Terminal sessions and information the system displays are in screen font.
node	The leading IP address or nodename of a SmartNode is substituted with node in boldface italic font.
SN	The leading SN on a command line represents the nodename of the SmartNode
#	An hash sign at the beginning of a line indicates a comment line.

Mouse conventions

The following conventions are used when describing mouse actions:

Table 2. Mouse conventions

Convention	Meaning
Left mouse button	This button refers to the primary or leftmost mouse button (unless you have changed the default configuration).
Right mouse button	This button refers the secondary or rightmost mouse button (unless you have changed the default configuration).
Point	This word means to move the mouse in such a way that the tip of the pointing arrow (referred to as the <i>cursor</i>) on the screen ends up resting at the desired location.
Click	Means to press and release the left or right mouse button one time quickly (as instructed in the procedure). Make sure you do not move the cursor while clicking a mouse button.
Double-click	Means to press and release the same mouse button two times quickly. Make sure you do not move the cursor while clicking a mouse button.
Drag	This word means to place the cursor and then hold down the left or right mouse button (as instructed in the procedure) as you move the mouse to a new location. When you have moved the cursor to the desired location, you can release the mouse button.

Chapter 1 **General Information**

Chapter contents

Model 3324 overview	14
Hardware overview	15
Ethernet uplink	16
POTS/ISDN	16
VDSL ports	17
RS-232 control port	17
Power system	17
Management services	17
LED display	17
Approvals	18

Model 3324 overview

The Patton Model 3324 VDSL (see [figure 1](#)) networking solution delivers cost-effective, high-performance broadband access to multi-unit buildings (hotels, apartments, and multi-tenant unit office buildings) and enterprise campus environments such as factories, educational campuses, and medical facilities. VDSL technology dramatically extends Ethernet over existing Category 1, 2, or 3 wiring at speeds from 5, 10, or 15 Mbps (full duplex) and distances up to 4,921, 3,937, or 3,281 feet (1,500, 1,200, or 1,000 meters). The Model 2234 delivers broadband service on the same infrastructure as *plain old telephone service* (POTS), digital telephone service, and ISDN service. In addition, VDSL supports modes compatible with symmetric digital subscriber line, allowing service providers to provision VDSL to buildings where broadband services may already exist.

The VDSL solution includes Patton Model 3324 (VDSL Access Concentrator), and Model 1058/CP (VDSL Customer Premise Modem).

The VDSL solution delivers everything needed to quickly deploy an Ethernet-based network with the performance required to deliver high-speed Internet access at much greater distances and drive services like IP telephony and audio/video streaming. With this technology, a broad range of customers can benefit from lower operating Costs and rapid deployment. The VDSL solution provides multicast, Layer 2 quality of service (QoS), Link Aggregation (LACP) dynamic trunking groups, security, GVRP, IGMP for VOD (Video on demand) and SNMP RMON management and Web-based Switch network management.

The Patton Model 3324 is a bridge between external Internet backbone through a router for IP sharing and the building 110D telephone rack or telephone box. It utilizes the available telephone wire to enable high-speed Internet access to building's residents. The Patton Model 3324 uses the phone line networking technology endorsed by the VDSL (Very High Data Rate DSL), and the 3324 utilizes already existing telephone wire to deliver 5/10/15 Mbps Internet access on each RJ-21 port. This gives users a low-cost, end-to-end solution that eliminates the need to train installation teams on multiple systems.




Figure 1. Model 3324 Carrier-Class Aggregator

Hardware overview

The Model 3324 combines networking and voice services by concentrating 24 x VDSL (Network) and 24 x POTS/ISDN ports for transport over a single phone grade twisted pair in a single 1U managed chassis. The 3324 (see [figure 2](#) and [figure 3](#) on page 16) comprises a 1U-high 19-inch wide chassis that contains a motherboard and on-board POTS/ISDN splitter and an AC power supply. A full set of LEDs are present on the chassis front panel along with all electrical connections. This makes both quick status checks and network connections a snap. LEDs are present to monitor the Ethernet uplink link and activity, VDSL link and activity, and power connections. One IEC-320 receptacle is provided for AC power input.




Figure 2. Model 3324 front panel connectors and LEDs

VDSL ports

The 24 VDSL ports operate at data-rates up to 15 Mbps symmetrical and are accessible via the RJ-21X 50-pin telco connector. Each port uses one twisted-pair (2-wires) for symmetrical communication. The VDSL ports concentrate the POTS/ISDN (voice) and data into one output on the VDSL ports. Other features include:

- QAM line encoding
- "Plug-and-Play" automatic configuration between the Model 3324 VDSL aggregator and the VDSL CPE modems
- Built-in surge protection
- VDSL configuration parameters and line status indicators
- Bandwidth management (speed rate control) from 100 kbps to 5/10/15 Mbps
- Signal-to-noise ratio (SNR) for checking wiring quality and cross talk

RS-232 control port

The RS-232 port provides for initial configuration of the Model 3324. The RS-232 port supports:

- Asynchronous data rate of 9600kbps, 8 data bits, no parity, 1 stop bit, flow control none.
- An DB9 connector
- A management interface that supports VT-100 terminals

Power system

Universal-input voltage range, 100–240 VAC, 50/60 Hz via IEC-320 connectors

Management services

- Out-of-band RS-232 configuration port for management and control
- SNMP version 1 configuration management
- MIB II
- TELNET Ethernet
- Remote software upgrade via FTP/TFTP
- Built-in HTTP server for complete configuration and control using a standard Web browser

LED display

LEDs are present to monitor the Ethernet Uplink Link and Activity, VDSL Link and Activity, and Power connections.

- **POWER:** Green LED is ON if power is being applied. If power is lost the green LED is OFF
- **POST** (*power on self test*): If LED is steady green Model 3324 is self-testing
- **ACT** (Receiving LEDs): LED flashes green when receiving or transmitting data
- **Speed 100/Speed 1000:** Steady yellow indicates communications have been set at 100 or 1000 Mbps

- **FD:** Steady yellow if working at full-duplex, OFF if working at half-duplex
- **LINK:** Steady green when the Model 3324 and CP has established a link, OFF when link is down

Approvals

The Model 3324 has achieved the following approvals and certifications:

- Safety
 - UL1950 (MET)
 - Industry Canada (cMET)
- RTTE Directive (CE Mark)
 - EMC Directive 89/336/EEC
 - Low Voltage Directive 73/23/EEC (EN 60950)
 - ITU-T CTR 12
 - ITU-T CTR 13
- EMC
 - FCC Part 15, Subpart B, Class A
- Telecom
 - FCC Part 68
 - Industry Canada

Chapter 2 **Hardware installation**

Chapter contents

Introduction	20
Unpacking the Model 3324.....	20
Model 3324 chassis installation	20
Cable installation.....	21
Installing the power cables—AC power supply	21
Connecting the Ethernet uplink ports	21
Cascading configuration	22
Optional GBIC Ethernet uplink slot	24
GBIC fiber optics	24
Connecting the EIA-574, RS-232 configuration port (DCE configured)	24
Connecting the POTS/ISDN Ports	25
Connecting the VDSL Ports	25
Completing the hardware installation	26

Introduction

This chapter contains the following procedures for installing the Model 3324:

- “Unpacking the Model 3324”—lists the contents in the Model 3324 shipping container
- “Model 3324 chassis installation”—describes installing the Model 3324 on a flat surface or in a standard 19-inch rack
- “Cable installation” on page 21—describes installing the power and network interface cables
- “Completing the hardware installation” on page 26—describes testing the Model 3324 hardware to verify that it is ready for software configuration

Unpacking the Model 3324

Inspect the shipping carton for external damage. Note any damage before removing the container contents. Report equipment damage to the shipping carrier immediately for claim purposes. Save all packing materials in case you need to return an item to the factory for servicing.

The Model 3324 comes with the following items:

- The Model 3324 VDSL Carrier Class Aggregator
- Install kit
 - 2 DB9-RJ45 (EIA-561) adapters, one to connect to the Model 3324 and one to connect to PC serial port
 - 1 RJ-45-to-RJ-45 cable to connect between the two adapters
- 2 Rack mounting brackets
- 4 Screws
- 4 Plastic feet
- *Model 3324 VDSL Carrier-Class Aggregator User Guide* on CD-ROM

Note Power cables are shipped separately from the Model 3324 DACS.

You will need two 5-foot (1.5-meter) RJ-21 male-to-male Telco connector cables.

Model 3324 chassis installation

Do the following:

1. If you have not done so already, remove the Model 3324 from its shipping container.

Note The Model 3324 should be placed as close as possible to the termination jack provided by the Telco. Avoid installing the Model 3324 in a location where the power cords or network interface cables could be accidentally disconnected. The location should be well ventilated, dry, and not in direct sunlight. Do not block the Model 3324 cooling fans.

2. If you are installing the Model 3324 in a 19-inch rack, go to step 3. Otherwise, place the Model 3324 at the desired location, then go to “Cable installation” on page 21.

3. Install the rack mounting ears onto the Model 3324 using the mounting hardware provided.
4. Place the Model 3324 at the desired position in the rack.
5. Secure the Model 3324 in position with the mounting screws.

Cable installation

This section describes installing the power, ground, and network interface cables.

Installing the power cables—AC power supply

This section describes installing the power cables into the IEC-320 connectors on the DACS. Do not connect the male end of the power cables to the power outlet at this time. Do the following:

1. Install a power cable into an IEC-320 connector (see [figure 3](#) on page 16). The AC main socket outlet shall be within 10 feet (3 meters) of the equipment and shall be easily accessible.

Connecting the Ethernet uplink ports

The Model 3324 has two auto-negotiating 10/100/1000Base-TX Ethernet interfaces that support full or half-duplex operation. The devices attached to these ports also must support auto-negotiation unless they always operate at half-duplex. Both ports feature auto MDI-X.

Note Make sure the Ethernet CAT-5 cable is not longer than 328 feet (100 meters).

Ethernet uplink port #25 is used to connect to devices such as servers, routers, or switches. Port #25 is your primary uplink (your connection to the service provider). Port #26 is used for cascading up to four Model 3324s together. Port #25 and port #26 will auto-sense the correct speed of the local LAN and automatically negotiate half- or full-duplex operation.




Figure 4. Cascading configuration

Cascading configuration

When cascading more than two Model 3324s (see [figure 4](#)), the default settings are set to full duplex, and 1000 Mbps via the daisy-chain port. The maximum number of Model 3324s that can be cascaded is four units. If more than four units must be cascaded, an Ethernet switch will be required (see configuration example shown in [figure 5](#) on page 23).




Figure 5. Cascade configuration using Ethernet switch

Optional GBIC Ethernet uplink slot

The Model 3324 supports the use of one GBIC interface auto-link function. Normal Ethernet uplink port status default is copper (RJ-45), but you can use the hot-swap capability—modules can be exchanged without turning off power—of the Model 3324 to quickly change the uplink media to fiber.

GBIC fiber optics

A gigabit interface converter (GBIC) is a transceiver that converts electric currents (digital highs and lows) to optical signals, and optical signals to digital electric currents. The GBIC is typically employed in fiber optic and Ethernet systems as an interface for high-speed networking. The data transfer rate is 1.25 gigabits per second (Gbps).

GBIC modules enable technicians to easily configure and upgrade electro-optical communications networks. The typical GBIC transceiver is a plug-in module that supports hot-plugging. The devices are economical, because they eliminate the necessity for replacing entire boards at the system level. Upgrading can be done with any number of units at a time, from an individual module to all the modules in a system. GBIC is compliant with the *Gigabit Interface Converter Specification, Rev. 5.4 (MOD_DEF4)* industry standard.

	Mode	Wavelength	Bit Rate	Voltage	Power Margin
1	LX-Single Mode	1310 nm	1.25 Gbps	5V	10.5 dB (6 miles/10 km)
2	SX-Multi Mode	850 nm	1.25 Gbps	5V	8.5 dB (1800 feet/550 m)

Connecting the EIA-574, RS-232 configuration port (DCE configured)

Install the supplied RJ-45-to-RJ-45 cable between the (2) DB9-RJ45 adapter and the RS-232 port (see [figure 2](#) on page 15) and an open serial port on your computer. If you need to assemble your own cable, refer to the pinout diagram in [figure 6](#).




Figure 6. DB-9-to-RJ-45 cable diagram

Connecting the POTS/ISDN Ports

The remote (customer premise) VDSL modems will receive their POTS/ISDN connections from the Model 3324 via the VDSL twisted pair. The POTS/ISDN services from a PBX are connected into the 3324 via a RJ-21X cable. Consult Appendix B, “Cabling” on page 77 in order to connect the properly match up the POTS/ISDN (VOICE) and VDSL Data to the selected VDSL modem port on the Model 3324 and CPE.

1. Connect the RJ-21X connector from a punch down block or directly from the PBX into the 50-pin RJ-21X receptacle on the front of the 3324 labeled POTS/ISDN.
2. Only 24 of the twisted pairs will be used since there are 24 VDSL modem connections, each being a 2-wire connection. When inserting the RJ-21 plug, be sure the tab on the plug clicks into position to ensure that is properly fastened to the Model 3324.

Connecting the VDSL Ports

The remote (Customer Premise) VDSL modems are connected to the 3324 via the RJ-21X cable. Consult Appendix B, “Cabling” on page 77 in order to connect the CP VDSL modems to the selected VDSL modem port on the 3324.

Note The 2-wire VDSL modem lines are polarity insensitive so you only need to match the correct twisted pairs without being concerned about matching the individual wires of the twisted pair. Wire must be 18–26 AWG (28 gauge or above is *not* recommended).

1. Connect the RJ-21X connector of the cable into the 50-pin RJ-21X receptacle on the front of the 3324 labeled VLINK.
2. The other end of the cable has 25 non-terminated twisted-pairs for connection to punch-down blocks. Select the twisted-pairs which will be used for active VDSL modem connections and terminate on the punch-down blocks. Only 24 of the twisted pairs will be used since there are 24 VDSL modem connections, each being a 2-wire connection. When inserting the RJ-21 plug, be sure the tab on the plug clicks into position to ensure that is properly fastened to the Model 3324.
3. Select and attach the appropriate twisted pair from each remote (CP) VDSL modem on punch-down blocks for connection to the chosen VDSL port in the Model 3324.

Completing the hardware installation

This section verifies that the 3324 hardware is operational to the point where you can begin configuring the software settings. Do the following:



CAUTION

The Model 3324's power supply automatically adjusts to accept an input voltage from 100 to 240 VAC (50/60 Hz), 1.5A.

Verify that the proper voltage is present before plugging the power cord into the receptacle. Failure to do so could result in equipment damage.

1. Verify that the AC power cord used with your 3324 is compatible with local standards. If it is not, refer to Chapter 6, “[Contacting Patton for assistance](#)” on page 69 to find out how to replace it with a compatible power cord.
2. Connect the male end of the power cord to an appropriate power outlet.
3. Verify that the green *POWER* LED is lit. If the *POWER* LED is flashing green, refer to Chapter 5, “[Troubleshooting](#)” on page 65.

Hardware installation is complete. Refer to Chapter 3, “[Configuring the 3324 for operation](#)” on page 27.

Chapter 3 **Configuring the 3324 for operation**

Chapter contents

Introduction	29
Configuration prerequisites	29
Initial configuration through the RS-232 control port	30
Connecting the DB9-RJ45 adapter with the included cable	30
Setting up the HyperTerminal (or similar program) session	30
Set IP address	33
Remote Network Management	35
Controlling the Model 3324 remotely through TELNET	35
Controlling the Model 3324 remotely through SNMP	35
Port Status	36
State	36
Link Status	36
SNR (Signal to Noise Ratio)	36
Speed Status	37
Duplex Status	37
Flow Control	37
Rate Control	37
Port Security	37
Port Statistics	38
Administrator	38
IP Address Configuration	39
Basic Switch Settings	39
Description	39
MAC Address	39
Firmware Version	39
Default Config Value Version	39
Advanced Switch Settings	39
Mac Address Age-out Time	39
Max Bridge Transit Delay Bound Control	40
Broadcast Storm Filter	40
Priority Queue Service Settings	40
First Come First Service	40
All High Before Low	40
WRR (Weighted Round-Robin)	40
Enable Delay Bound	41
QoS Policy High Priority Levels	41
Protocol Enable Settings	41
Enable STP	41
Enable IGMP	41

Console Port Settings	41
Port Control Settings	42
State	42
Negotiation	42
Speed	42
Link Watch Dog(LWD) function:	42
Procedure for Changing VDSL Ports Speed Settings:	42
Rate Control	43
Port Security	43
Duplex	43
Flow Control	44
Trunking	44
System Priority	44
State Activity	46
Filter Database	46
IGMP Snooping	46
Static MAC Address	47
MAC Filtering	48
VLAN Configurations	48
Support Port-based VLAN	49
Tagged-based VLAN	50
Port VID	53
Ingress Filtering	53
Spanning Tree Protocol Settings	53
Port Sniffer	55
SNMP Settings	56
Security Manager	57
System Configuration (802.1X)	57
Per port Configuration	58
Misc. Configuration	58
TFTP Update Firmware	58
Using TFTP	59
TFTP Restore Configuration	59
TFTP Backup Configuration	60
Resetting the Model 3324	60
Rebooting the Model 3324	60

Introduction

This chapter contains the following procedures for configuring the Model 3324 for operation:

- “Configuration prerequisites”—lists the items you need to have on hand before configuring the 3324.
- “Initial Configuration through the RS-232 Control Port” on page XX—describes setting up the 3324’s LAN IP address, netmask, and gateway parameters.
- “Using a Web browser to complete Model 3324 configuration” on page XX—describes the process to complete the software installation parameters—that is, to bring it on-line. The steps are:
 - Setting the switch features
 - Setting the console port
 - Setting the VSDL port controls
 - Trunking (LACP)
 - Forwarding and filtering database
 - Setting VLAN configurations
 - Spanning tree
 - Port sniffer
 - SNMP management
 - Security manager
 - 802.1X system configuration
 - TFTP updates
 - Backup configuration
 - Reset and Reboot
- “Saving your configuration” on page 47—tells you how to save the configuration settings.
- “Completing the installation” on page 49—describes testing the 3324 to verify that it is fully operational.

Configuration prerequisites

You will need the following to configure the Model 3324:

- A PC that includes the following:
 - RS-232/V.24 serial port
 - VT-100 terminal program, e.g., HyperTerminal
 - Ethernet port
 - Web browser (e.g., Microsoft Internet Explorer)
- You will need the following information to configure the Model 3324:
 - The IP address and subnet mask for the 3324’s Ethernet port

- The IP address of the default gateway
- The 3324 VDSL port number to which each customer premises equipment (CPE) VDSL modem will be connecting
- The data rate at which each CPE VDSL will be operating
- The final destination of the CPE's VDSL modem connection

Initial configuration through the RS-232 control port

Initially you must configure the 3324's IP address and—in rare instances—change the netmask from the default settings.

Note Do not connect power or the Ethernet connection to the Model 3324 at this time.

Connecting the DB9-RJ45 adapter with the included cable

Do the following:

1. Connect the DB9-RJ45 adapter to your PC's RS-232 serial port and 3324's console port.
2. Connect the RJ45-RJ45 cable between the adapters which you installed in step 1 (see figure X on page XX).

Setting up the HyperTerminal (or similar program) session

Do the following:

1. Open a HyperTerminal session by double-clicking on *HYPERTERM.EXE*.



Figure 7. Connection Description window

Type a connection name (e.g., *3324 Config*), select an icon, then click **OK** (see figure 7).



Figure 8. Connect To window

3. On the *Connect To* window (see [figure 8](#)), set *Connect using:* to one of the options named *Direct to ComX* (where the *X* refers to the number identifying the RS-232 serial port on the PC). In the following procedure, *Com1* will be the used as the port identifier.
4. Click on **OK**.
5. The *COM1 Properties* window displays.
6. Configure your COM port settings as shown in [figure 9](#), then click **OK**.
 - Set *Bits per second* at *9600* to the content window.
 - Set *Flow control* at *None*




Figure 9. COM1 Properties window

7. Click on the **File** menu, then select **Properties**.

8. Configure the settings for *Function, arrow and ctrl keys act as to Terminal keys* as shown in [figure 10](#), then click **OK**.




Figure 10. Terminal keys configuration

9. Connect the male end of the Model 3324 power cable to the power outlet.
10. When the PC connects with the Model 3324, boot up information will display on your HyperTerminal connection window, followed by a login request window.
11. At the login window type the following login and password:

Login name: admin

Password: 123

The Main Menu displays (see [figure 11](#) on page 33)

Note Operational keys are as follows:
 Tab=Next Item; Backspace=Previous Item; Enter=Select ItemSelect




Figure 11. Main Menu

Set IP address

1. Do the following:
2. Choose *Switch Static Configuration* from the *Main Menu* screen (see [figure 11](#)).




Figure 12. Switch Configuration menu

3. Choose *Administration Configuration* (see [figure 12](#)). This takes you to the *Device Configuration* page (see [figure 13](#) on page 34).

```

Intelligent Switch : Device Configuration
=====

Change Username

Change Password

Device Information

IP Configuration

Previous Menu

Configure the IP information.
Tab=Next Item      BackSpace=Previous Item      Enter=Select Item

```

Figure 13. Device Configuration menu

4. Choose *IP Configuration*. This takes you to the *IP Configuration* page (see [figure 13](#)).

```

VDSL Switch :      IP Configuration
=====

IP Address   : 192.168.16.254

Subnet Mask  : 255.255.255.0

Gateway      : 192.168.16.1

actions->    <Edit>          <Save>          <Quit>
Configure the IP Information.
Tab=Next Item  BackSpace=Previous Item  CTRL+A=Action menu  Enter=Select Item

```

Figure 14. IP Configuration page

5. Choose **Edit** item to change ip address, subnet mask and gateway.
6. Use **CTRL+A** to go back to actions.
7. Choose **Save** item to save change and return to *System Configuration* page.
8. Choose **Previous Menu** item to exit *System Configuration* page.
9. Choose **Main Menu** item to exit the 3324 Switch Configuration page and return to Main Menu.

10. Choose **Reboot System** item.
11. Choose **Restart** item to reboot your Model 3324.

Remote Network Management

Now that you have established an IP Address through the local serial console port (RS-232 port) you now have the ability to remotely control and monitor your Patton Model 3324 through Telnet or SNMP (WWW). You can also change your computer's IP domain same with VDSL SWITCH. Then use the default IP address to control this VDSL concentrator.

Controlling the Model 3324 remotely through TELNET

To enter Telnet, type the IP address of the Model 3324 to connect management system. And type user name and password.

Default User Name: admin
Default Password: 123

Note For security reasons the Model 3324 will only allow either a Telnet session or Console Port session at any given time. When ending a Console Port session it is important to log out. If a user does not log out you will not be able to log into the Model 3324 using Telnet. SNMP Management does not have a user login limit.

Controlling the Model 3324 remotely through SNMP

The Patton Model 3324 provides a web browser to manage and monitor the performance of the Model 3324.

The default values are as follows:

- **Default IP Address:** 192.168.16.250
- **Subnet Mask:** 255.255.255.0
- **Default Gateway:** 192.168.16.1
- **User Name:** admin
- **Password:** 123

You can browse <http://192.168.16.250>, just type user name and password as above.



Figure 15. Web Management Home Overview



Model 3324 Carrier Class VDSL Concentrator

Figure 16. Welcome page

Port Status

Through this page an administrator can see every ports status, user settings, and the negotiation results.

Port Status

The following information provides a view of the current status of the unit.

Port	State		Link	SNR		Speed		Duplex		Flow Control			Rate Control(100K)		Priority	Security
	Config	Atual		Value	Unit	Config	Atual	Config	Atual	Config		Atual	Ingr	Egr		
			Full							Half						
PORT1	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT2	On	On	Down	17	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT3	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT4	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT5	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT6	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT7	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT8	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT9	On	On	Down	16	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off
PORT10	On	On	Down	17	db	10	10	Full	Full	On	On	On	Off	Off	Disable	Off

Figure 17. Port status page

State

Display Port status disable or enable. “UNLINK” is treated as “OFF”

Link Status

DOWN is “NO LINK”, UP is “LINK”

SNR (Signal to Noise Ratio)

The SNR is used to indicate the quality of the link. If the SNR value is greater than (>) 25, it means a good link has been established between the 3324 and CPE.

Speed Status

- Config: Displays user configured port settings 1-24 at 5/10/15 Mbps and port 25/26 at 10/100/1000 Mbps
- Actual: Displays the actual line rate the individual links have achieved

Duplex Status

- Config: Displays user configured Full or Half-Duplex Mode
- Actual: Displays which mode is actually being achieved

Flow Control

Full-Displays the flow control status as enabled ON or disabled OFF

- Half: Displays the backpressure is in enabled ON or disabled OFF
- Actual: Displays what flow control is being used


Rate Control

- Ing: Displays the port effective ingress rate of user setting
- Egr: Displays the port effective egress rate of user setting.

Port Security

- Displays if a port is receiving Priority. If it is, it will read *Enabled*, if not, *Disabled*
- Port Security: Displays the user setting, it is either *OFF* or *ON*

Note To read a specific port's information double-click on the port # you wish to examine.



Port	4
State	On
Link	Up
TxGoodPkt	5025
TxBadPkt	0
RxGoodPkt	3374
RxBadPkt	0
TxAbort	0
Collision	0
DropPkt	6


From this Port Status you can read the following:

- Port: This is the port # you have double-clicked
- State:
- Link:

- TxGoodPkt:
- TxBadPkt:
- RxGoodPkt:
- RxBadPkt:
- TxAbort:
- Collision:
- DropPkt:

Port Statistics

This page provides an administrator a quick overview on every ports LAN statistics. These statistics can be reset at any time by double clicking the reset icon at the bottom of the menu screen.



The following information provides a view of the current status of the unit.

Port	State	Link	TxGoodPkt	TxBadPkt	RxGoodPkt	RxBadPkt	TxAbort	Collision	DropPkt
FORT1	Off	Down	0	0	0	0	0	0	0
FORT2	Off	Down	0	0	0	0	0	0	0
FORT3	Off	Down	0	0	0	0	0	0	0
FORT4	Off	Down	0	0	0	0	0	0	0
FORT5	On	Up	5737	0	3389	0	0	0	6
FORT6	Off	Down	0	0	0	0	0	0	0
FORT7	Off	Down	0	0	0	0	0	0	0
FORT8	Off	Down	0	0	0	0	0	0	0
FORT9	Off	Down	0	0	0	0	0	0	0
PORT10	Off	Down	0	0	0	0	0	0	0
PORT11	Off	Down	0	0	0	0	0	0	0

Administrator

Most of the management functions of the 3324 can be found in this menu. Management functions include:

- IP address
- Switch settings
- Console port information
- Port controls
- Trunking
- Filter database
- VLAN configuration
- Spanning tree

- Port Sniffer
- SNMP
- Security Manager
- 802.1x configuration

IP Address Configuration

The administrator can configure the IP Address from this screen. Once the change has been made, click the Apply icon at the bottom of the menu screen. Once the IP Address has been modified by the administrator the box must be reset to for the new IP Address to be implemented.

IP Address	192.168.223.100
Subnet Mask	255.255.248.0
Gateway	192.168.223.254

Apply Help

Basic Switch Settings

Description

Display the name of the device

MAC Address

The unique hardware address assigned by the manufacturer (default)

Firmware Version

Displays the 3324's hardware revision

Default Config Value Version

Displays write to default EEPROM value table version

Switch Settings	
Basic Module Info	
Description	Intelligent 24+2G VDSL Switch
MAC Address	004063800108
Firmware version	v1.4
Hardware version	A01.00
Default config value version	V01.00

Advanced Switch Settings

Mac Address Age-out Time

Enter the number of second that in inactive MAC address remains in the 3324's address table. The valid range is between 300–765 seconds. (Default 300 seconds).

Max Bridge Transit Delay Bound Control

Limits the packets queuing time in the concentrator. When enabled the packets queued past the time limit will be dropped. The valid time limits are 1 second, 2 seconds, 4 seconds, and off. (Default is 1 second)

Broadcast Storm Filter

To configure Broadcast Storm Control, enable it and set the upper threshold for the individual ports. The threshold is the percentage of the port's total bandwidth used by broadcast traffic. When broadcast traffic for a port rises about the threshold, the broadcast storm control will become active. The valid range is 5%, 10%, 15%, 20%, 25%, and OFF.

The screenshot shows the 'Switch Settings' page with the 'Advanced' tab selected. Below the tabs, there is a message: 'Enter the settings, then click Submit to apply the changes on this page.' The settings shown are:

- MAC Table Address Entry Age-Out Time: 300 seconds
- Max bridge transmit delay bound control: OFF
- Broadcast Storm Filter Mode: OFF

Priority Queue Service Settings

First Come First Service

The sequence of packets sent is dependent on the order the packets arrived.

The screenshot shows the 'Priority Queue Service' configuration page. The settings are:

- First Come First Service
- All High before Low
- WRR: High weight: 2, Low weight: 1
- Enable Delay Bound: Max Delay Time: 255 ms
- Qos Policy: High Priority Levels
- Level0 Level1 Level2 Level3 Level4 Level5 Level6 Level7

All High Before Low

The high priority packets are sent before the low priority packets.

WRR (Weighted Round-Robin)

Select the preference given to packets in the 3324's high-priority queue. These options represent the number of high priority packets that will be sent before one low priority packet is sent. For example, 5 High/2 Low means that the 3324 will send the 5 high priority packets before sending the 2 low priority packets.

Enable Delay Bound

Limits the low priority packets queuing time in switch. The Default Max Delay Time is 255ms. If the low priority packets stay in 3324 exceeds Max Delay Time, it will be sent. The valid range is 1-255 ms.

Note Make sure that the “Max Bridge Transit Delay Bound Control” is enabled before the Delay Bound is enabled because enable Delay Bound must work under “Max Bridge Transit Delay Bound Control” is enabled situation.

QoS Policy High Priority Levels

0-7 priority level can map to high or low queue.

Protocol Enable Settings


This menu allows you to enable Spanning Tree Protocol and IGMP.

Enable STP

Default recommend to enable Spanning Tree Protocol

Enable IGMP

Enable Internet Group Multicast Protocol



Console Port Settings

The console uses a standard UART interface that communicates with serial port. The administrator can use the windows program, HyperTerminal, to access the Model 3324.

- Bits per seconds: 9600
- Data Bits: 8
- Parity: none

- Stop Bits: 1
- Flow Control: none

Port Control Settings

This section shows you how to change the various ports of the Model 3324.

State

The administrator can disable or enable any port.

- Enable (ON)
- Disable (OFF)

Negotiation

The administrator can set the auto negotiation mode for the CPE devices through the 3324. The three choices are:

- Auto
- Nway (TM) (specify the speed/duplex on this port and enable auto-negotiation)
- Force of Per Port

Speed

User can set 5Mbps/10Mbps/15Mbps/LWD for ports 1-24. For ports 25 and 26 the options available are 10/100/1000Mbps.

10/100Mbps speed on Port25-Port26 (based on copper uplink). If a GBIC 1000Base-FX is used then then the uplink port will be forced to 1000Mbps.

The following distance are achievable between the 3324 and VDSL CPE when using standard 24 Gauge (0.5mm) cable:

- 5 Mbps -> 4,920 feet (1.5km)
- 10 Mbps -> 3,940 feet (1.2km)
- 15 Mbps -> 3,280 feet (1.0km)
- Link Watch Dog (LWD) -> 6,070 feet (1.8-1.9km)

Link Watch Dog(LWD) function: The LWD enables the 3324 to reconnect to the CPE modem with known and predefined VDSL link values. This is necessary whenever loading normal VDSL link parameters fails.

Procedure for Changing VDSL Ports Speed Settings:

1. Confirm the VDSL port currently has a link before you change the speed.
2. Select the port you want to configure. (Ports 1-24 are the VDSL ports)
3. Select the line rate (speed) you would like the port to run at
4. Click "Apply" to confirm the settings

Note The VDSL port will link down. After 20 seconds, the VDSL port will link up again with the line rate (speed) you have configured.

Rate Control

Port 1-24 on the Model 3324 supports port-by-port ingress and egress rate control. For example, assume Port 1 is 10Mbps, users can set it's effective egress rate is 1Mbps, ingress rate is 500 kbps. The Model 3324 will be performing flow control or back-pressure to confine the ingress rate to meet the specified rate.

- Ingress: Type the port effective ingress rate. The valid range is 0–100. (Default is 100K) Entering 0 disables rate control. (100 = 10 Mbps)
- Egress: Type the port effective egress rate. The valid range is 0–100. (Default is 100K) Entering 0 disables rate control. (100 = 10 Mbps)

Port Security

When a port is in security mode the port will be “locked” without the permission of address learning. Only the incoming packets with MAC addresses already existing in the address table can be forwarded normally. Users can disable the port from learning any new MAC addresses, and then use the static MAC addresses screen to define a list of MAC addresses that can be use on the secure port. Enter the settings, then click the Apply button to make the changes to the Model 3324.

Port Controls

Port	State	Negotiation	Speed	Duplex	Flow Control		Rate Control (100K)		Priority
					Full	Half	Ingress	Egress	
PORT23									
PORT24	Enable	Auto	10	Full	Enable	Enable	0	0	Disable
PORT25			5						
PORT26			10						
			15						
			LWD						

Apply

Figure 18. VDSL Port Controls

Port Controls

Port	State	Negotiation	Speed	Duplex	Flow Control		Rate Control (100K)		Priority
					Full	Half	Ingress	Egress	
PORT23									
PORT24	Enable	Auto	100	Full	Enable	Enable	0	0	Disable
PORT25			10						
PORT26			100						
			1000						

Apply

Figure 19. Ethernet Port Controls

Duplex

User can set full-duplex or half-duplex mode of per port.

Flow Control

- Full: User can set flow control function is enable or disable in full mode.
- Half: User can set backpressure is enable or disable in half mode.

Trunking

The *link aggregation control protocol* (LACP) provides a standardized means for exchanging information between Partner Systems on a link. Link aggregation lets you group up to eight consecutive ports into a single dedicated connection. This feature can expand bandwidth to a device on the network. LACP operation requires full-duplex mode, more detail information refers to IEEE802.3ad.

System Priority

This is the value used to identify the active LACP. The 3324/Switch with the lowest value has the highest priority and is selected as the active LACP. There are six steps to activate LACP.

1. Group ID: There are seven trunk groups to provided configure. Choose the "group id" and click "Get".
2. LACP: If enabled, the group is LACP static trunking group. If disabled, the group is local static trunking group All ports support LACP dynamic trunking group. If connecting to the device that also supports LACP, the LACP dynamic trunking group will be created automatically.
3. **Work Ports: Allows a maximum of four ports to be aggregated at the same time. If the LACP static trunking group exceeds the 4 port maximum it will set to standby, and will aggregate if the work ports fail. If local static trunking group is set, the number must be as same as the group member ports.**
4. Select the ports to join the trunking group. A maximum of four ports can be aggregated at the same time.
5. If LACP is enabled, you can configure LACP Active/Passive status for each port on State Activity page.
6. Click Apply.

When you are setting the LACP aggregator, you will see one of the following screens below.

This page is when no group is active. LACP is not working.



This page shows a Static Trunking group. LACP is working.



Port	LACP State Activity	Port	LACP State Activity
1	<input checked="" type="checkbox"/> Active	14	<input type="checkbox"/> Passive
2	<input checked="" type="checkbox"/> Active	15	<input type="checkbox"/> Passive
3	<input checked="" type="checkbox"/> Active	16	<input type="checkbox"/> Passive
4	<input checked="" type="checkbox"/> Active	17	<input type="checkbox"/> Passive
5	<input checked="" type="checkbox"/> Active	18	<input type="checkbox"/> Passive
6	<input checked="" type="checkbox"/> Active	19	<input type="checkbox"/> Passive
7	<input checked="" type="checkbox"/> Active	20	<input type="checkbox"/> Passive
8	<input checked="" type="checkbox"/> Active	21	<input type="checkbox"/> Passive
9	<input type="checkbox"/> Passive	22	<input type="checkbox"/> Passive
10	<input type="checkbox"/> Passive	23	<input type="checkbox"/> Passive
11	<input type="checkbox"/> Passive	24	<input type="checkbox"/> Passive
12	<input type="checkbox"/> Passive	25	<input type="checkbox"/> Passive
13	<input type="checkbox"/> Passive	26	<input type="checkbox"/> Passive

State Activity

- Active (select): The port automatically sends LACP protocol packets.
- Passive (no select): The port does not automatically send LACP protocol packets, and responds only if it receives LACP protocol packets from the opposite device.

A link having either two active LACP ports or one active port can perform dynamic LACP trunking. If a link has two passive LACP ports, dynamic LACP trunking will not be performed because both ports are waiting for and LACP protocol packet from the opposite device. **If you are active LACP's actor, when you are select trunking port, the active status will be created automatically.**



Filter Database

IGMP Snooping

The Model 3324 supports IP multicast. IP manages multicast traffic by using switches, routers, and hosts that support IGMP (Internet Group Management Protocol). Enabling IGMP allows the ports to detect IGMP queries and report packets and manage IP multicast traffic through the switch. IGMP can be enabled through the web management's switch settings advanced page. From the Switch Settings Advanced page, choose IGMP snooping. This page will allow you to view the different multicast groups, VID and member ports. IP multicast addresses range from 224.0.0.0 through 239.255.255.255.

IP manages multicast traffic by using switches, routers, and hosts that support IGMP. Enabling IGMP allows the ports to detect IGMP queries and report packets and manage IP multicast traffic through the switch. IGMP have three fundamental types of message as follows:

Message	Description
Query	A message sent from the querier (IGMP router or switch) asking for a response from each host belonging to the multicast group.
Report	A message sent by a host to the querier to indicate that the host wants to be or is a member of a given group indicated in the report message.
Leave Group	A message sent by a host to the querier to indicate that the host has quit to be a member of a specific multicast group.



Static MAC Address

When you add a static MAC address, it will remain in the switch's address table, regardless of whether the device is physically connected to the switch or not. This saves the switch from having to re-learn a device's MAC address in cases where a device may have been powered off or disconnected from the network.

1. From the main menu, click administrator _ Filter Database _ Static MAC Address.

2. In the MAC address box, enter the MAC address to and from which the port should permanently forward traffic, regardless of the device's network activity.
3. In the Port Number box, enter a port number.
4. If tag-based (IEEE 802.1Q) VLANs are set up on the switch, static addresses are associated with individual VLANs. Type the VID (tag-based VLANs) to associate with the MAC address.
5. Click the **Add** button.

A screenshot of a web management interface showing a configuration form for MAC address filtering. The form has three input fields: 'Mac Address', 'Port num', and 'Vlan ID'. Below the fields are three buttons: 'Add', 'Delete', and 'Help'.

MAC Filtering

MAC address filtering allows the switch to drop unwanted traffic. Traffic is filtered based on the destination addresses.

1. In the MAC Address box, enter the MAC address that wants to filter.
2. If tag-based (802.1Q) VLAN are set up on the switch, in the VLAN ID box, type the VID to associate with the MAC address.
3. Click the **Add** button.
4. Choose the MAC address that you want to delete and then click the **Delete** button.


A screenshot of the 'MAC Filtering' configuration page in a web management interface. The page has a navigation bar with three tabs: 'IGMP Snooping', 'Static MAC Addresses', and 'MAC Filtering'. Below the tabs, there is a heading 'Specify a MAC address to filter.' and a large vertical input field. At the bottom, there are two smaller input fields labeled 'Mac Address' and 'Vlan ID', and three buttons: 'Add', 'Delete', and 'Help'.

VLAN Configurations

The Model 3324 supports both port-based and 802.1Q (tagged-based) VLAN, through the web management page.

A Virtual LAN (VLAN) is a logical network grouping that limits the broadcast domain. It allows you to isolate network traffic so only members of the VLAN receive traffic from the same VLAN members. Basically, creating a VLAN is logically equivalent to reconnecting a group of network devices to another Layer 2 switch, even though the network devices have the same physical connection.

The default configuration for VLAN support is disable.



Note If you change the VLAN Operation Mode from disabled to enabled, you must wait 50 seconds. Every time you reboot the Patton Model 3324 you will have to change the VLAN mode to a valid value.

Support Port-based VLAN

Packets can only be transmitted and received among members of the same VLAN group. All unselected ports are treated as though they belong to another single VLAN. If the port-based VLAN is enabled, the VLAN-tagging is ignored.





Figure 20. Support Tag-based VLAN (IEEE 802.1Q VLAN)

1. Click **Add** to create a new VLAN group.
2. Enter the VLAN name, group ID and select the members for the new VLAN.
3. Click **Apply**.
4. If there are many groups that over the limit of one page, you can click the “Next Page” to view other VLAN groups.

Note If the trunk group exists, you can see it (ex. TRK1,TRK2.....) in select menu of ports, and you can configure it is the member of the VLAN or not.



Tagged-based VLAN

Tagged-based VLAN is an IEEE 802.1Q specification standard. Because this is a standard, it is possible to create a VLAN across devices from various switch vendors. IEEE 802.1Q VLAN uses a technique to insert a “tag” into the Ethernet frames. This “tag” contains a VLAN Identifier (VID) that indicates the VLAN numbers.

In order to for a station to send packets to different VLANs, it itself has to be either capable of tagging packets it sends with VLAN tags, or it must be attached to a VLAN-aware bridge that is capable of classifying and tagging the packets with different VLAN ID based on not only default PVID but also other information about the packet, such as the protocol.





Figure 21. Support Tag-based VLAN (IEEE 802.1Q VLAN)

From the VLAN Configuration page, the administrator can create a Tag-based VLAN, and enable or disable GVRP (Generic Attribute Registrations Protocol). You can configure up to 256 VLAN groups. Once 802.1Q

VLAN is enabled, all ports on the Model 3324 will belong to the default VLAN (VID 1). The default VLAN cannot be deleted.

GVRP allows automatic VLAN configuration between the switch and nodes. If the Model 3324 is connected to a device with GVRP enabled, you can send a GVRP request using the VID of a VLAN defined on the Patton Model 3324, the Model 3324 will then automatically add that device to the existing VLAN.



To create a VLAN and add tagged member ports to it follow the steps below.

From the main menu:

1. Click administrator
2. Click VLAN configuration

- Click Add then you will see the page below.

- Type a name for the new VLAN.
- Type a VID (between 2-4,094). The default is 1.
- Choose the protocol type.
- From the available ports box on the left, select which ports to add to the 3324 and click “Add ”. If the trunk groups exist, you can see it in here (ex:TRK1,TRK2...). If you want to configure the TRK as a member of the VLAN you can do it through this screen.
- Click Next. This will take you to [figure 24](#).

VLAN Name:	13			
VLAN ID:	13			
Tag Member				
PORT1	Tag ▼	PORT2	Untag ▼	
PORT3	Tag ▼	PORT4	Untag ▼	
PORT5	Untag ▼			
Apply				

Figure 22. VLAN Tag Menu

9. Using this page to set the outgoing frames are VLAN-Tagged frames or no. Then click Apply.
 - Tag: outgoing frames with VLAN-Tagged.
 - Un-tag: outgoing frames without VLAN-Tagged.

Port VID

Do the following to configure port VID settings:

From the main Tag-based (IEEE 802.1Q) VLAN page, click Port VID Settings.

1. Click administrator
2. Click VLAN configuration
3. Click Port VID and that will take you to the page below (figure 23)

NO	PVID	Ingress Filtering 1	Ingress Filtering 2	NO	PVID	Ingress Filtering 1	Ingress Filtering 2
PORT1	1	Enable	Disable	PORT2	1	Enable	Disable
PORT3	1	Enable	Disable	PORT4	1	Enable	Disable
PORT5	1	Enable	Disable	PORT6	1	Enable	Disable
PORT7	1	Enable	Disable	PORT8	1	Enable	Disable
PORT9	1	Enable	Disable	PORT10	1	Enable	Disable
PORT11	1	Enable	Disable	PORT12	1	Enable	Disable
PORT13	1	Enable	Disable	PORT14	1	Enable	Disable
PORT15	1	Enable	Disable	PORT16	1	Enable	Disable
PORT17	1	Enable	Disable	PORT18	1	Enable	Disable

Figure 23. Port VID menu screen

4. Set the port VLAN ID that will be assigned to untagged traffic on a given port. This feature is useful for accommodating devices that you want to participate in the VLAN but that don't support tagging. Each port of the Model 3324 allows the user to set one PVID, the range is 1~255 and the default PVID is 1. The PVID must be the same as the VLAN ID that the port belongs to, or the untagged traffic will be dropped.

Ingress Filtering


Ingress filtering allows frames belonging to a specific VLAN to be forwarded if the port belongs to that VLAN. The Model 3324 has two ingress filtering rules:

- Ingress Filtering Rule 1: Forward only packets with VID matching this port's configured VID.
- Ingress Filtering Rule 2: Drop Untagged Frame.

Spanning Tree Protocol Settings

Spanning-Tree Protocol (STP) is a standardized method (IEEE 802.1D) for avoiding loops in switched networks. When STP is enabled, it ensures that only one path at a time is active between any two nodes on the network. You can enable Spanning-Tree Protocol through the web management's Switch Setting Advanced

menu, then select enable STP. It is recommended that you enable STP on your Model 3324 to ensure a single active path on your network. Additionally, you can view STP information about the Root Bridge by clicking on Root Bridge Information (see [figure 24](#)).




The screenshot shows a web interface titled "Set Spanning Tree" with a sub-section "Root Bridge Information". Below the title is a table with the following data:

Root Bridge Information	
Priority	32768
Mac Address	004063800071
Root_Path_Cost	0
Root Port	we are root
Max Age	20
Hello Time	2
Forward Delay	15

Figure 24. Root Bridge Information

You can also view STP port status by clicking on STP Port Status



The screenshot shows a web interface titled "STP Port Status" with a table listing port information. The table has four columns: PortNum, PathCost, Priority, and PortState. All 15 ports listed are in the FORWARDING state.

PortNum	PathCost	Priority	PortState
1	10	128	FORWARDING
2	10	128	FORWARDING
3	10	128	FORWARDING
4	10	128	FORWARDING
5	10	128	FORWARDING
6	10	128	FORWARDING
7	10	128	FORWARDING
8	10	128	FORWARDING
9	10	128	FORWARDING
10	10	128	FORWARDING
11	10	128	FORWARDING
12	10	128	FORWARDING
13	10	128	FORWARDING
14	10	128	FORWARDING
15	10	128	FORWARDING

Figure 25. STP Port Status

You can set new values for the STP parameter in the Configuring Spanning Tree Parameters screen. Once the new values are set be sure to click the Apply button to save the configuration. The parameters that can be modified are as follows:

- **Priority:** This value is used to identify the root bridge. The bridge with the lowest value has the highest priority and will be selected as the root bridge. The valid range is between 1-65,535.
- **Max Age:** This value represents the number of seconds a bridge waits without receiving STP configuration messages before attempting a reconfiguration. The valid range is between 6-10.
- **Hello Time:** Hello Time represents the number of seconds between the transmission of STP configuration messages. The valid range is a between 1-10.

- **Forward Delay Time:** Forward Delay Time is the number of seconds a port waits before changing from its STP learning and listening states to the forwarding state. The valid range is from 4-30.

Configure Spanning Tree Parameters

Priority (1-65535)	32768
Max Age (6-40)	20
Hello Time (1-10)	2
Forward_Delay_Time(4-30)	15

Apply

Port Priority and Path Cost can be configured on each port. When finished click the apply icon.

- **Port Priority:** Using Port Priority will make that port more or less likely to become the root port, the rage is 0-255,default setting is 128 the lowest number has the highest priority.
- **Path Cost:** Specifies the path Cost of the port that switch uses to determine which port are the forwarding ports the lowest number is forwarding ports, the rage is 1-65535 and default value base on IEEE802.1D

10Mb/s = 50-600 100Mb/s = 10-60 1000Mb/s = 3-10

Configure Spanning Tree Port Parameters

Port Number	Priority (0 - 255; Default 128)	Path Cost (1 - 65535; Default 10)
1 ▲		
2 ▲		
3 ▲	128	10
4 ▼		
5 ▼		

Apply Help

Port Sniffer

Port Sniffer is a method for monitoring traffic in switched networks. Traffic that goes in or out of the monitored ports will be duplicated into the sniffer port.

- **Sniffer Mode:** Press Space key to set sniffer mode: Disable\Rx\Tx\Both.
- **Monitoring Port:** The sniffer port can be used to see all monitored port traffic. You can connect the sniffer port to LAN analyzer or net x-ray.
- **Monitored Port:** These are the ports you want to monitor. All monitored port traffic will be copied to the sniffer port. You can select up to a maximum of 25 ports to monitor ports.

If you want to disable the function, you must select monitor port to none.

Roving Analysis State:		DISABLE			
Analysis Port:		port1			
Monitor Ports	Rx	Tx	Monitor Ports	Rx	Tx
1	<input type="checkbox"/>	<input type="checkbox"/>	2	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	4	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	<input type="checkbox"/>	6	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	8	<input type="checkbox"/>	<input type="checkbox"/>
9	<input type="checkbox"/>	<input type="checkbox"/>	10	<input type="checkbox"/>	<input type="checkbox"/>
11	<input type="checkbox"/>	<input type="checkbox"/>	12	<input type="checkbox"/>	<input type="checkbox"/>
13	<input type="checkbox"/>	<input type="checkbox"/>	14	<input type="checkbox"/>	<input type="checkbox"/>
15	<input type="checkbox"/>	<input type="checkbox"/>	16	<input type="checkbox"/>	<input type="checkbox"/>
17	<input type="checkbox"/>	<input type="checkbox"/>	18	<input type="checkbox"/>	<input type="checkbox"/>
19	<input type="checkbox"/>	<input type="checkbox"/>	20	<input type="checkbox"/>	<input type="checkbox"/>
21	<input type="checkbox"/>	<input type="checkbox"/>	22	<input type="checkbox"/>	<input type="checkbox"/>
23	<input type="checkbox"/>	<input type="checkbox"/>	24	<input type="checkbox"/>	<input type="checkbox"/>
25	<input type="checkbox"/>	<input type="checkbox"/>	26	<input type="checkbox"/>	<input type="checkbox"/>

Apply Default Help

SNMP Settings

Any Network Management running the simple Network Management Protocol (SNMP) can manage the Model 3324, provided the Management Information Base (MIB) is installed correctly on the management station. SNMP is a protocol that governs the transfer of information between management and agent.

Use this page to define management stations, trap managers, and to enter SNMP community strings. Users can also define a name, location, and contact person for the 3324. Fill in the system options data, then click Apply to update the changes on this page.

- **Name:** Enter a name to be used for the switch.
- **Location:** Enter the location of the switch.
- **Contact:** Enter the name of a person or organization.

SNMP Management

System Options

Name :

Location :

Contact :

Apply Help

Community Strings serve as passwords and can be entered as one of the following:

- **RO (Read Only):** Enables requests accompanied by this string to display MIB-object information.
- **RW (Read Write):** Enables requests accompanied by this string to display MIB-object information and to set MIB objects.

- **Accounting Port:** The UDP port number used by the authentication server to retrieve accounting information.
- **Shared Key:** A key shared between this switch and authentication server.
- **NAS Identifier:** A string used to identify this switch.

Per port Configuration

In this page, you can select the specific port and configure the authorization state. Each port can select four kinds of authorization state:

- **Fu:** force the specific port to be unauthorized.
- **Fa:** force the specific port to be authorized.
- **Au:** the state of the specific port was determined by the outcome of the authentication.
- **No:** the specific port didn't support 802.1x function.

Misc. Configuration

In this page, you can change the default configuration for the 802.1x standard:

- **Quiet Period:** Defines periods of time during which it will not attempt to acquire a supplicant (Default time is 60 seconds).
- **Tx Period:** Determines when an EAPOL PDU is to be transmitted (Default value is 30 seconds).
- **Supplicant Timeout:** Determines timeout conditions of the exchanges between the supplicant and authentication server (Default value is 30 seconds).
- **Server Timeout:** Determines timeout conditions of the exchanges between the authenticator and authentication server (Default value is 30 seconds).
- **ReAuthMax:** Determines the number of reauthentication attempts that are permitted before the specific port becomes unauthorized (Default value is 2 times).
- **ReAuth Period:** Determines a nonzero number of seconds between periodic re-authentication of the supplicants (Default value is 3600 seconds).

TFTP Update Firmware

The following menu options provide some system control functions to allow a user to update firmware and remote boot switch system:

- Install TFTP Turbo98 and execution.
- Copy firmware update version image.bin to TFTP Turbo98 directory.
- In web management select administrator—TFTP update firmware.

- Download new image.bin file then in web management press <update firmware>.
- After update finished, press <reboot> to restart switch.



TFTP Server IP Address	192.168.223.99
Firmware File Name	image.bin

Apply Help


Image download complete.
Would you make sure to update firmware?

Update Firmware

Using TFTP

TFTP Restore Configuration

Use this page to set the TFTP server address. You can restore the EEPROM values from here. It is important to first put the image back in the TFTP server, then the Model 3324 will download the original flash image.



TFTP Server IP Address	192.168.223.3
Restore File Name	flash.dat

Apply Help

TFTP Backup Configuration

Use this page to set the TFTP servers IP address. You can save the current EEPROM value here. Once the EEPROM value has been saved, go to the TFTP restore configuration page to restore the EEPROM value.



The screenshot shows the 'TFTP Configuration' page with two tabs: 'TFTP Restore Configuration' and 'TFTP Backup Configuration'. The 'TFTP Backup Configuration' tab is active. It contains two input fields: 'TFTP Server IP Address' with the value '192.168.223.3' and 'Backup File Name' with the value 'flash.dat'. Below the fields are 'Apply' and 'Help' buttons.

Resetting the Model 3324

Reset the Patton Model 3324 to default configuration, default value as below.



The screenshot shows the 'Reset System' page with the title 'Reset Switch to Default Configuration'. Below the title is a 'reset' button.

Rebooting the Model 3324

Reboot the Patton Model 3324 in software reset.



The screenshot shows the 'Reboot Switch System' page with the title 'Reboot Switch System'. Below the title are 'reboot' and 'Help' buttons.

Chapter 4 Applications

Chapter contents

MxU multi-service delivery.....62
High bandwidth backbone63

MxU multi-service delivery

The Model 3324 provides a high speed, 5/10/15Mbps transmission over existing home telephone wiring over a single Internet account to provide simultaneous independent Internet access to multiple users. Either ISDN or POTS Telephone systems can be used. VDSL Technology allows the simultaneous use of a telephone system (voice) and VDSL network (data) over one voice-grade twisted pair wire.




Figure 26. MxU Multi-Service Delivery

High bandwidth backbone

The Model 3324 provides 10/100/1000Mbps auto sensing Uplinks for bandwidth intensive applications.




Figure 27. Application for VOD and Video conference




Figure 28. Broadband access applications utilizing Model 3324

Chapter 5 **Troubleshooting**

Chapter contents

Diagnosing VDSL indicators	66
System Diagnostics	66
Power and Cooling Problems	66
Installation	67
Transmission Mode	67
Cabling	67
Physical Configuration	67
System Integrity	67
CPE (Customer Premise/Remote) Side Starts Link Watch Dog	67

Diagnosing VDSL indicators

The Model 3324 is easily monitored through its comprehensive panel indicators. These indicators assist the network manager in identifying problems the Model 3324 may encounter. This section describes the common problems you may encounter and possible solutions.

Symptom	Cause	Solution
POWER indicator does not light up (green) after power on.	Defective power outlet, power cord, internal power supply	Check the power outlet by trying another outlet that is functioning properly. Check the power cord with another device. If these measures fail to resolve the problem, have the unit power supply replaced by a qualified distributor.
Link indicator does not light up (green) after making a connection	Network interface (e.g., a network adapter card on the attached device), network cable, or switch port is defective	<ol style="list-style-type: none"> 1. Verify the switch and attached device are powered on. 2. Be sure the cable is plug into both the switch and corresponding device. 3. Verify that the proper cable type is used and its length does not exceed specified limits. 4. Check the adapter on the attached device and cable connections for possible defects. 5. Replace the defective adapter or cable if necessary.
I had a VDSL link. But, after disconnecting the line for several minute, there is no link any more.		This is normal behavior for the modem. The LWD (Link Watch Dog) is automatically activated in the VDSL modem, when ever is no link after a specified time. Users just re-plug the power of VDSL modem, and then they can link again and solve this problem.

System Diagnostics

Power and Cooling Problems

If the POWER indicator does not turn on when the power cord is plugged in, you may have a problem with the power outlet, power cord, or internal power supply as explained in the previous section. However, if the unit should turn itself off after running for a while, check for loose power connections, power losses or surges at the power outlet, and verify that the fan on back of the unit is unobstructed and running prior to shutdown. If you still cannot isolate the problem, then the internal power supply may be defective. In this case, contact your supplier for assistance.

Installation

Verify that all system components have been properly installed. If one or more components appear to be malfunctioning (e.g., the power cord or network cabling), test them in an alternate environment, where you are sure that all the other components are functioning properly.

Transmission Mode

The default transmission mode of the RJ-45 ports is auto-negotiation. Therefore, if the Link signal is disrupted (e.g., by unplugging the network cable and plugging it back in again, or by resetting the power), the port will try to reestablish communications with the attached device Model 3324 through auto-negotiation. If auto-negotiation fails, then communications are set to half duplex by default. Based on this type of industry-standard connection policy, if you are using a full-duplex device that does not support auto-negotiation, communications can easily be lost (i.e., reset to the wrong mode) whenever the attached device is reset or experiences a power fluctuations. The best way to resolve this problem is to upgrade these devices to products that will support auto-negotiation.

Cabling

- Verify that the cable type is correct.
- Be sure RJ-45 cable connectors are securely fastened into the correct ports.
- Use 100W straight-through cables for all standard connections.
- Use Category 5 cable for 100/1000Mbps Fast Ethernet connections, or Category 3, 4 or 5 cables for standard 10Mbps Ethernet connections.
- Be sure RJ21 phone wiring, use 18-26 gauge.
- Make sure all devices are connected to the network. Equipment any have been unintentionally disconnected from the network.
- When cascading two devices using RJ-45 station ports at both ends of the cable (Model 3324 supports auto MDIX), without crossover cable can be used.

Physical Configuration

If problems occur after altering the network configuration, restore the original connections, and try to track the problem down by implementing the new changes, one step at a time. Ensure that cable distances and other physical aspects of the installation do not exceed recommendations

System Integrity

As a last resort verify the switch integrity with a power-on reset. Turn the power to the switch off and then on several times. If the problem still persists and you have completed all the preceding diagnoses, contact your dealer for assistance.

CPE (Customer Premise/Remote) Side Starts Link Watch Dog

If the CPE side (VDSL Modem) is on power standby for an excess of 20 minutes without connecting to the Model 3324, the link has failed. The users must power cycle the CPE once to clear and the CPE should reconnect to the Model 3324.

Chapter 6 **Contacting Patton for assistance**

Chapter contents

- Introduction70
- Contact information70
- Warranty Service and Returned Merchandise Authorizations (RMAs)70
 - Warranty coverage70
 - Out-of-warranty service70
 - Returns for credit70
 - Return for credit policy71
- RMA numbers71
 - Shipping instructions71

Introduction

This chapter contains the following information:

- “Contact information”—describes how to contact PATTON technical support for assistance.
- “Warranty Service and Returned Merchandise Authorizations (RMAs)”—contains information about the RAS warranty and obtaining a return merchandise authorization (RMA).

Contact information

Patton Electronics offers a wide array of free technical services. If you have questions about any of our other products we recommend you begin your search for answers by using our technical knowledge base. Here, we have gathered together many of the more commonly asked questions and compiled them into a searchable database to help you quickly solve your problems.

- Online support—available at www.patton.com.
- E-mail support—e-mail sent to support@patton.com will be answered within 1 business day
- Telephone support—standard telephone support is available 5 days a week, from 8:00am to 5:00pm EST by calling +1 (301) 975-1007

Warranty Service and Returned Merchandise Authorizations (RMAs)

Patton Electronics is an ISO-9001 certified manufacturer and our products are carefully tested before shipment. All of our products are backed by a comprehensive warranty program.

Note If you purchased your equipment from a Patton Electronics reseller, ask your reseller how you should proceed with warranty service. It is often more convenient for you to work with your local reseller to obtain a replacement. Patton services our products no matter how you acquired them.

Warranty coverage

Our products are under warranty to be free from defects, and we will, at our option, repair or replace the product should it fail within one year from the first date of shipment. Our warranty is limited to defects in workmanship or materials, and does not cover customer damage, lightning or power surge damage, abuse, or unauthorized modification.

Out-of-warranty service

Patton services what we sell, no matter how you acquired it, including malfunctioning products that are no longer under warranty. Our products have a flat fee for repairs. Units damaged by lightning or other catastrophes may require replacement.

Returns for credit

Customer satisfaction is important to us, therefore any product may be returned with authorization within 30 days from the shipment date for a full credit of the purchase price. If you have ordered the wrong equipment or you are dissatisfied in any way, please contact us to request an RMA number to accept your return. Patton is not responsible for equipment returned without a Return Authorization.

Return for credit policy

- Less than 30 days: No Charge. Your credit will be issued upon receipt and inspection of the equipment.
- 30 to 60 days: We will add a 20% restocking charge (crediting your account with 80% of the purchase price).
- Over 60 days: Products will be accepted for repairs only.

RMA numbers

RMA numbers are required for all product returns. You can obtain an RMA by doing one of the following:

- Completing a request on the RMA Request page in the *Support* section at www.patton.com
- By calling +1 (301) 975-1000 and speaking to a Technical Support Engineer
- By sending an e-mail to returns@patton.com

All returned units must have the RMA number clearly visible on the outside of the shipping container. Please use the original packing material that the device came in or pack the unit securely to avoid damage during shipping.

Shipping instructions

The RMA number should be clearly visible on the address label. Our shipping address is as follows:

Patton Electronics Company

RMA#: xxxx

7622 Rickenbacker Dr.

Gaithersburg, MD 20879-4773 USA

Patton will ship the equipment back to you in the same manner you ship it to us. Patton will pay the return shipping costs.

Appendix A **Specifications**

Chapter contents

VDSL line interface	74
POTS-ISDN interface	74
Modulation	74
Frequency range	74
Transmission	74
Management	74
Ethernet standards	74
Management standards	74
LED indicators	74
Power supply	74
Compliance	74
Environment	74
Operating temperature	74
Humidity	75
Dimensions	75
Weight	75

VDSL line interface

24 ports presented on one RJ-21

POTS-ISDN interface

24 ports presented on one RJ-21

Modulation

QAM (Quadrature Amplitude Modulation)

Frequency range

- VDSL: 1–8 MHz
- POTS/ISDN: 0–120 kHz

Transmission

Software 5/10/15 Mbps symmetrical line rates

Management

In-Band/out-of-band (DB9 RS-232 Console, Telnet, or HTTP)

Ethernet standards

802.1d (Spanning Tree), 802.1p (Priority Queuing), 802.1Q (VLAN Tagging), 802.3ad (Port Trunking), 802.3x (Flow Control), 802.3 (Ethernet), 802.3u (Fast Ethernet), 802.3z (Gigabit Ethernet)

Management standards

SNMP RFC-1493 Bridge MIBs, RFC-1213 MIB II, RFC-1643 Ethernet MIB & Enterprise MIB, RFC-1757 RMON MIB (RMON groups 1,2,3,9)

LED indicators

Power, Error, VDSL status, and Ethernet Uplink Status

Power supply

Internal AC: 120–240 VAC (50–60 Hz)

Compliance

EMC Directive 89/336/EEC, Low Voltage Directive 73/23/EEC; CE Mark

Environment

Operating temperature

41 to 122°F (5 to 50°C)

Humidity

10–90% non-condensing

Dimensions

2.0H x 17.5W x 16.5L inch (5.08H x 44.45W x 41.91L cm)

Weight

12.5 lbs (5.66 kg)

Appendix B **Cabling**

Chapter contents

Introduction.....	78
-------------------	----

Introduction

RJ-21 Telco ports distribution

Table 3. RJ-21 Pin and VDSL port contrast list

VDSL 50 Pin RJ-21 Cable Connector List Cable Characteristic = 24 AWG twist wire	
VDSL Port No.	RJ-21 Cable No.
1	24 & 49
2	23 & 48
3	22 & 47
4	21 & 46
5	20 & 45
6	19 & 44
7	18 & 43
8	17 & 42
9	16 & 41
10	15 & 40
11	14 & 39
12	13 & 38
13	12 & 37
14	11 & 36
15	10 & 35
16	9 & 34
17	8 & 33
18	7 & 32
19	6 & 31
20	5 & 30
21	4 & 29
22	3 & 28
23	2 & 27
24	1 & 26

Note RJ-21 Pins 25 and 50 are not used




Figure 29. RJ-21 Cable Drawing (1500 cm Male to Male)

Appendix C **VDSL Spectrum**


Chapter contents

Introduction.....	82
-------------------	----

Introduction

Spectrum allocation

VDSL Technology – Requirements & Definitions Spectral Allocation



- Co-exists with legacy Voice and ISDN services
- Co-exists with other xDSL technologies
- Programmable notch filter to avoid Radio Frequency Interference

Appendix D **Example of VLAN Setting**

Chapter contents

Introduction.....	84
-------------------	----

Introduction

Web management -> Administrator -> Switch settings -> Advanced: protocol setting -> VLAN Operation Mode: Select "Port_Based"

WRR High weight: weight:
 Enable Delay Bound Max Delay Time: ms
QoS Policy: High Priority Levels
 Level0 Level1 Level2 Level3 Level4 Level5 Level6 Level7

Protocol Enable Setting:
 Enable STP Protocol
 Enable IGMP Protocol
VLAN Operation Mode:

Web management -> Administrator -> Switch settings -> Vlan Configuration:

VLAN Configuration

Port_based VLAN Information

--

Add VLAN Group 1, member: port 1 and port 9

The screenshot shows a configuration window for adding members to a VLAN group. At the top, there are two input fields: "VLAN Name:" with the value "1" and "Grp ID:" with the value "1". Below these are two vertical lists of numbers. The left list contains numbers 2, 3, 4, 5, 6, 7, 8, and 10. The right list contains numbers 1 and 9. Between the lists are two buttons: "Add >>" and "<< Remove". At the bottom of the window are two buttons: "Apply" and "Help".