

# USER MANUAL

---

**MODEL 1019 and 1019S  
DB-9 Async. Short Range  
Modem With Transformer  
Isolation**



**PATTON**  
**Electronics Co.**



*An ISO-9001  
Certified Company*

Part# 07M1019-C  
Doc# 051021UC  
Revised 06/03/99

SALES OFFICE  
(301) 975-1000  
TECHNICAL SUPPORT  
(301) 975-1007  
<http://www.patton.com>

## TABLE OF CONTENTS

<b>SECTION</b>	<b>PAGE</b>
1.0 Warranty Information .....	2
1.1 Radio and TV Interference	
1.2 Service Information	
2.0 General Information.....	3
2.1 Features	
2.2 Description	
3.0 Installation.....	4
3.1 Connection to the Twisted Pair Interface	
3.1.1 Twisted Pair Connection Using RJ-11 or RJ45	
3.1.2 Twisted Pair Connection Using terminal Blocks	
3.2 Connection to the RS-232 Interface	
3.3 Operating the Model 1019	
Appendix A - Specifications.....	10
Appendix B - Block Diagram.....	11

## 1.0 WARRANTY INFORMATION

**Patton Electronics** warrants all Model 1019 components to be free from defects, and will—at our option—repair or replace the product should it fail within one year from the first date of shipment.

This warranty is limited to defects in workmanship or materials, and does not cover customer damage, abuse or unauthorized modification. If this product fails or does not perform as warranted, your sole recourse shall be repair or replacement as described above. Under no condition shall **Patton Electronics** be liable for any damages incurred by the use of this product. These damages include, but are not limited to, the following: lost profits, lost savings and incidental or consequential damages arising from the use of or inability to use this product. **Patton Electronics** specifically disclaims all other warranties, expressed or implied, and the installation or use of this product shall be deemed an acceptance of these terms by the user.

### 1.1 RADIO AND TV INTERFERENCE

The Model 1019 generates and uses radio frequency energy, and if not installed and used properly—that is, in strict accordance with the manufacturer's instructions—may cause interference to radio and television reception. The Model 1019 has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection from such interference in a commercial installation. However, there is no guarantee that interference will not occur in a particular installation. If the Model 1019 does cause interference to radio or television reception, which can be determined by disconnecting the RS-232 interface, the user is encouraged to try to correct the interference by one or more of the following measures: moving the computing equipment away from the receiver, re-orienting the receiving antenna and/or plugging the receiving equipment into a different AC outlet (such that the computing equipment and receiver are on different branches).

### 1.2 SERVICE

All warranty and non-warranty repairs must be returned freight prepaid and insured to Patton Electronics. All returns must have a Return Materials Authorization number on the outside of the shipping container. This number may be obtained from Patton Electronics Technical Service at **(301) 975-1007**. *Packages received without an RMA number will not be accepted.*

Patton Electronics' technical staff is also available to answer any questions that might arise concerning the installation or use of your Model 1019. Technical Service hours: **8AM to 5PM EST, Monday through Friday.**

## 2.0 GENERAL INFORMATION

Thank you for your purchase of this Patton Electronics product. This product has been thoroughly inspected and tested and is warranted for One Year parts and labor. If any questions or problems arise during installation or use of this product, please do not hesitate to contact Patton Electronics Technical Support at (301) 975-1007.

### 2.1 FEATURES

- Transformer isolation
- Range to 9 miles
- Data rates to 19,200 bps
- Full duplex communication
- No AC power or batteries required
- Very thin case for closely spaced computer ports
- Custom equipped with a DB-9 interface
- Available with RJ-11, RJ-45 or terminal block with strain relief
- Surge protection (Model 1019S only)
- Made in USA

### 2.2 DESCRIPTION

The Patton Model 1019 Short Range Modem provides direct connection to RS-232 devices equipped with DB-9 connectors including IBM PCs/ATs, Unisys 7000 and the NCR Tower series. Supporting asynchronous data rates to 19.2 Kbps and distances to 9 miles, the Model 1019 requires no AC power or batteries.

Compatible with Patton Models 1010, 1016 and other Patton short range modems, the Model 1019 uses built-in transformers to provide protection against ground loops. The Model 1019 incorporates custom-designed, high permeability, ferrite core transformers that yield 1500V of line isolation.

Measuring only 2.5" x 1.2" x .75", the Model 1019 is housed in a pop-open ABS plastic case. The Model 1019 comes with a male or female DB-9 connector and a choice of interfaces (RJ-11 jack, RJ-45 jack or terminal blocks with strain relief). The surge protected Model 1019S incorporates Silicon Avalanche Diodes which provide 600 watts per wire of protection against harmful transient surges.

## 3.0 INSTALLATION

The Model 1019 is easy to install. This section tells you how to properly connect the Model 1019 to the twisted pair and RS-232 interfaces, and how to operate the Model 1019.

### 3.1 CONNECTION TO THE TWISTED PAIR INTERFACE

The Model 1019 supports data-only communication between two RS-232 devices at distances to 9 miles and data rates to 19.2 Kbps. There are two essential requirements for installing the Model 1019:

1. These units work in pairs. Therefore, you must have one Model 1019 at each end of a two twisted pair interface.
2. To function properly, the Model 1019 needs two twisted pairs of metallic wire. The pairs must be unconditioned, dry metallic wire, between 19 and 26 AWG (the higher number gauges may limit distance). Standard dial-up telephone circuits or leased circuits that run through signal equalization equipment are not acceptable.

For your convenience, the Model 1019 is available with three different twisted pair interfaces: RJ-11 jack, RJ-45 jack and terminal blocks with strain relief.

#### 3.1.1 TWISTED PAIR CONNECTION USING RJ-11 OR RJ-45

The RJ-11 and RJ-45 connectors on the Model 1019's twisted pair interface are pre-wired for a standard TELCO wiring environment (see Figure 1). The signal/pin relationships are shown on the charts on the following page.




Figure 1. AT&T Standard Modular Color Codes

### RJ-11 Twisted Pair Wiring Diagram

<b>RJ-11</b>	<b>SIGNAL</b>
1 -----	GND <sup>†</sup>
2 -----	RCV-
3 -----	XMT+
4 -----	XMT-
5 -----	RCV+
6 -----	GND <sup>†</sup>

<sup>†</sup>Connection to ground is optional

### RJ-45 Twisted Pair Wiring Diagram

<b>RJ-45</b>	<b>SIGNAL</b>
1 -----	N/C
2 -----	GND <sup>†</sup>
3 -----	RCV-
4 -----	XMT+
5 -----	XMT-
6 -----	GND <sup>†</sup>
7 -----	RCV+
8 -----	N/C

<sup>†</sup>Connection to ground is optional

When connecting two Model 1019s, it is necessary to use a “crossover” cable. The diagram below shows how a crossover cable should be constructed for an environment where both Model 1019s use a 4-wire RJ-11 connector. Similar logic should be followed when using RJ-45 connectors or a combination of the two.

### Crossover Cable Wiring Diagram

<b>SIGNAL</b>	<b>PIN#</b>	<b>COLOR<sup>‡</sup></b>	<b>COLOR</b>	<b>PIN#</b>	<b>SIGNAL</b>
GND <sup>†</sup>	1	Blue-----	White	6	GND <sup>†</sup>
RCV-	2	Yellow-----	Red	4	XMT-
XMT+	3	Green-----	Black	5	RCV+
XMT-	4	Red-----	Yellow	2	RCV-
RCV+	5	Black-----	Green	3	XMT+
GND <sup>†</sup>	6	White-----	Blue	1	GND <sup>†</sup>



<sup>†</sup>Connection to ground is optional

<sup>‡</sup>Standard color codes—yours may be different

### 3.1.2 TWISTED PAIR CONNECTION USING TERMINAL BLOCKS


If your RS-232 application requires you to connect two pairs of bare wires to the Model 1019, you will need to open the case to access the terminal blocks. The following instructions will tell you how to open the case, connect the bare wires to the terminal blocks and fasten the strain relief collar in place so that the wires won't pull loose.

1. Open the unit by gently inserting a screwdriver between the DB-9 connector and the lip of the plastic case (see below). You don't have to worry about breaking the plastic, but be careful not to bend the D-sub connector.




Once the unit has been opened, you will be able to see the terminal blocks located at the rear of the PC board.

2. Strip the outer insulation from the twisted pairs about one inch from the end.




- Strip the insulation on each of the twisted pair wires about .25".




- Connect *one pair* of wires to XMT+ and XMT- (transmit positive and negative) on the terminal block, making careful note of which color is positive and which color is negative.
- Connect the *other pair* of wires to RCV+ and RCV- (receive positive and negative) on the terminal block, again making careful note of which color is positive and which color is negative.


**Ultimately, you will want to construct a two pair crossover cable that connects the two short hauls as shown below:**




- If there is a shield around the telephone cable, it may be connected to "G" on the terminal block. To avoid ground loops, we recommend connecting the shield at the computer end only. A ground wire is *not necessary* for proper operation of the Model 1019.
- When you finish connecting the wires to the terminal block, the assembly should resemble the diagram below:




- Place the 2 halves of the strain relief assembly on either side of the telephone wire and press together very lightly. Slide the assembly that it is about 2 inches from the terminal posts and press together firmly. If your cable diameter is too small or too large for our strain relief, please contact Technical Support. We have strain relief assemblies to accommodate most cable diameters.



- Insert the strain relief assembly with the wire into the slot in the bottom half of the modem case and set it into the recess in the case.



- TIP the top half of the case as necessary to place it over the strain relief assembly. Do not snap the case together yet.



- Insert one captive screw through a saddle washer and then insert the entire piece through the hole in the DB-9 end of the case. Snap that side of the case closed. Repeat the process for the other side. This completes the cable installation.

### 3.2 CONNECTION TO THE RS-232 INTERFACE

Once you have connected the twisted pair wires correctly, simply plug the Model 1019 directly into the DB-9 port of the RS-232 device. Remember to insert and tighten the two captive connector screws.

**Note:** If you must use a cable to connect the Model 1019 to the RS-232, make sure it is a *straight through* cable of the shortest possible length—we recommend 6 feet or less.

### 3.3 OPERATING THE MODEL 1019

Once the Model 1019 is properly installed, it should operate transparently—as if it were a standard cable connection. Operating power is derived from the RS-232 data and control signals; there is no “ON/OFF” switch. All data signals from the RS-232 interface are passed straight through. All control signals from the RS-232 interface are looped back.

## APPENDIX A

### PATTON ELECTRONICS MODEL 1019 SPECIFICATIONS

<b>Transmission Format:</b>	Asynchronous
<b>Data Rate:</b>	0 to 19,200 bps (no strapping)
<b>Surge Protection:</b>	600W power dissipation at 1 mS and response time of .5 uS; transformer isolation
<b>Control Signal:</b>	DSR and DCD follow DTR from the terminal; CTS follows RTS from the terminal
<b>Transmit Line:</b>	4 wire, unconditioned twisted pair
<b>Transmit Mode:</b>	Full duplex
<b>Transmit Level:</b>	-6 dBm
<b>Connectors:</b>	Either a male or female DB-9 connector
<b>Power Supply:</b>	None required, uses ultra low power from EIA data and control signals
<b>Range:</b>	Up to 9 miles
<b>Temperature:</b>	32° to 140°F
<b>Humidity:</b>	Non-condensing
<b>Size:</b>	2.5" x 1.2" x 0.75"

#### Distance Table:

Distance Table (miles)			
Data Rate	Wire Gauge		
	19	24	26
19,200	2.5	1.8	1.2
9,600	5.5	3.7	2.5
4,800	7.5	5.0	3.0
2,400	8.5	5.6	3.7
1,200	9.0	6.2	4.3

## APPENDIX B

### PATTON ELECTRONICS MODEL 1019 BLOCK DIAGRAM

