

Test report & configuration guide
Patton Gateway / eSBC
Deutsche Telekom – DeutschlandLAN SIP-Trunk
(Technical Specification 1TR118)



Table of contents

Introduction.....	3
SmartNode overview	4
Test environment.....	6
Registration mode.....	7
Configuration guide.....	8
Test plan – Standard calls	15
Outgoing calls	15
Incoming calls	16
DTMF codes (RFC2833 / RFC4733).....	16
Call hold (RFC3264).....	17
Emergency calls.....	17
Unsuccessful calls / wrong dialled numbers	18
Telephony codecs	18
DDI Management (belonging to the SIP-Trunk account DTAG 1TR118).....	19
Test plan - Telephony features	20
Call-Waiting.....	20
Blind call transfer (unattended).....	20
Incoming call transferred to an outgoing call	20
Transfer from outgoing call to outgoing call.....	21
Attended call transfer	22
Incoming call transferred to an outgoing call	23
Transfer of outgoing calls : outgoing call transferred to outgoing call	24
3-party conferences.....	25
Caller Identity Presentation / CLIP.....	26
Swapping between two hold calls.....	26
Call forwarding	28
Fax calls	31
Signalling and Media Security (TLS & SRTP)	32
Contacting Patton Support & Sales.....	33

Introduction

Patton SmartNode products integrate IP and TDM communications for Enterprise and Carrier access networks, offering VoIP gateways combined with IP access routing, WAN transmission, and transcoding functionality. SmartNode scales from 1 to 32,768 VoIP or fax calls with various telephony interfaces including analog FXS/FXO and digital ISDN BRI, PRI, DS3 and STM-1.

This document includes a general overview of the requirements and provides the necessary configuration to interconnect Patton SmartNode VoIP Gateway / eSBC devices with the NGN Platform of Deutsche Telekom through the SIP interface DeutschlandLAN SIP-Trunk (Technical Specification 1TR118).

DeutschlandLAN SIP-Trunk is a SIP-Trunking service of Deutsche Telekom AG, which is available to Business customers. The SIP-Trunk is also available in conjunction with the professional symmetrical internet access **DeutschlandLAN Connect IP**.

Product information related to **DeutschlandLAN SIP-Trunk**:

<https://geschaeftskunden.telekom.de/internet-dsl/tarife/festnetz-internet-dsl/deutschlandlan-sip-trunk>

SmartNode overview

In scope of these tests, Patton SmartNode VoIP Gateways & eSBC's have been tested in the 3rd-Party Lab of Deutsche Telekom in Bonn.

Following Patton equipment has been tested:

- Analog Gateways interconnecting analog devices (phone, fax) to SIP-Trunk

Analog	SN200	SN4140	SN5540	SN5550	SN4740
Product Photo					
Embedded Software	Trinity™	Trinity™	Trinity™	Trinity™	Trinity™
Patton Cloud Connect	Yes	Yes	Yes	Yes	Yes
Telephony Interfaces	FXS (or 1FXS+1FXO)	FXS & FXO	FXS & FXO	FXS/FXO & BRI S0/T0	FXS (FXO soon)
Number of Telephony Ports	1,2 or 4	2,4 or 8	2,4 or 8	2,4,8 or 16	16,24 or 32
Call Capacity	Up to 4 Calls	Up to 8 Calls	Up to 8 Calls	Up to 16 Calls	Up to 32 Calls
VoIP Gateway (Converts TDM to SIP) Converts TDM to IP	✓	✓	✓	✓	✓
USB Support (WiFi, Cellular Modem etc.) IP Routing, QoS, VPN, etc.		✓	✓	✓	✓
IP Router IP Routing, QoS, VPN, etc.		Optional	✓	✓	Optional
Number of Ethernet Ports	1 10/100	1 or 2 10/100/1000	2 10/100/1000	2 10/100/1000	2 10/100/1000
WAN Access			Fiber SFP G.SHDSL-EFM/ATM ADSL/VDSL Gigabit Ethernet	Fiber SFP G.SHDSL-EFM/ATM ADSL/VDSL Gigabit Ethernet	
Industrial version available		✓			

- ISDN Gateways interconnecting Legacy ISDN PBX (BRI, PRI) to SIP-Trunk
 - PRI (S2M) models

T1 / E1 / PRI	SN4170	SN4970	SN5570	SN4980	SN4990
Product Photo					
Embedded Software	Trinity™	Trinity™	Trinity™	Trinity™	Trinity™
Patton Cloud Connect	Yes	Yes	Yes	Yes	Yes
Telephony Interfaces	T1/E1/PRI	T1/E1/PRI	T1/E1/PRI	T1/E1/PRI	T1/E1/PRI
Number of Telephony Ports	1 (2nd Fallback)	1 or 4	1 (2nd Fallback)	1 or 4	1 or 4
Call Capacity	15 to 30	15, 30, 60 or 120	15 to 30	15, 30, 60 or 120	15, 30, 60 or 120
VoIP Gateway Converts TDM to IP	✓	✓	✓	✓	✓
USB Support WiFi, Cellular Modem etc.	✓		✓		
IP Router IP Routing, QoS, VPN, etc.			✓	✓	✓
Number of Ethernet Ports	1 or 2 10/100/1000	1 10/100/1000	2 10/100/1000	2 10/100/1000	2 10/100/1000
Transcoding Interconnect multiple VoIP networks	Yes	Yes	Yes	Optional	Optional
WAN Access			Fiber SFP G.SHDSL-EFM/ATM ADSL/VDSL Gigabit Ethernet		Fiber SFP G.SHDSL-EFM/ATM ADSL/VDSL Gigabit Ethernet

- BRI models

ISDN BRI	SN4130	SN4150
Product Photo		
Embedded Software	Trinity™	Trinity™
Telephony Interfaces	BRI	BRI with FXS/FXO
Number of Telephony Ports	2,4 or 8	4 or 8
Call Capacity	4, 8 or 16	4 or 8
VoIP Gateway Converts TDM to IP	✓	✓
IP Router IP Routing, QoS, VPN, etc.		
Number of Ethernet Ports	1 10/100	1 10/100/1000
WAN Access		


- eSBC (Enterprise Session Border Controller) for SIP-SIP connectivity

eSBC	vSN	SN5300	SN5480	SN5490	SN5500
Product Photo					
Embedded Software	Trinity™	Trinity™	SmartWare™ or Trinity™	SmartWare™ or Trinity™	Trinity™
Telephony Interfaces	N/A	N/A	N/A	N/A	N/A
SIP Sessions	1 to 1,000's	4 to 60	Up to 80	Up to 80	4 to 200
Transcoded Calls	N/A	N/A	Up to 64	Up to 64	Up to 16
IP router IP Routing, QoS, VPN, etc.	✓	✓	✓	✓	✓
Number of Ethernet Ports	HW dependent	4 10/100	2 10/100/1000	2 10/100/1000	2 10/100/1000
Transcoding	Roadmap		✓	✓	✓
WAN Access	N/A	G.SHDSL.bis (ATM or EFM)		Fiber G.SHDSL EFM X.21	G.SHDSL EFM&ATM, ADSL- VDSL

eSBC	SN5530	SN5540	SN5550	SN5570	SN5600
Product Photo					
Embedded Software	Trinity™	Trinity™	Trinity™	Trinity™	Trinity™
Telephony Interfaces	2, 4 or 8 BRI	2, 4 or 8 FXS/FXO	BRI with FXS/FXO	1 or 2 PRI	N/A
SIP Sessions	4 to 200	4 to 200	4 to 200	4 to 200	4 to 1,000
Transcoded Calls	Up to 8	Up to 4	Up to 4	Up to 15	N/A
IP router IP Routing, QoS, VPN, etc.	✓	✓	✓	✓	✓
Number of Ethernet Ports	2 10/100/1000	2 10/100/1000	2 10/100/1000	2 10/100/1000	2 10/100/1000
Transcoding	✓	✓	✓	✓	N/A
WAN Access	VDSL/ADSL G.SHDSL.bis	VDSL/ADSL G.SHDSL.bis		VDSL/ADSL G.SHDSL.bis	N/A

Remark: Limitation concerning the virtual SN (vSN) and SN5600 -> no transcoding and no SRTP available (models without DSPs). Support of SRTP planned in a future Firmware release.

Test environment



The tests performed in the 3rd-Party Lab involved Patton SmartNode Gateways / eSBC's with analog & ISDN devices connected through FXS & BRI interfaces. Customer tests have also been performed with a PRI PBX. Additionally, specific tests with SIP hard- and softphones on LAN side of SBC have been used to test SIP-SIP interworking (Yealink T41S as SIP phone, and MicroSIP as SIP softphone).

As displayed in the figure above, SIP and RTP termination is realized between Patton Gateway / eSBC and the NGN-Softswitch, meaning that the SIP-Trunking functionality on the IAD shall be disabled for this scenario.

Recommended Firmware version : Trinity 3.17.1 or higher

SIP-Trunk Access Data:

Outbound-Proxy:	reg.sip-trunk.telekom.de
Registrar:	sip-trunk.telekom.de
Registration number:	+4922842223470
Country code:	+49
Area code:	228
Extension number:	4222347
Phone number block:	0 – 9
Attendant / main number:	+49-228-4222347-0
Telephony user name:	
Telephony password:	

Registration mode

The Technical Specification 1TR118 describes two supported operation modes:

- Registration Mode
 - Preferred method: SIP REGISTER message according to the RFC 6140: not supported yet by Patton SmartNode devices
 - eSBC's / SIP-PBXs which do not support the RFC 6140 yet, may register according to the RFC 3261 and ETSI TS 182 025 : supported by Patton SmartNode devices; this is the method used in this certification.
- Static Mode SIP PBXs
 - supported but not used, as the registration mode is the preferred one.

As required by DTAG in case of registration mode according to RFC 3261, Patton devices send only one REGISTER for the whole assigned DDI range, using the SIP-Trunk access data. The Contact: header of the REGISTER request of Patton Trinity device contains the prefix of one of the phone number blocks configured for the SIP-Trunk in the user-part and its IP-address in the host-part, according to RFC 3261.

REGISTER of Patton's eSBC / GW with configuration for 1TR118:

```

v Session Initiation Protocol (REGISTER)
  v Request-Line: REGISTER sip:sip-trunk.telekom.de SIP/2.0
    Method: REGISTER
    > Request-URI: sip:sip-trunk.telekom.de
    [Resent Packet: False]
  v Message Header
    > Via: SIP/2.0/TCP 192.168.0.150:5060;branch=z9hG4bK1b4f4b8e4d08c759f;rport
    > Route: <sip:reg.sip-trunk.telekom.de;lr>
    Max-Forwards: 70
    > From: <sip:+4922842223470@sip-trunk.telekom.de>;tag=2336b35458
    > To: <sip:+4922842223470@sip-trunk.telekom.de>
    Call-ID: f1247eea67e39eac
    [Generated Call-ID: f1247eea67e39eac]
    > CSeq: 2083146457 REGISTER
    > Authorization: Digest username="XXXXXXXXXX",realm="sip-trunk.telekom.de",nonce="2cb4abd500eb308b2cb4abd5f6983cd5e987f48b32eabb61ccd48e8f2b3e9673",uri="sip:sip-trunk.telekom.de",response="XXXXXXXXXX"
    > Contact: <sip:+4922842223470@192.168.0.150:5060;transport=tcp>;reg-id=1;+sip.instance="urn:00A08A008A58:GW_SIP_DTAG"
    Expires: 1800
    Supported: path, outbound
    User-Agent: Patton SN5531/2BIS4VRHP 00A08A008A58 3.17.1-20044 1.6 MST SIP Stack/4.2.28.153
    Content-Length: 0
  
```

Configuration guide

The example below is based on a Patton SN5531 (ISDN BRI SBC) test configuration file SN_Config_1TR118_18.cfg

If an analog or an ISDN PRI Gateway model is used, adapt the port settings accordingly.

The configuration contains both the unencrypted SIP/TCP + RTP and the encrypted part SIP/TLS + SRTP. Only three very minor configuration changes must be done to switch from one to the other operation mode (see red highlighting).

Meaning of the highlighted configuration parts:

- Recommended general configuration (non-variable part)
- Project / customer specific configuration (variable part): should be adapted/replaced accordingly by considering your customer's environment (IP addresses, DDI range, credentials etc.)
- Switch between [SIP/TCP + RTP] and [SIP/TLS + SRTP]
- (Comments are inserted between # and do not affect the configuration file)

```
cli version 4.00
superuser admin password xxxxxx
system hostname DTAG_SIPT
system description DTAG_SIPT
system location "Patton Inalp Networks - Bern CH"
system provider DTAG
clock local default-offset +01:00
clock local dst-rule SUMMERTIME +1:00 from mar last sunday 02:00 2019 until oct last sunday 03:00
2036

profile aaa DEFAULT
  method 1 nodems continue-on-reject
  method 2 local
  method 3 none

console
  use profile aaa DEFAULT

telnet-server
  use profile aaa DEFAULT
  no shutdown

ssh-server
  use profile aaa DEFAULT
  no shutdown

snmp-server
  shutdown

web-server
  protocol http port 80
  protocol https port 443
  use profile aaa DEFAULT
  no shutdown

ntp
server 0.de.pool.ntp.org
server 1.de.pool.ntp.org
server 2.de.pool.ntp.org
server 3.de.pool.ntp.org
no shutdown

system
clock-source 1 bri 0 0
clock-source 2 bri 0 1

profile napt NAPT_WAN

# DNS server config. used for SIP devices and other IP clients on LAN side #
# Ignore this part otherwise #
dns-server
  host 172.20.74.1 smartnode.local
```



```
relay dns-client
no shutdown

# In necessary, configure one or more DNS servers.
# Mandatory if static IP addressing is used on WAN interface.
dns-client
name-server 9.9.9.11

# Enable DHCP for SIP devices and other IP clients on LAN side #
# Ignore this part otherwise #
profile dhcp-server DHCP_SERVER_LAN
network 172.20.74.0/24
lease 24 hours
default-router 172.20.74.1
domain-name-server 172.20.74.1
include 172.20.74.2 172.20.74.100

profile tls DEFAULT
authentication incoming
authentication outgoing
private-key pki:private-key/DEFAULT
own-certificate 1 pki:certificate/DEFAULT
diffie-hellman-parameters pki:diffie-hellman-parameters/DEFAULT-2048

profile tls PF_TLS DTAG
no protocol tls-v1.0
no protocol tls-v1.1
no authentication incoming
authentication outgoing
private-key pki:private-key/DEFAULT
own-certificate 1 pki:certificate/DEFAULT
diffie-hellman-parameters pki:diffie-hellman-parameters/DEFAULT-2048

profile tone-set DEFAULT

profile voip DEFAULT
codec 1 g711alaw64k rx-length 20 tx-length 20
codec 2 g722-64k rx-length 20 tx-length 20
codec 3 g711ulaw64k rx-length 20 tx-length 20
codec 4 g729 rx-length 20 tx-length 20
codec 5 transparent-clearmode rx-length 20 tx-length 20
dtmf-relay rtp
response-preferred-codec g711alaw64k
fax transmission 1 relay t38-udp
fax transmission 2 bypass g711alaw64k rx-length 20 tx-length 20
fax max-bit-rate 9600

profile voip SRTP
codec 1 g711alaw64k rx-length 20 tx-length 20
codec 2 g722-64k rx-length 20 tx-length 20
codec 3 g711ulaw64k rx-length 20 tx-length 20
codec 4 transparent-clearmode rx-length 20 tx-length 20
srtp transmission forced
response-preferred-codec g711alaw64k
fax transmission 1 relay t38-udp
fax transmission 2 bypass g711alaw64k rx-length 20 tx-length 20
fax max-bit-rate 9600

profile pstn DEFAULT

profile rip DEFAULT

profile sip DEFAULT

context ip ROUTER

# Depending on the customer network administration #
# set dynamic WAN IP through DHCP like or, if required, set a static IP + routing like here #
interface WAN
ipaddress WAN_IP 217.11.220.244/27

# In our setup, the LAN Itf is used on private side for the SIP-SIP SBC setup #
interface LAN
ipaddress LAN 172.20.74.1/24

# In case of static settings, insert the corresponding routes #
```

```

# Static route in this example, as the WAN Itf has a static IP address #
routing-table DEFAULT
  route 0.0.0.0/0 gateway 217.11.220.225 metric 0

bgp
  shutdown

rip
  shutdown

context ip ROUTER
  use profile dhcp-server DHCP_SERVER_LAN

nodems-client
  organization-key XXXXXXXX # configure your specific Org.Key for Patton Cloud #
  resource any
  no shutdown

profile packetsmart DEFAULT

profile ppp DEFAULT

cwmpp-client
  bind ipaddress ROUTER WAN DHCP
  session-retry-maximum 1
  shutdown

  stun
  shutdown

context cs SWITCH

# internal numbering plan 20x #
# ISDN MSNs : 200,201 on BRI01 and BRI02 #
# SIP phones : 205, 206 #
# DDI translation used : #
# (pubic <---> internal) #
# +49 228 422 23470 <---> 200 #
# +49 228 422 23471 <---> 201 #
# ... #
# +49 228 422 23479 <---> 209 #

mapping-table calling-e164 to calling-e164 MT_INTERNAL_to_SIP_DTAG_CNPN
  map 20(.) to \+492284222347\1

mapping-table called-e164 to called-e164 MT_INTERNAL_to_SIP_DTAG_CDPN
  map 0(.%) to \+49\1
  map 00(.%) to +\1

mapping-table called-e164 to called-e164 MT_SIP_DTAG_to_INTERNAL_CDPN
  map 02284222347(.) to 20\1
  map 492284222347(.) to 20\1

mapping-table calling-numbering-plan to calling-numbering-plan MT_SIP_DTAG_to_INTERNAL_NPI
  map default to isdn-telephony

mapping-table calling-e164 to calling-e164 MT_SIP_DTAG_to_INTERNAL_CNPN
  map 49(.%) to \1

mapping-table calling-e164 to calling-type-of-number MT_SIP_DTAG_to_INTERNAL_CNPN_DE
  map 49(.%) to national

routing-table called-e164 RT_FROM_INTERNAL
  route T dest-interface IF_SIP_DTAG_CF_INTERNAL_to_SIP_DTAG
# in case of SIP/TLS + SRTP, set dest-interface to IF_SIP_DTAG_TLS instead #

# In the RT below, set the PBX DDI range(s) to be routed to the Hunt Group SRV_HG, by using RegEx #
# In our test case, only these two ISDN phone numbers were used 492284222347[01] #
# In our test case, only these two SIP phone numbers were used 492284222347[56] #
routing-table called-e164 RT_FROM_SIP_DTAG
  route 492284222347[01] dest-service SRV_HG_CF_SIP_DTAG_to_INTERNAL
  route 492284222347[56] dest-service SRV_SIP_LOC_MT_SIP_DTAG_to_INTERNAL_CDPN

complex-function CF_INTERNAL_to_SIP_DTAG
  execute 1 MT_INTERNAL_to_SIP_DTAG_CNPN
  execute 2 MT_INTERNAL_to_SIP_DTAG_CDPN

```

```
complex-function CF_SIP_DTAG_to_INTERNAL
execute 1 MT_SIP_DTAG_to_INTERNAL_CDPN
execute 2 MT_SIP_DTAG_to_INTERNAL_NPI
execute 3 MT_SIP_DTAG_to_INTERNAL_CNPN_DE
execute 4 MT_SIP_DTAG_to_INTERNAL_CNPN

interface isdn IF_BRI_00
route call dest-table RT_FROM_INTERNAL
call-reroute emit
diversion emit

interface isdn IF_BRI_01
route call dest-table RT_FROM_INTERNAL
call-reroute emit
diversion emit

interface sip IF_SIP_DTAG
bind context sip-gateway GW_SIP_DTAG
route call dest-table RT_FROM_SIP_DTAG
remote sip-trunk.telekom.de
local telekom.de
hold-method direction-attribute sendonly
no call-transfer emit
call-reroute emit
privacy
uri-scheme sip
address-translation incoming-call called-e164 p-called-party-id
session-timer 1800

interface sip IF_SIP_PHONES
bind context sip-gateway GW_SIP_PHONES
route call dest-table RT_FROM_INTERNAL
local 172.20.74.1
call-reroute accept
privacy

interface sip IF_SIP_DTAG_TLS
bind context sip-gateway GW_SIP_DTAG_TLS
route call dest-table RT_FROM_SIP_DTAG
remote sip-trunk.telekom.de
local telekom.de
hold-method direction-attribute sendonly
no call-transfer emit
call-reroute emit
privacy
uri-scheme sip
address-translation incoming-call called-e164 p-called-party-id
use profile voip SRTP
session-timer 1800

service hunt-group SRV_HG
cyclic
drop-cause normal-undefined
drop-cause no-circuit-channel-available
drop-cause network-out-of-order
drop-cause temporary-failure
drop-cause switching-equipment-congestion
drop-cause access-info-discarded
drop-cause circuit-channel-not-available
drop-cause resources-unavailable
route call 1 dest-interface IF_BRI_00
route call 2 dest-interface IF_BRI_01

service sip-location-service SRV_SIP_LOC
bind location-service LS_SIP_PHONES

context cs SWITCH
no shutdown

# Authentication service : use here the SIP-Trunk credentials provided by DTAG #
authentication-service AS_DTAG_SIPT
username 55XXXXXXXXXX password XXXXXX

authentication-service AS_SIP_PHONES
realm 1 GROUP1
```

```
username 205 password XXXXX  
username 206 password XXXXX
```

```
location-service LS_SIP_DTAG  
domain 1 sip-trunk.telekom.de  
domain 2 telekom.de
```

```
identity +4922842223470  
alias expression [0-9]+
```

```
authentication outbound  
authenticate 1 authentication-service AS_DTAG_SIPT username 55XXXXXXXXXX
```

```
registration outbound  
registrar sip-trunk.telekom.de  
uri-scheme sip  
transport-protocol force tcp  
proxy 1 reg.sip-trunk.telekom.de  
lifetime 1800  
register auto  
flows  
keep-alive options 50
```

```
call outbound  
force-destination registrar address  
proxy 1 reg.sip-trunk.telekom.de  
transport-protocol force tcp  
use profile voip DEFAULT  
flows
```

```
location-service LS_SIP_DTAG_TLS  
domain 1 sip-trunk.telekom.de  
domain 2 telekom.de
```

```
identity +4922842223470  
alias expression [0-9]+
```

```
authentication outbound  
authenticate 1 authentication-service AS_DTAG_SIPT username 55XXXXXXXXXX
```

```
registration outbound  
registrar sip-trunk.telekom.de  
uri-scheme sip  
transport-protocol force tls  
proxy 1 reg.sip-trunk.telekom.de  
lifetime 1800  
register auto  
flows  
keep-alive options 50
```

```
call outbound  
force-destination registrar address  
proxy 1 reg.sip-trunk.telekom.de  
transport-protocol force tls  
use profile voip SRTP  
flows
```

```
call inbound  
use profile voip SRTP
```

```
location-service LS_SIP_PHONES  
domain 1 172.20.74.1  
match-any-domain
```

```
identity-group ID_GROUP_PHONES
```

```
authentication inbound  
authenticate authentication-service AS_SIP_PHONES
```

```
registration inbound  
lifetime default 3600 min 60 max 2147483647
```

```
identity 205 inherits ID_GROUP_PHONES
```

```
authentication inbound
```

```
identity 206 inherits ID_GROUP_PHONES

authentication inbound

sip
no lock-dns-record

context sip-gateway GW_SIP_DTAG
bind location-service LS_SIP_DTAG

interface IF_GW_SIP_DTAG
transport-protocol udp+tcp 5060
no transport-protocol tls
bind ipaddress ROUTER WAN WAN_IP

context sip-gateway GW_SIP_DTAG
no shutdown
# in case of SIP/TLS + SRTP, set state to shutdown #

context sip-gateway GW_SIP_DTAG_TLS
use profile tls PF_TLS_DTAG
bind location-service LS_SIP_DTAG_TLS

interface IF_GW_SIP_DTAG_TLS
no transport-protocol udp+tcp
transport-protocol tls 5061
bind ipaddress ROUTER WAN WAN_IP

context sip-gateway GW_SIP_DTAG_TLS
shutdown
# in case of SIP/TLS + SRTP, set state to no shutdown #

context sip-gateway GW_SIP_PHONES
bind location-service LS_SIP_PHONES

interface IF_GW_SIP_PHONES
transport-protocol udp+tcp 5060
no transport-protocol tls
bind ipaddress ROUTER LAN LAN

context sip-gateway GW_SIP_PHONES
no shutdown

sip-survivability
shutdown

port ethernet 0 0
bind interface ROUTER WAN
no shutdown

port ethernet 0 1
bind interface ROUTER LAN
no shutdown

port bri 0 0

encapsulation q921

q921
protocol pp
permanent-layer2
uni-side net
encapsulation q931

q931
protocol dss1
uni-side net
encapsulation cc-isdn
bind interface IF_BRI_00

port bri 0 0
no shutdown

port bri 0 1

encapsulation q921
```

```
q921  
  protocol pp  
  permanent-layer2  
  uni-side net  
  encapsulation q931
```

```
q931  
  protocol dss1  
  uni-side net  
  encapsulation cc-isdn  
  bind interface IF_BRI_01
```

```
port bri 0 1  
  no shutdown
```

Test plan – Standard calls

Following calls and telephony features have been tested with the configuration described in this guide.

Outgoing calls

Test scenario	Result * / ✓	Comments
Outgoing call to PSTN : call to a fix network number in Germany, call pick up, dialog et hang up by calling party		Calls performed with ISDN and SIP devices behind Patton. In ISDN case, mostly ISDN devices connected through BRI, but also through a BRI/PRI PBX.
The ring back tone is received and displayed by the calling terminal.	✓	
The called device is ringing.	✓	
The caller's number / identity is correctly presented.	✓	
The call is being connected after pick up.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by calling party.	✓	
Call hang up by calling party : call correctly released on both sides.	✓	
Outgoing call to PSTN : call to a fix network number in Germany, call pick up, dialog et hang up by called party		
Call hang up by called party : call correctly released on both sides.	✓	
Outgoing call to PSTN : call to a fix network number in Germany, hang up before pick up		
The device of the called party is ringing.	✓	
Hang up before pick up: called device stops ringing.	✓	

Incoming calls

Test scenario	Result * / ✓	Comments
Incoming call from PSTN : call from a fix network number in Germany, call pick up, dialog et hang up by calling party		Calls performed with ISDN and SIP devices behind Patton. In ISDN case, mostly ISDN devices connected through BRI, but also through a BRI/PRI PBX.
The ring back tone is received and displayed by the calling terminal.	✓	
The called device is ringing.	✓	
The caller's number / identity is correctly presented.	✓	
The call is being connected after pick up.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by calling party.	✓	
Call hang up by calling party : call correctly released on both sides.	✓	
Incoming call from PSTN : call from a fix network number in Germany, call pick up, dialog et hang up by called party		
Call hang up by called party : call correctly released on both sides.	✓	
Outgoing call to PSTN : call to a fix network number in Germany, hang up before pick up		
The phone device of the called party is ringing.	✓	
Hang up before pick up: called device stops ringing.	✓	

DTMF codes (RFC2833 / RFC4733)

Test scenario	Result * / ✓	Comments
Patton's eSBC / Gateway uses RFC 2833 / RFC4733 by sending DTMF events.	✓	
The payload can be set to 101.	✓	
Call a public IVR (for ex. Vodaphone 0800 724 2640 or health care service 116117) and check the correct menu navigation.	✓	
Call a DTAG IVR (for ex. customer service 0800 33 01000 or 0800 33 02202) and check the correct menu navigation.	✓	

Call hold (RFC3264)

Test scenario	Result * / ✓	Comments
Put a call Patton (ISDN BRI/PRI) <-> DTAG/NGN/PSTN on hold		
Use of the method described in RFC 3264 (ReINVITE offer SDP parameter 'media attribute' set to recvonly / sendonly / inactive).	✓	
The remote party of the call is correctly put on hold, according to chapter "2.18 Call Hold and Announcements (Music-on-Hold)" of 1TR118.	✓	The MoH itself is not played by Patton device, but by the (IP)PBX of the remote connected party.
Put call off hold : the communication gets reestablished.	✓	
Put a call Patton (SIP) <-> DTAG/NGN/PSTN on hold		
Use of the method described in RFC 3264 (ReINVITE offer SDP parameter 'media attribute' set to recvonly / sendonly / inactive).	✓	
The remote party of the call is correctly put on hold, according to chapter "2.18 Call Hold and Announcements (Music-on-Hold)" of 1TR118.	✓	The MoH itself is not played by Patton device, but by the (IP)PBX of the remote connected party.
Put call off hold : the communication gets reestablished.	✓	

Emergency calls

These are calls setup from customer's (IP)PBX through Patton SBC to destination numbers 110, 112, 115, 116 (or 11x in general) in R-URI.

The most relevant emergency calls have been tested to check the correct routing by the NGN based on the origin. Also the correct call setup has been verified.

Test scenario	Result * / ✓	Comments
Call the police: 110		
Dial 110 from a device behind Patton SBC. Call setup without delay.	✓	
The call is correctly setup.	✓	
The public-safety point answering the call is responsible for the region of the calling party.	✓	
Call the EU-Emergency: 112		
Dial 112 from a device behind Patton SBC. Call setup without delay.	✓	
The call is correctly setup.	✓	

The public-safety point answering the call is responsible for the region of the calling party.	✓	
Call the Government Service number: 115		
Dial 115 from a device behind Patton SBC. Call setup without delay.	✓	
The call is correctly setup.	✓	
The public-safety point answering the call is responsible for the region of the calling party.	✓	

Unsuccessful calls / wrong dialled numbers

Test scenario	Result ✘/✓	Comments
Call to a busy PSTN subscriber		
Setup a call from a PSTN subscriber line having no Call-Waiting feature enabled. Setup a call from a device behind Patton eSBC / Gateway to this busy PSTN line. The calling terminal informs the user by the display and busy tone that the called party is busy.	✓	
Call a number not belonging to the national numbering plan		
Setup a call from a device behind Patton eSBC / Gateway to a phone number not belonging to the national numbering plan. Either a fast-busy tone is signaled or a corresponding announcement of the provider is played.	✓	
Call a non-existing international phone number		
Setup a call from a device behind Patton eSBC / Gateway to a non-existing / invalid international phone number. Either a fast-busy tone is signaled, or a corresponding announcement of the provider is played.		Could not be tested due to the traffic class limitation in the IP-Test center to only national numbers, but this should also work the same way as the previous test (NGN configuration)

Telephony codecs

Test scenario	Result ✘/✓	Comments
Patton eSBC / Gateway must support G.711a		
The codec G.711a has the highest priority in the offer of outgoing calls. Incoming calls with G.711a codec are correctly answered and G.711a is supported.	✓	
Patton eSBC / Gateway should support G.722	✓	

The codec G.722 is defined with 2 nd priority in the offer of outgoing calls. Incoming calls with G.722 codec are correctly answered and G.722 is supported.		
Patton eSBC / Gateway should support G.711μ, G.729 and clear channel	✓	
The codecs G.711 μ , G.729 and clear channel (RFC 4040[12]) are not modified in offers for calls via the NGN.		

DDI Management (belonging to the SIP-Trunk account DTAG 1TR118)

Test scenario	Result * / ✓	Comments
Authentication		
Outgoing calls from assigned DDI range correctly use the authentication credentials belonging to main number of the SIP-Trunk account.	✓	
From header field		
The From header field of outgoing calls from Patton device contains the DDI of the calling party.	✓	
Correct connection of incoming calls		
Incoming calls from NGN are connected by considering the P-Called-Party-ID header field of the incoming INVITE.	✓	
OIR of incoming calls		
Incoming calls with OIR (Originating Identification Restriction): Patton device correctly interprets the From header field of NGN (set to anonymous@anonymous.invalid) and restricts the presentation of the calling party number.	✓	
OIR of outgoing calls		
Outgoing calls with OIR (Originating Identification Restriction): Patton device sets the Privacy header field to "id" or "user" and the calling party number in the P-Preferred-Identity header field.	✓	

Test plan - Telephony features

Call-Waiting

Test scenario	Result * / ✓	Comments
Setup a first call to a device behind Patton eSBC, then setup a second call from PSTN to the same device and do not pick-up.		
Ring-back tone played on the PSTN calling device.	✓	
The call-waiting signal is played on the busy device.	✓	
Setup a first call to a device behind Patton eSBC, then setup a second call from PSTN to the same device. Hang-up the first call during the call-waiting of the second.		
After hang-up, the first device starts ringing.	✓	
Pick-up the call : the second call is correctly connected.	✓	
Setup a first call to a device behind Patton eSBC, then setup a second call from PSTN to the same device. Put the first call on hold and pick-up the second.		
After hearing the call-waiting signal on the first device, press R-key (or line key). The second call is connected.	✓	
The first call is put on hold	✓	
Pressing R-key (or Swap) allows swapping from one call to the other.	✓	

Blind call transfer (unattended)

As there are many different call scenarios, only the most common use cases have been tested, which are listed below. Furthermore, call transfer tests enable the validation of call-waiting / swapping. Each time we refer to a device behind Patton, we mean an extension belonging to the DDI of the SIP-Trunk. It can be a device on a PBX connected to Patton SmartNode, or an ISDN device directly connected through BRI, or a SIP device registered on SmartNode.

Incoming call transferred to an outgoing call

Test scenario	Result * / ✓	Comments
Call transfer from device behind Patton to a PSTN device: call from a 1st to a 2nd device behind Patton. From the 2nd device, call setup to a PSTN device.		

Setup a call from a 1 st to a 2 nd device behind Patton. Pick up the call on the 2 nd device and put the call on hold. The 1 st device is put on hold.	✓	
Proceed to a call transfer to a PSTN phone number. The call is being transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by calling party.	✓	
Call transfer from one to another device behind Patton: call from a 1st to a 2nd device behind Patton. From the 2nd device, call setup to a 3rd device behind Patton.		
Setup a call from a 1 st to a 2 nd device behind Patton. Pick up the call on the 2 nd device and put the call on hold. The 1 st device is put on hold.	✓	Fully internal call scenario, not involving the SIP-Trunk
Proceed to a call transfer to a 3 rd device behind Patton. The call is being transferred.	✓	Fully internal call scenario, not involving the SIP-Trunk
Voice correctly heard by called party.	✓	Fully internal call scenario, not involving the SIP-Trunk
Voice correctly heard by calling party.	✓	Fully internal call scenario, not involving the SIP-Trunk
Call transfer from a PSTN device to another PSTN device: call from a 1st PSTN device to a device behind Patton. From the 2nd device, call setup to a PSTN device.		
From a PSTN device call a device behind Patton. Pick up the call and put it on hold. The PSTN device is put on hold.	✓	
Proceed to a blind transfer to a 2 nd PSTN device. The call is being transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by calling party.	✓	
Call transfer of an incoming PSTN call to an internal device: call from a PSTN device to a device behind Patton. From this device, call setup to another device behind Patton.		
From a PSTN device call a device behind Patton. Pick up the call and put it on hold. The PSTN device is put on hold.	✓	
Proceed to a blind transfer to a 2 nd device behind Patton. The call is being transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by calling party.	✓	

Transfer from outgoing call to outgoing call

Test scenario	Result * / ✓	Comments
Call transfer of an outgoing call to a PSTN device: call from a 1st to a 2nd device behind Patton. From the 1st device, call setup to a PSTN device.		
Setup a call from a 1 st to a 2 nd device behind Patton. Pick up the call on the 2 nd device and put the call on hold. The 2 nd device is put on hold.	✓	
From the 1 st device proceed to a call transfer to a PSTN phone number. The call is being transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by calling party.	✓	
Call transfer of an outgoing call to a PSTN device: call from a device behind Patton to a PSTN device. From the same device behind Patton, call setup to a 2nd PSTN device.		
Setup a call from a device behind Patton to a PSTN device. Pick up the call and put it on hold. The PSTN device is put on hold.	✓	
From the device behind Patton proceed to a call transfer to another PSTN phone number. The call is being transferred.	✓	
Voice correctly heard by the 1 st PSTN party.	✓	
Voice correctly heard by the 2 nd PSTN party.	✓	
Call transfer of an internal outgoing call to another internal device: call from a 1st to a 2nd device behind Patton. From the 1st device behind Patton, call setup to a 3rd device behind Patton.		
Setup a call from a 1 st to a 2 nd device behind Patton. Pick up the call and put it on hold. The 2 nd device is put on hold.	✓	Fully internal call scenario, not involving the SIP-Trunk
From the 1 st device proceed to a call transfer to a 3 rd device behind Patton. The call is being transferred.	✓	Fully internal call scenario, not involving the SIP-Trunk
Voice correctly heard by called party.	✓	Fully internal call scenario, not involving the SIP-Trunk
Voice correctly heard by transferred party.	✓	Fully internal call scenario, not involving the SIP-Trunk

Attended call transfer

As there are many different call scenarios also in this case, only the most common use cases have been tested, which are listed below.

Incoming call transferred to an outgoing call

Test scenario	Result * / ✓	Comments
Call transfer of an internal incoming call to PSTN device: call from a 1st to a 2nd device behind Patton. From the 2nd device behind Patton, call setup to a PSTN device.		
Setup a call from a 1 st to a 2 nd device behind Patton. Pick up the call on the 2 nd device and put the call on hold. The 1 st device is put on hold.	✓	
From the second internal device, call a PSTN device. The call is correctly setup.	✓	
Transfer the call (from 2 nd device). The call is correctly transferred	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by transferred party.	✓	
Call transfer from one to another internal device behind Patton : call from a 1st to a 2nd device behind Patton. From the 2nd, call to 1 3rd internal device.		
From a 1 st , call a 2 nd device behind Patton. On the 2 nd device pick up the call and put it on hold. The 1 st internal device is put on hold.	✓	Fully internal call scenario, not involving the SIP-Trunk
From the 2 nd internal device, call a 3 rd internal device. The call is correctly setup.	✓	
Proceed to call transfer. The call is correctly transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by transferred party.	✓	
Transfer of a PSTN call to a PSTN device : call from a 1st PSTN device to an internal device. From the internal device, call a 2nd PSTN device.		
From a 1 st PSTN device, call an internal device behind Patton. On the internal device, pick up the call and put it on hold. The 1 st PSTN device is correctly put on hold.	✓	
From the internal device, call a 2 nd PSTN device. The call is correctly setup.	✓	
Proceed to call transfer. The call is correctly transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by transferred party.	✓	
Transfer of a PSTN call to an internal device : call from a PSTN device to a 1st internal device. From this 1st internal device, call 1 2nd internal device.		

From a PSTN device, setup a call to a 1st internal device. On this 1st internal device, pick up the call and put it on hold. The PSTN device is put on hold.	✓	
From the 1st internal device, call a 2 nd internal device. The call is correctly setup.	✓	
Proceed to call transfer. The call is correctly transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by transferred party.	✓	

Transfer of outgoing calls : outgoing call transferred to outgoing call

Test scenario	Result * / ✓	Comments
Transfer of an internal outgoing call to a PSTN device: call from a 1st internal device to a 2nd one. From the 1st internal device, call a PSTN device.		
Setup a call from a 1st internal device to a 2nd one. From the 1st internal device, put the call on hold. The 2 nd internal device is correctly put on hold.	✓	
From the 1st internal device, call a PSTN device. The call is correctly setup.	✓	
Proceed to call transfer. The call is correctly transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by transferred party.	✓	
Transfer of an outgoing PSTN call to a PSTN device : Call from an internal to a 1st PSTN device. From the internal device, call a 2nd PSTN device.		
From an internal device, call a 1 st PSTN device. From the internal device, put the call on hold. The 1st PSTN device is correctly put on hold.	✓	
From the internal device, call a 2 nd PSTN device. The call is correctly setup.	✓	
Proceed to call transfer. The call is correctly transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by transferred party.	✓	
Transfer of an internal outgoing call to another internal device : call from a 1st to a 2nd internal device. From the 1st internal device, call a 3rd internal device.		
From a 1st internal device, call a 2 nd internal device. From the 1st device, put the call on hold. The 2 nd device is put on hold.	✓	

From the 1st internal device, call a 3 rd internal device. The call is correctly setup.	✓	
Proceed to call transfer. The call is correctly transferred.	✓	
Voice correctly heard by called party.	✓	
Voice correctly heard by transferred party.	✓	

3-party conferences

Test scenario	Result * / ✓	Comments
Setup a 1st call from one to another internal device. From the 1st one, call a PSTN device and establish a 3-party conference.		
From an internal device, call another internal device. From the 1st internal device, put the call on hold and setup a 2 nd call to a PSTN device. The 2 nd internal device is correctly put on hold and the communication with the PSTN device is established.	✓	The conference feature was tested from either a SIP device registered on Patton eSBC or an ISDN PBX with its internal conference feature, but not from a simple ISDN phone connected to eSBC through BRI port (ISDN phones not supporting 3-P conf. without a PBX)
Establish the conference. The conference is properly established.	✓	
The first device hears the two other devices.	✓	
The two other devices hear the 1st device.	✓	
The two other devices can hear each other.	✓	
Setup a 1st call from one to another internal device. From the 1st one, call a 3rd internal device and establish a 3-party conference.		
From an internal device, call another internal device. From the 1st internal device, put the call on hold and setup another call to a 3 rd internal device. The 2 nd internal device is correctly put on hold and the communication with the 3 rd internal device device is established.		Completely internal call scenario. The conference feature was tested from either a SIP device registered on Patton eSBC or an ISDN PBX with its internal conference feature, but not from a simple ISDN phone connected to eSBC through BRI port (ISDN phones not supporting 3-P conf. without a PBX)
Establish the conference. The conference is properly established.		
The first device hears the two other devices.		
The two other devices hear the 1st device.		
The two other devices can hear each other.		
Setup a 1st call from an internal device to a 1st PSTN device. From the internal device, call a 2nd PSTN device and establish a 3-party conference.		
From an internal device, call a 1 st PSTN device. From the internal device, put the call on hold and setup another call to a	✓	The conference feature was tested from either a SIP device registered on Patton eSBC or an

2 nd PSTN device. The 1 st PSTN device is correctly put on hold and the communication with the 2 nd PSTN device is established.		ISDN PBX with its internal conference feature, but not from a simple ISDN phone connected to eSBC through BRI port (ISDN phones not supporting 3-P conf. without a PBX)
Establish the conference. The conference is properly established.	✓	
The first device hears the two other devices.	✓	
The two other devices hear the 1st device.	✓	
The two other devices can hear each other.	✓	

Caller Identity Presentation / CLIP

Test scenario	Result ✘/✓	Comments
CLIP towards a PSTN device		
From an internal device, setup a call to a PSTN having the CLIP feature available. The calling party number presentation is correct. The call is being connected.	✓	Tested in all previous call scenarios as well.
CLIP towards a device behind Patton		
From a PSTN device, setup a call to an internal device (over SIP-Trunk). The calling party number presentation is correct.	✓	
The calling party name (if any) is correctly displayed. The call is correctly connected.	✓	
CLIR / OIR (Identity restriction)		
On an internal device, activate the Identity Restriction (on SIP devices : enable anonymous calls). From this device, setup a call to a PSTN having the CLIP feature available. The calling party number is NOT presented. The call is being connected.	✓	CLIR call from SIP device with public phone number +4922842223475; Patton eSBC sets the Privacy: id header field and the From + PPI header fields are set to Anonymous <sip:+4922842223475@telekom.de> Result OK CLIR from ISDN phone / PBX, Patton eSBC sets Privacy: id, and From + PPI headers still contain whole user identity in the user part; Result OK
CLIR / OIR towards a device behind Patton		
Setup an external call from PSTN to an internal device supporting the CLIP feature. The calling party number is NOT presented. The call is being connected.	✓	
Correct presentation of DDI		
On outgoing calls from a device belonging to the assigned DDI-Range of the SIP-Trunk, the correct DDI number is presented on the PSTN called device.	✓	

Swapping between two hold calls

Hold a PSTN call	Result * / ✓	Comments
Setup a call with a PSTN device from/to an internal one, then put the call on hold from the internal device. The music on hold is heard correctly on the PSTN device.	✓	MoH dependent on the remote party PBX capabilities.
Swapping from one held call to the other reconnects to the waiting party without issues.	✓	

Call forwarding


Test scenario	Result * / ✓	Comments
Call Forwarding Unconditional (CFU) of a PSTN call to another PSTN device		
Set a CFU from an internal device to a 1st PSTN device. From a 2 nd PSTN device, call this internal device with activated CFU. The 1st PSTN device starts ringing immediately.	✓	"call-reroute emit" configured on Patton SIP interface towards DTAG → 302 moved temporarily response to DTAG, working OK (RTP does not flow through SIP-Trunk)
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding Unconditional (CFU) of an internal call to a PSTN device		
Keep the same CFU activated before. From another internal device, call the internal device on which CFU is active. The PSTN device (CFU target number) starts ringing immediately.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding Unconditional (CFU) of a PSTN call to another internal device		
Set a CFU from an internal device to another internal device. From a PSTN device, call this internal device with activated CFU. The 2 nd internal device (CFU target number) starts ringing immediately.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding Unconditional (CFU) of an internal call to another internal device		
Keep the same CFU activated before. From another (3 rd) internal device, call the internal device on which CFU is active. The 2 nd internal device (CFU target number) starts ringing immediately.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding No Reply (CFNR) of a PSTN call to another PSTN device		
Deactivate all call forwardings. Activate a CFNR to a PSTN device, with for example ringing duration of 20s before forwarding. From another PSTN device, call the internal device on which CFNR was activated and do not pick up the call. The internal device is ringing during 20s, then stops ringing.	✓	"call-reroute emit" configured on Patton SIP interface towards DTAG → 302 moved temporarily response to DTAG, working OK (RTP does not flow through SIP-Trunk)
The target PSTN device starts ringing. Pick up the call.	✓	

The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding No Reply (CFNR) of an internal call to a PSTN device		
Keep the same CFNR activated before. From another internal device, call the internal device on which CFNR was activated. The internal device is ringing during the configured delay (20s), then stops ringing.	✓	
The target PSTN device starts ringing. Pick up the call.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding No Reply (CFNR) of a PSTN call to another internal device		
Deactivate all call forwardings. Activate a CFNR to another internal device, with for example ringing duration of 20s before forwarding. From another PSTN device, call the internal device on which CFNR was activated and do not pick up the call. The internal device is ringing during 20s, then stops ringing.	✓	
The other internal device (CFNR target number) starts ringing. Pick up the call.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding No Reply (CFNR) of an internal call to another internal device		
Keep the same CFNR activated before. From a 3rd internal device, call the internal device on which CFNR was activated and do not pick up. The 1st device starts is ringing during 20s, then stops ringing.	✓	
The other internal device (CFNR target number) starts ringing. Pick up the call.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding Busy (CFB) of a PSTN call to another PSTN device		
Deactivate all call forwardings. On an internal device, activate a CFB to a PSTN device. Let this internal device be busy. From another PSTN device, call this internal device. The PSTN device, which was configured as CFB target number, starts ringing immediately. Pick up the call.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding Busy (CFB) of an internal call to a PSTN device		

Keep the CFB previously activated. Let the internal device with activated CFB be busy. From another internal device, call this internal device. The PSTN device (CFB target number) starts ringing immediately.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding Busy (CFB) of a PSTN call to another internal device		
Deactivate all call forwardings. Activate a CFB to another internal device. Let the internal device with activated CFB be busy. From a PSTN device, call this 1 st internal device. The PSTN device (CFB target number) start ringing immediately. Pick up the call.	✓	
The call is established between the two devices and both parties hear each other.	✓	
Call Forwarding Busy (CFB) of an internal call to another internal device		
Keep the CFB previously activated. Let the internal device with activated CFB be busy. From another (3 rd) internal device, call this 1 st internal device. The 2 nd internal device (CFB target number) starts ringing immediately. Pick up the call.	✓	
The call is established between the two devices and both parties hear each other.	✓	

Fax calls

Fax calls have been tested within the following network topology in the 3rd Party Lab of DTAG:



Outgoing Fax calls:

Fax 1 -> Patton GW1-> IAD -> NGN 1TR118 -> NGN 1TR119 -> IAD -> Patton GW2 -> Fax 2

- T.38 Fax calls tested successfully with provided configuration
- Fallback to G.711 tested successfully

Incoming Fax calls:

Fax 2 -> Patton GW2-> IAD -> NGN 1TR119 -> NGN 1TR118 -> IAD -> Patton GW1 -> Fax 1

- T.38 Fax calls tested successfully with provided configuration
- Fallback to G.711 tested successfully

Signalling and Media Security (TLS & SRTP)

SIP/TLS and SRTP have been successfully tested with the provided configuration guide, which is fully prepared for both configurations.

In order for SIP/TLS and SRTP to work with this Patton Configuration, only the three following minimal changes must be done, as already highlighted in the configuration guide above:

- Deactivate the SIP Gateway for SIP/TCP (shutdown)
- Activate the SIP Gateway for TLS (no shutdown)
- Replace dest-interface IF_SIP_DTAG by dest-interface IF_SIP_DTAG_TLS in the Routing Table from internal side to SIP-Trunk.

Contacting Patton Support & Sales

Support

e-Mail: support@patton.com

Phone: +41 31 985 2555

Sales

e-Mail: we@patton.com

Phone: +41 31 985 2525